

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
ABW ○○R○○○○	B37	Insert (Turning)
ABW ○○R○○○○M	B37	Insert (Turning)
ACLС% ○(○)-○JXF	E22	Toolholder (Turning)
ACLС% ○○○○□□-○○FF	E22	Toolholder (Turning)
ADJС% ○(○)-○JXF	E24	Toolholder (Turning)
ADJС% ○○○○□□-○○FF	E24	Toolholder (Turning)
AVJB% ○(○)-○JXF	E30	Toolholder (Turning)
AVJB% ○○○○□□-○○FF	E30	Toolholder (Turning)
B		
BDGT ○○T○○○FR-JA	M2	Insert (Milling)
BDMT ○○T○○○ER-JS	M2	Insert (Milling)
BDMT ○○T○○○ER-JT	M2	Insert (Milling)
BDMT ○○T○○○FR	C17,M2	Insert (Milling)
BDMT ○○○○○○ER-JS	M2	Insert (Milling)
BDMT ○○○○○○ER-JT	M2	Insert (Milling)
C		
○○○○□- SCLCRO○-○○○EZ	F18	Toolholder (EZ Bar-Plus)
○○○(○)□- SCLС%○	F43	Boring Bars
○○○(○)□- SCLС%○○-○○A	F39	Boring Bars (Dynamic Bar)
○○○□- SCLP%○	F43	Boring Bars
○○○□- SJLC%○○-○○○	F50	Boring Bars
○○○□- SJZС%○○-○○○	F50	Boring Bars
○○○□- STLB%○○-○○A	F53	Boring Bars (Dynamic Bar)
○○○□- STXB%○○-○○○	F50	Boring Bars / Previous Part Number
○○○□- STXP%○○-○○○	F56	Boring Bars / Previous Part Number
○○○□- STZB%○○-○○○	F56	Boring Bars / Previous Part Number
○○○□- SWUB%○	F66	Boring Bars
○○○□- SWUB%○○-○○A	F65	Boring Bars (Dynamic Bar)
CCET ○○○○○F%-USF	B11	Insert (Turning)
CCET ○○○○○(○)(○)M%-F	B10	Insert (Turning)
CCET ○○○○○(○)(○)MF%-J	B12	Insert (Turning)
CCET ○○○○○(○)(○)MF%-U	B11	Insert (Turning)
CCET ○○○○○(○)MF%-USF	B11	Insert (Turning)
CCET ○○○○○(○)(○)M%-FSF	B10	Insert (Turning)
CCET ○○○○○(○)%-FSF	B10	Insert (Turning)
CCGT ○○○○(○)	B9	Insert (Turning)
CCGT ○○○○AH	B12	Insert (Turning)
CCGT ○○○○○(○)E%-U	B12	Insert (Turning)
CCGT ○○○○○F%-U	B12	Insert (Turning)
CCGT ○○○○○(○)(○)M	B9	Insert (Turning)
CCGT ○○○○○○M-CF	B8	Insert (Turning)
CCGT ○○○○○○MP-CF	B8	Insert (Turning)
CCGT ○○○○○○MP-CK	B8	Insert (Turning)
CCGT ○○○○○(○)ME%-U	B12	Insert (Turning)
CCGT ○○○○○(○)(○)MF	B10	Insert (Turning)

Part Number	Page	Description
CCGT ○○○○(○)MF-GF	B8	Insert (Turning)
CCGT ○○○○(○)MFP-GF	B8	Insert (Turning)
CCGT ○○○○(○)MF-GQ	B8	Insert (Turning)
CCGT ○○○○(○)MFP-GQ	B9	Insert (Turning)
CCGT ○○○○(○)MFP-SK	B8	Insert (Turning)
CCGT ○○○○(○)(○)MF%-U	B12	Insert (Turning)
CCGT ○○○○○(○)(○)M%-F	B11	Insert (Turning)
CCGT ○○○○(○)(○)%-A3	B13	Insert (Turning)
CCGT ○○○○○(○)%-F	B11	Insert (Turning)
CCGW ○○○○(○)(○)	B13,C12	Insert (Turning)
CCGW ○○○○(○)(○)NE	C12	Insert (Turning)
CCGW ○○○○(○)(○)SE	C12	Insert (Turning)
CCMT ○○○○(○)	B9,C12	Insert (Turning)
CCMT ○○○○(○)(○)GK	B9	Insert (Turning)
CCMT ○○○○(○)HQ	B9	Insert (Turning)
CCMT ○○○○MQ	B10	Insert (Turning)
CCMT ○○○○(○)NE	C12	Insert (Turning)
CCMT ○○○○(○)PP	C9	Insert (Turning)
CCMT ○○○○(○)SE	C12	Insert (Turning)
CCMW ○○○○MEF	C4	Insert (Turning)
CCMW ○○○○S○○○○○MES	C4	Insert (Turning)
CCMW ○○○○S○○○○○MET	C4	Insert (Turning)
CCMW ○○○○(○)(○)S○○○○○SET	C4	Insert (Turning)
CCMW ○○○○(○)T○○○○○OME	C4	Insert (Turning)
CCMW ○○○○(○)(○)T○○○○○OSE	C4	Insert (Turning)
CKC-2%	G24,J27	Spare Parts (Clamp)
CNGG ○○○FP-TK	B41	Insert (Turning)
CNGG ○○○(○)MFP-SK	B41	Insert (Turning)
CNGU ○○○○(○)ME%-U	B38	Insert (Turning)
CNGU ○○○○(○)(○)MF%-F	B38	Insert (Turning)
CNGU ○○○○(○)(○)MF%-U	B38	Insert (Turning)
CNGU ○○○○MF-SK	B38	Insert (Turning)
CNGU ○○○○MFP-SK	B38	Insert (Turning)
CNMU ○○○○(○)E-GK	B38	Insert (Turning)
CPGB ○○○S○○○○○MES	C4	Insert (Turning)
CPGB ○○○(○)(○)S○○○○○MET	C4	Insert (Turning)
CPGB ○○○(○)(○)S○○○○○SET	C4	Insert (Turning)
CPGB ○○○(○)(○)T○○○○○OME	C4	Insert (Turning)
CPGB ○○○(○)(○)T○○○○○OSE	C4	Insert (Turning)
CPGT ○○○○(○)	B13	Insert (Turning)
CPMB ○○○(○)(○)(○)	B14	Insert (Turning)
CPMH ○○○(○)(○)(○)	B13,G13	Insert (Turning)
CPMH ○○○(○)(○)HQ	B13	Insert (Turning)
CPMH ○○○(○)(○)(○)NE	C13	Insert (Turning)
CPMH ○○○(○)(○)%-Y	B14	Insert (Turning)
CPMH ○○○(○)(○)SE	C13	Insert (Turning)
CPMT ○○○(○)(○)GP	B13	Insert (Turning)

GRADES	A
INSERTS	B
CBN & POD	C
TURNING	E
BORING	F
GRINDING	G
CUT-OFF	H
THREADING	J
SOLID END MILLS	L
MILLING	M
SPARE PARTS	P
TECHNICAL	R
INDEX	T