для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
AABSR	○(○)-○○□□F	E17, E48	Toolholder (Back Turning)
AABSR	○○○○□□-○○F	E17, E48	Toolholder (Back Turning)
AABWR	○(○)-○○□□F	E18, E19, E48	Toolholder (Back Turning)
AABWR	○○○○□□-○○F	E18, E19, E48	Toolholder (Back Turning)
ABS	○○R○○○○	B86	Insert (Back Turning)
ABS	○○R○○○○M	B86	Insert (Back Turning)
ABW	○○R○○○○	B86	Insert (Back Turning)
ABW	○○R○○○○M	B86	Insert (Back Turning)
ACLC%L	○○○○-○○F	E48, P21	Toolholder (Turning / Discontinued Description)
ACLC%L	○(○)-○□□FF	E22, E48	Toolholder (Turning)
ACLC%L	○○○○□□-○○FF	E22, E48	Toolholder (Turning)
AD○○□		F76	Boring Bars (AD Bar Adaptor)
ADJC%L	○(○)-○□□FF	E24, E48	Toolholder (Turning)
ADJC%L	○○○○-○○F	E48, P21	Toolholder (Turning / Discontinued Description)
ADJC%L	○○○○□□-○○FF	E24, E48	Toolholder (Turning)
ADNCR	○○○○-○○F	E48, P21	Toolholder (Turning / Discontinued Description)
AJ-6X38		P2	Spare Parts (Screw)
AJ-8X44-9.5		P2	Spare Parts (Screw)
AJ-10X46		P2	Spare Parts (Screw)
AJM5F		N14-N16	Spare Parts (Axial Adjustment Screw)
AJM6		N14	Spare Parts (Axial Adjustment Screw)
AVJB%L	○○○○□-○○F	E48, P21	Toolholder (Turning / Discontinued Description)
AVJB%L	○-○□□FF	E30, E48	Toolholder (Turning)
AVJB%L	○○○○□□-○○FF	E30, E48	Toolholder (Turning)
AVVB%L	○○○○□-○○F	E48, P21	Toolholder (Turning / Discontinued Description)
B			
BCS	-○	H29, P13	Spare Parts (Clamp Set)
BGIAR	○○-○		Blade (Grooving)
BH3X6		F91, P2	Spare Parts (Screw)
BH3X12		D35-37, F89, P2	Spare Parts (Screw)
BH6X10TR		G23-G25, G84, G92-G93, H8, H19, P12	Spare Parts (Screw)
BH6X25		P12	Spare Parts (Screw)
BH8X30		P12	Spare Parts (Screw)
C			
C○○□-	SCLC%L○○-○○	F100	Boring Bars (Discontinued Description)
C○○□-	SCLC%L○(.○)	F43	Boring Bars (General Purpose)
C○○□-	SCLC%L○○-○○A	F39	Boring Bars (Dynamic Bar)
C○○□-	SCLC%L○○-○○-AS	F97	Boring Bars (Assembly(AS) / Discontinued Description)
C○○□-	SCLCR○○-○○○EZ	F20	Boring Bars (EZ Bar PLUS)
C○○□-	SCLP%L○(.○)	F43	Boring Bars (General Purpose)
C○○□-	SCLP%L○○-○○	F100	Boring Bars (Discontinued Description)
C○○□-	SCLP%L○○-○○-○/○	F100	Boring Bars (Discontinued Description)
C○○□-	SDUC%L○○-○○	F100	Boring Bars (Discontinued Description)
C○○□-	SJLC%L○○-○○○	F50	Boring Bars
C○○□-	SJZC%L○○-○○○	F50	Boring Bars
C○○□-	STLB%L○○-○○A	F53	Boring Bars (Dynamic Bar)
C○○□-	STUB%L○○-○○	F100	Boring Bars (Discontinued Description)
C○○□-	STUP%L○○-○○	F100, F101	Boring Bars (Discontinued Description)
C○○□-	STUP%L○○-○○-○/○	F100, F101	Boring Bars (Discontinued Description)
C○○□-	STUPR○○-○○-AS	F97	Boring Bars (Assembly(AS) / Discontinued Description)
C○○□-	STXB%L○○-○○○	F57	Boring Bars
C○○□-	STXP%L○○-○○	F57	Boring Bars
C○○□-	STZB%L○○-○○○	F57	Boring Bars
C○○□-	SWUB%L○.○	F69	Boring Bars (General Purpose)
C○○□-	SWUB%L○○-○○	F101	Boring Bars (Discontinued Description)
C○○□-	SWUB%L○○-○○A	F67	Boring Bars (Dynamic Bar)
C○○□-	SWUB%L○○-○○-AS	F97	Boring Bars (Assembly(AS) / Discontinued Description)
C○○□-	SWUB%L○○-○○-○/○	F101	Boring Bars (Discontinued Description)
C○○□-	SWUP%L○○-○○	F101	Boring Bars (Discontinued Description)
C○○□-	SWUP%L○○-○○-○/○	F101	Boring Bars (Discontinued Description)
C09N		P15	Spare Parts (Clamp)
C17R		P15	Spare Parts (Clamp)
C20R		P15	Spare Parts (Clamp)
C25R		P15	Spare Parts (Clamp)
CB-11		D27, D36, D37, P16	Spare Parts (Chipbreaker)
CB-12		D28, F89, P16	Spare Parts (Chipbreaker)
CB-13		D28, F89, P16	Spare Parts (Chipbreaker)
CB-14		D25, P16	Spare Parts (Chipbreaker)
CB-15		D25, P16	Spare Parts (Chipbreaker)
CB-16		D24, D25, F89, P16	Spare Parts (Chipbreaker)
CB-17		D24, P16	Spare Parts (Chipbreaker)
CB-51		D27, P16	Spare Parts (Chipbreaker)
CB-S3220		E42, P16	Spare Parts (Chipbreaker)
CB-S4220		E42, P16	Spare Parts (Chipbreaker)
CBSN%L	○○○○□-○○	D40	Toolholder (Turning)
CBSN%L	○○○○B-12-A20	F72	Boring Bar (for Bearing Machining)
CB-T2212		E43, P16	Spare Parts (Chipbreaker)
CB-T3220		E43, P16	Spare Parts (Chipbreaker)
CCET	○○○○(○)F%L-USF	B55	Insert (Turning)
CCET	○○○○(○)(○)MF%L-J	B56	Insert (Turning)
CCET	○○○○(○)(○)MF%L-U	B55	Insert (Turning)
CCET	○○○○(○)(○)MF%L-USF	B55	Insert (Turning)
CCET	○○○○(○)(○)M%L-F	B54	Insert (Turning)
CCET	○○○○(○)(○)M%L-FSF	B54	Insert (Turning)
CCET	○○○○(○)(○)%L-FSF	B54	Insert (Turning)
CCGT	○○○○(○)(○)	B53	Insert (Turning)
CCGT	○○○○AH	B56	Insert (Turning)
CCGT	○○○○(○)E%L-U	B56	Insert (Turning)
CCGT	○○○○○F%L-U	B56	Insert (Turning)
CCGT	○○○○(○)(○)M	B53	Insert (Turning)
CCGT	○○○○○○M-CF	B52	Insert (Turning)
CCGT	○○○○(○)ME%L-U	B56	Insert (Turning)
CCGT	○○○○(○)(○)MF	B54	Insert (Turning)
CCGT	○○○○(○)MF-GF	B52	Insert (Turning)
CCGT	○○○○(○)MF-GQ	B52	Insert (Turning)
CCGT	○○○○(○)MFP-GF	B52	Insert (Turning)
CCGT	○○○○(○)MFP-GQ	B53	Insert (Turning)
CCGT	○○○○(○)MFP-SK	B52	Insert (Turning)
CCGT	○○○○(○)(○)MF%L-U	B56	Insert (Turning)
CCGT	○○○○○○MP-CF	B52	Insert (Turning)
CCGT	○○○○(○)MP-CK	B52	Insert (Turning)
CCGT	○○○○○(○)(○)M%L-F	B55	Insert (Turning)
CCGT	○○○(○)(○)(○)%L-A3	B57	Insert (Turning)
CCGT	○○○○○(○)(○)%L-F	B55	Insert (Turning)
CCGW	○○○○(○)(○)	B57, C24	Insert (Turning)
CCGW	○○○○(○)(○)NE	C24	Insert (Turning)
CCGW	○○○○(○)(○)SE	C24	Insert (Turning)
CCLN%L	○○○○□-○○	D24	Toolholder (Turning)
CCLN%L	○○○○□-○○A	D34, F91	Toolholder (Turning)
CCLN%L	○○○○B-○○A	F91	Boring Bar (Previous Description)
CCLN%L	○○○○□-○○GX	D30	Toolholder (Turning)
CCMT	○○○○(○)	B53, C24	Insert (Turning)
CCMT	○○○(○)(○)GK	B53	Insert (Turning)
CCMT	○○○○(○)HQ	B53	Insert (Turning)
CCMT	○○○○MQ	B54	Insert (Turning)
CCMT	○○○○(○)NE	C24	Insert (Turning)
CCMT	○○○○(○)PP	B53	Insert (Turning)
CCMT	○○○○(○)SE	C24	Insert (Turning)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru