для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
CCMT	○○○○(○)WP	B53	Insert (Turning)
CCMW	○○○○MEF	C14	Insert (Turning)
CCMW	○○○○S○○○○○MES	C14	Insert (Turning)
CCMW	○○○○(○)(○) S○○○○○SET	C14	Insert (Turning)
CCMW	○○○○(○)T○○○○○ME	C14	Insert (Turning)
CCMW	○○○○(○)(○) T○○○○○SE	C14	Insert (Turning)
CCMW	○○○○S○○○○○MET	C14	Insert (Turning)
CCRN%	○○○○□-○○A	D34	Toolholder (Turning)
CDHN%	○○○○□-○○GX	D31	Toolholder (Turning)
CDJN%	○○○○□-○○	D25	Toolholder (Turning)
CDJN%	○○○○□-○○GX	D31	Toolholder (Turning)
CE-010		D24, D25, F89, P13	Spare Parts (Clamp Set)
CE-020		D27, D28, D36, D37, P13	Spare Parts (Clamp Set)
CE-030		D29, P13	Spare Parts (Clamp Set)
CE-030A		D27, D29, D34-D38, P13	Spare Parts (Clamp Set)
CE-040		D27, D29, D37, P13	Spare Parts (Clamp Set)
CE-111		P15	Spare Parts (Clamp)
CE-121		P15	Spare Parts (Clamp)
CE-131		P15	Spare Parts (Clamp)
CE-141		P15	Spare Parts (Clamp)
CE-220		D24, D27, P13	Spare Parts (Clamp Set)
CE-320		F89, P13	Spare Parts (Clamp Set)
CE-360S		F89, F91, P13	Spare Parts (Clamp Set)
CE-410		D30-D33, F90, P13	Spare Parts (Clamp Set)
CE-430		D31, P13	Spare Parts (Clamp Set)
CELNR	○○○○B-○○	F89	Boring Bar (Previous Description)
CELN%	○○○○□-○○	D25	Toolholder (Turning)
CGA-3%		G41, P15	Spare Parts (Clamp)
CGA-4%		G41, P15	Spare Parts (Clamp)
CGA-5%		G41, P15	Spare Parts (Clamp)
CGB%		P15	Spare Parts (Clamp)
CGH-1%		G40, G67, P15	Spare Parts (Clamp)
CGH-2%		G40, G67, P15	Spare Parts (Clamp)
CGH-3%		G40, P15	Spare Parts (Clamp)
CGIA-3R		G69, P15	Spare Parts (Clamp)
CGIA-4R		G69, P15	Spare Parts (Clamp)
CGIA-5R		G69, P15	Spare Parts (Clamp)
CH-20R		P15	Spare Parts (Clamp)
CIN%	○○○○S-○○	J21	Toolholder (Threading)
CKC-2%		G31, G71, J16, J17	Spare Parts (Clamp)
CKC-3%		G31, G71, G117, J17	Spare Parts (Clamp)
CL-6		D14	Spare Parts (Clamp)
CL-9		D12, D14	Spare Parts (Clamp)
CL-12		D8, D19	Spare Parts (Clamp)
CL-20		D8, D10, D22	Spare Parts (Clamp)
CL-30		D19	Spare Parts (Clamp)
CL63-1		N3-N10, P19	Spare Parts (Coolant Pipe)
CL100-1		N3-N4, N10, P19	Spare Parts (Coolant Pipe)
CNGA	○○○	B20	Insert (Turning)
CNGA	○○○MEF	C6	Insert (Turning)
CNGA	○○○S○○○○○	B90	Insert (Turning)
CNGA	○○○(○)S○○○○○ME	C6	Insert (Turning)
CNGA	○○○S○○○○○MEH	C6	Insert (Turning)
CNGA	○○○S○○○○○MEP	C6	Insert (Turning)
CNGA	○○○S○○○○○MET	C6	Insert (Turning)
CNGA	○○○S○○○○○MEW	C6	Insert (Turning)
CNGA	○○○S○○○○○SE	C6	Insert (Turning)
CNGA	○○○S○○○○○SET	C6	Insert (Turning)
CNGA	○○○T○○○○○	B90	Insert (Turning)
CNGA	○○○T○○○○○AA	B90	Insert (Turning)
CNGA	○○○T○○○○○ME	C6	Insert (Turning)
CNGA	○○○T○○○○○SE	C6	Insert (Turning)
CNGG	○○○AH	B20	Insert (Turning)
CNGG	○○○FP-TK	B18	Insert (Turning)
CNGG	○○○HQ	B14	Insert (Turning)
CNGG	○○○(○)MFP-SK	B18	Insert (Turning)
CNGG	○○○%	B21	Insert (Turning)
CNGG	○○○%-25R	B21	Insert (Turning)
CNGG	○○○%-A3	B20	Insert (Turning)
CNGG	○○○(○)%-S	B21	Insert (Turning)
CNGG	○○○TK	B18	Insert (Turning)
CNGG	○○○Z	B21	Insert (Turning)
CNGM	○○○S○○○○○BB○	C7	Insert (Turning)
CNG	○○○T○○○○○AA	B90	Insert (Turning)
CNG	○○○T○○○○○	B90	Insert (Turning)
CNGU	○○○○(○)ME%-U	B49	Insert (Turning)
CNGU	○○○○(○)(○)MF%-F	B49	Insert (Turning)
CNGU	○○○○(○)(○)MF%-U	B49	Insert (Turning)
CNGU	○○○○○MF-SK	B49	Insert (Turning)
CNGU	○○○○○MFP-SK	B49	Insert (Turning)
CNGX	○○○T○○○○○	B90	Insert (Turning)
CNMA	○○○	B20	Insert (Turning)
CNMA	○○○T○○○○○AA	B90	Insert (Turning)
CNMG	○○○	B16	Insert (Turning)
CNMG	○○○AH	B20	Insert (Turning)
CNMG	○○○C	B19	Insert (Turning)
CNMG	○○○CJ	B15	Insert (Turning)
CNMG	○○○CQ	B14	Insert (Turning)
CNMG	○○○GC	B20	Insert (Turning)
CNMG	○○○(○)GP	B14	Insert (Turning)
CNMG	○○○GS	B15	Insert (Turning)
CNMG	○○○GT	B16	Insert (Turning)
CNMG	○○○GU	B18	Insert (Turning)
CNMG	○○○HK	B15	Insert (Turning)
CNMG	○○○HQ	B14	Insert (Turning)
CNMG	○○○HS	B15	Insert (Turning)
CNMG	○○○HT	B16	Insert (Turning)
CNMG	○○○HU	B18	Insert (Turning)
CNMG	○○○MQ	B19	Insert (Turning)
CNMG	○○○MS	B19	Insert (Turning)
CNMG	○○○MU	B19	Insert (Turning)
CNMG	○○○PG	B15	Insert (Turning)
CNMG	○○○PH	B16	Insert (Turning)
CNMG	○○○(○)PP	B14	Insert (Turning)
CNMG	○○○PQ	B14	Insert (Turning)
CNMG	○○○PS	B15	Insert (Turning)
CNMG	○○○PT	B16	Insert (Turning)
CNMG	○○○TK	B18	Insert (Turning)
CNMG	○○○TN-V	B15	Insert (Turning)
CNMG	○○○WP	B14	Insert (Turning)
CNMG	○○○WQ	B14	Insert (Turning)
CNMG	○○○XF	B17	Insert (Turning)
CNMG	○○○XP	B17	Insert (Turning)
CNMG	○○○XQ	B17	Insert (Turning)
CNMG	○○○XS	B17	Insert (Turning)
CNMG	○○○ZS	B19	Insert (Turning)
CNMM	○○○(○)M	C23	Insert (Turning)
CNMM	○○○(○)MNE	C23	Insert (Turning)
CNMM	○○○(○)MSE	C23	Insert (Turning)
CNMM	○○○PX	B17	Insert (Turning)
CNM	○○○S○○○○○	C19	Insert (Turning)
CNM	○○○T○○○○○	B90	Insert (Turning)
CNMU	○○○○(○)E-GK	B49	Insert (Turning)
CP-2D		D14, D22, F84, P16	Spare Parts (Clamp)
CP-3D		D8, D10, D12, D22, F77, F80, F83, F84, F87, P16	Spare Parts (Clamp)
CP-5D		D18, P16	Spare Parts (Clamp)
CP-8TE		P16	Spare Parts (Clamp)
CP-8W		P16	Spare Parts (Clamp)
CPGB	○○○S○○○○○MES	C14	Insert (Turning)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru