для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
CPGB	○○○(○)(○) S○○○○○MET	C14	Insert (Turning)
CPGB	○○○(○)(○) S○○○○○SET	C14	Insert (Turning)
CPGB	○○○(○)(○)T○○○○○ME	C14	Insert (Turning)
CPGB	○○○(○)(○)(○) T○○○○○SE	C14	Insert (Turning)
CPGT	○○○○(○)	B57	Insert (Turning)
CPMB	○○○(○)(○)	B58	Insert (Turning)
CPMH	○○○(○)(○)(○)	B58, C25	Insert (Turning)
CPMH	○○○(○)(○)HQ	B58	Insert (Turning)
CPMH	○○○(○)(○)(○)NE	C25	Insert (Turning)
CPMH	○○○(○)(○)%-Y	B58	Insert (Turning)
CPMH	○○○(○)SE	C25	Insert (Turning)
CPMT	○○○(○)(○)GP	B58	Insert (Turning)
CPMT	○○○(○)(○)PP	B58	Insert (Turning)
CPMT	○○○(○)(○)XP	B58	Insert (Turning)
CPMT	○○○XQ	B58	Insert (Turning)
CP-RC%		D40, F72, P13	Spare Parts (Clamp Set)
CP8X15TL		P2	Spare Parts (Screw)
CP8X23TL		P2	Spare Parts (Screw)
CPS-1		F71, P14	Spare Parts (Clamp Set)
CPS-2		F70, F71, P14	Spare Parts (Clamp Set)
CPS-2P		E42, E43, P14	Spare Parts (Clamp Set)
CPS-2S		F71, P14	Spare Parts (Clamp Set)
CPS-2TR		P14	Spare Parts (Clamp Set)
CPS-3		E42, E43, F70, F71, P14	Spare Parts (Clamp Set)
CPS-4V		G61, N15, P14	Spare Parts (Clamp Set)
CPS-5E		P14	Spare Parts (Clamp Set)
CPS-5F		G61, P14	Spare Parts (Clamp Set)
CPS-5%		D19, P14	Spare Parts (Clamp Set)
CPS-5S		J20, J21, N9, P14	Spare Parts (Clamp Set)
CPS-5V		G61, G108, G109, G122, N15, P14	Spare Parts (Clamp Set)
CPS-6F		P14	Spare Parts (Clamp Set)
CPS-6M		P14	Spare Parts (Clamp Set)
CPS-6S		J20, J21, N9, P14	Spare Parts (Clamp Set)
CPS-6V		G61, G109, G113-G114, G122, P14	Spare Parts (Clamp Set)
CPS-8V		G109, G113-G114, G122, P14	Spare Parts (Clamp Set)
CRDCN	○○-○□	D29	Toolholder (Turning)
CRDNN	○○-○□	D29	Toolholder (Turning)
CRDNN	○○○○□-○○	D29	Toolholder (Turning)
CRDNN	○○○○□-○○A	D35	Toolholder (Turning)
CRSN%	○○○○□-○○	D29	Toolholder (Turning)
CRSN%	○○○○□-○○A	D35	Toolholder (Turning)
CS-2D		D14, D22, F84, P2	Spare Parts (Screw)
CS-3D		D8, D10, D12, D22, F77, F80, F83, F84, F87, P2	Spare Parts (Screw)
CS-5D		D18, P2	Spare Parts (Screw)
CSBPR	○○○○□-○○N	E42	Toolholder (Turning)
CSDNN	○○○○□-○○	D27	Toolholder (Turning)
CSDNN	○○○○□-○○A	D37	Toolholder (Turning)
CSDNN	○○○○□-○○GX	D32	Toolholder (Turning)
CSDPN	○○○○□-○○N	E42	Toolholder (Turning)
CSKN%	○○○○□-○○	D27, F89	Toolholder (Turning)
CSKNR	○○○○□-○○A	D36	Toolholder (Turning)
CSKN%	○○○○B-○○	F89	Boring Bar (Previous Description)
CSKN%	○○○○□-○○GX	D33	Toolholder (Turning)
CSKPR	○○○○B-○○	F70	Boring Bar (Previous Description)
CSKPR	○○○○□-○○N	E42	Toolholder (Turning)
CS-N%	○○○○□-○○	D27	Toolholder (Turning)
CS-N%	○○○○□-○○GX	D33	Toolholder (Turning)
CSRN%	○○-□	D27	Toolholder (Turning)
CSRN%	○○○○□-○○	D27	Toolholder (Turning)
CSRN%	○○○○□-○○A	D36	Toolholder (Turning)
CSRN%	○○○○□-○○GX	D32	Toolholder (Turning)
CSSN%	○○-○□	D27	Toolholder (Turning)
CSSN%	○○○○□-○○	D27	Toolholder (Turning)
CSSN%	○○○○□-○○A	D37	Toolholder (Turning)
CSSN%	○○○○□-○○GX	D32	Toolholder (Turning)
CSSP%	○○○○□-○○N	E42	Toolholder (Turning)
CSYN%	○○○○□-○○	D27	Toolholder (Turning)
CSYN%	○○○○□-○○A	D36	Toolholder (Turning)
CSYN%	○○○○□-○○GX	D33	Toolholder (Turning)
CTDPR	○○CA○○	N15	Toolholder (Cartridge)
CTEPR	○○CA○○	N15	Toolholder (Cartridge)
CTFP%	○○○○□-○○N	E43	Toolholder (Turning)
CTFPR	○○CA○○	N15	Toolholder (Cartridge)
CTGP%	○○○○□-○○N	E43	Toolholder (Turning)
CTJN%	○○-○□	D28	Toolholder (Turning)
CTJN%	○○○○□-○○	D28	Toolholder (Turning)
CTJN%	○○○○□-○○A	D38	Toolholder (Turning)
CTTP%	○○○○□-○○N	E43	Toolholder (Turning)
CTUN%	○○○○B-○○A	F91	Boring Bar (Previous Description)
CTUN%	○○○○□-○○	D28	Toolholder (Turning)
CTUN%	○○○○□-○○A	D38	Toolholder (Turning)
CTUP%	○○○○B-○○	F71	Boring Bar (Previous Description)
D			
DB	○○○R○○	G43	Insert (Grooving)
DB	○○○□(□□)T00420	G43	Insert (Grooving)
DC-42		F77, F80, F87, P8	Spare Parts (Shim)
DC-44		D8, P8	Spare Parts (Shim)
DCET	○○○○○F%-JSF	B64	Insert (Turning)
DCET	○○○○○(○)F%-USF	B63	Insert (Turning)
DCET	○○○○(○)(○)MF%-J	B64	Insert (Turning)
DCET	○○○○○MF%-JSF	B64	Insert (Turning)
DCET	○○○○(○)(○)MF%-U	B63	Insert (Turning)
DCET	○○○○○(○)MF%-USF	B63	Insert (Turning)
DCET	○○○○(○)(○)M%-F	B62	Insert (Turning)
DCET	○○○○(○)(○)M%-FSF	B62	Insert (Turning)
DCET	○○○○(○)%-FSF	B62	Insert (Turning)
DCGT	○○○○(○)	B61	Insert (Turning)
DCGT	○○○○AH	B65	Insert (Turning)
DCGT	○○○○○CF	B59	Insert (Turning)
DCGT	○○○○○CK	B59	Insert (Turning)
DCGT	○○○○(○)E%-J	B64	Insert (Turning)
DCGT	○○○○(○)E%-U	B64	Insert (Turning)
DCGT	○○○○(○)F%-J	B64	Insert (Turning)
DCGT	○○○○○F%-U	B63	Insert (Turning)
DCGT	○○○○(○)FN-Z	B61	Insert (Turning)
DCGT	○○○○(○)(○)M	B61	Insert (Turning)
DCGT	○○○○○M-CF	B59	Insert (Turning)
DCGT	○○○○○M-CK	B59	Insert (Turning)
DCGT	○○○○(○)(○)ME%-J	B64	Insert (Turning)
DCGT	○○○○(○)ME%-U	B64	Insert (Turning)
DCGT	○○○○(○)(○)MF	B61	Insert (Turning)
DCGT	○○○○(○)MF-GF	B59	Insert (Turning)
DCGT	○○○○(○)MF-GQ	B60	Insert (Turning)
DCGT	○○○○(○)MFP-GF	B59	Insert (Turning)
DCGT	○○○○(○)MFP-GQ	B60	Insert (Turning)
DCGT	○○○○(○)MFP-SK	B59	Insert (Turning)
DCGT	○○○○(○)(○)MF%-J	B64	Insert (Turning)
DCGT	○○○○(○)(○)MF%-U	B63	Insert (Turning)
DCGT	○○○○○MP-CF	B59	Insert (Turning)
DCGT	○○○○○MP-CK	B60	Insert (Turning)
DCGT	○○○○(○)(○)M%-F	B62	Insert (Turning)
DCGT	○○○○(○)%-A3	B65	Insert (Turning)
DCGT	○○○○(○)%-F	B62	Insert (Turning)
DCGT	○○○○(○)%-FS	B62	Insert (Turning)
DCGW	○○○○(○)	B65	Insert (Turning)
DCLN%	○○-○□	D8	Toolholder (Turning)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru