для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
DCLN%L ○○○○□-○○	D8	Toolholder (Turning)
DCMT ○○○○(○)	B61, C25	Insert (Turning)
DCMT ○○○○(○)GK	B60	Insert (Turning)
DCMT ○○○○(○)GP	B60	Insert (Turning)
DCMT ○○○○(○)HQ	B60	Insert (Turning)
DCMT ○○○○(○)MQ	B61	Insert (Turning)
DCMT ○○○○(○)NE	C25	Insert (Turning)
DCMT ○○○○(○)PP	B60	Insert (Turning)
DCMT ○○○○(○)%L-NE	C25	Insert (Turning)
DCMT ○○○○(○)SE	C25	Insert (Turning)
DCMT ○○○○(○)XP	B61	Insert (Turning)
DCMT ○○○○XQ	B61	Insert (Turning)
DCMW ○○○○MEF	C15	Insert (Turning)
DCMW ○○○○(○) S○○○○○MES	C15	Insert (Turning)
DCMW ○○○○(○) S○○○○○MET	C15	Insert (Turning)
DCMW ○○○○S○○○○○SET	C15	Insert (Turning)
DCMW ○○○○(○)T○○○○○ME	C15	Insert (Turning)
DCMW ○○○○(○)T○○○○○SE	C15	Insert (Turning)
DCMX ○○○○WP	B60	Insert (Turning)
DD-42	P8	Spare Parts (Shim)
DD-42-16	F80, P8	Spare Parts (Shim)
DD-43	D10, P8	Spare Parts (Shim)
DD-44	D10, P8	Spare Parts (Shim)
DDJN%L ○○-○□	D10	Toolholder (Turning)
DDJN%L ○○○○□-○○○○	D10	Toolholder (Turning)
DDHN%L ○○○○□-○○○○	D10	Toolholder (Turning)
DN10	F77, F80, F83, F84, F87, P19	Spare Parts (Nozzle)
DN20	F77, F80, F83, F84, F87, P19	Spare Parts (Nozzle)
DNGA ○○○MEF	C8	Insert (Turning)
DNGA ○○○S○○○○○	B91	Insert (Turning)
DNGA ○○○(○)S○○○○○ME	C8	Insert (Turning)
DNGA ○○○S○○○○○MEH	C8	Insert (Turning)
DNGA ○○○S○○○○○MEP	C8	Insert (Turning)
DNGA ○○○S○○○○○MET	C8	Insert (Turning)
DNGA ○○○(○)S○○○○○SE	C8	Insert (Turning)
DNGA ○○○S○○○○○SET	C9	Insert (Turning)
DNGA ○○○T○○○○○	B91	Insert (Turning)
DNGA ○○○T○○○○○AA	B91	Insert (Turning)
DNGA ○○○T○○○○○ME	C8	Insert (Turning)
DNGA ○○○T○○○○○SE	C8	Insert (Turning)
DNGG ○○○AH	B27	Insert (Turning)
DNGG ○○○FP-TK	B26	Insert (Turning)
DNGG ○○○(○)MFP-SK	B25	Insert (Turning)
DNGG ○○○%L	B27	Insert (Turning)
DNGG ○○○%L-A3	B27	Insert (Turning)
DNGG ○○○(○)%L-S	B27	Insert (Turning)
DNGG ○○○TK	B26	Insert (Turning)
DNGM ○○○S○○○○○BB○	C9	Insert (Turning)
DNG ○○○S○○○○○	B91	Insert (Turning)
DNG ○○○T○○○○○	B91	Insert (Turning)
DNG ○○○T○○○○○AA	B91	Insert (Turning)
DNGU ○○○○(○)ME%L-U	B50	Insert (Turning)
DNGU ○○○○(○)(○)MF%L-F	B50	Insert (Turning)
DNGU ○○○○(○)(○)MF%L-U	B50	Insert (Turning)
DNGU ○○○○(○)MF-SK	B50	Insert (Turning)
DNGU ○○○○(○)MFP-SK	B50	Insert (Turning)
DNGX ○○○T○○○○○	B91	Insert (Turning)
DNMA ○○○	B27	Insert (Turning)
DNMG ○○○	B24	Insert (Turning)
DNMG ○○○AH	B27	Insert (Turning)
DNMG ○○○C	B26	Insert (Turning)
DNMG ○○○CJ	B23	Insert (Turning)
DNMG ○○○CQ	B22	Insert (Turning)
DNMG ○○○GC	B27	Insert (Turning)

Part Number	Page	Description
DNMG ○○○(○)GP	B22	Insert (Turning)
DNMG ○○○GS	B23	Insert (Turning)
DNMG ○○○GT	B24	Insert (Turning)
DNMG ○○○GU	B25	Insert (Turning)
DNMG ○○○HK	B23	Insert (Turning)
DNMG ○○○(○)HQ	B22	Insert (Turning)
DNMG ○○○HS	B24	Insert (Turning)
DNMG ○○○MQ	B26	Insert (Turning)
DNMG ○○○MS	B26	Insert (Turning)
DNMG ○○○MU	B26	Insert (Turning)
DNMG ○○○PG	B23	Insert (Turning)
DNMG ○○○PH	B24	Insert (Turning)
DNMG ○○○(○)PP	B22	Insert (Turning)
DNMG ○○○PQ	B22	Insert (Turning)
DNMG ○○○PS	B24	Insert (Turning)
DNMG ○○○PT	B24	Insert (Turning)
DNMG ○○○TK	B26	Insert (Turning)
DNMG ○○○TN-V	B23	Insert (Turning)
DNMG ○○○XF	B25	Insert (Turning)
DNMG ○○○XP	B25	Insert (Turning)
DNMG ○○○XQ	B25	Insert (Turning)
DNMG ○○○XS	B25	Insert (Turning)
DNMG ○○○ZS	B27	Insert (Turning)
DNMM ○○○(○)M	C23	Insert (Turning)
DNMM ○○○(○)MNE	C23	Insert (Turning)
DNMM ○○○(○)MSE	C23	Insert (Turning)
DNMM ○○○PX	B25	Insert (Turning)
DNMP ○○○TK	B23	Insert (Turning)
DNMU ○○○○(○)E-GK	B50	Insert (Turning)
DPET ○○○○○(○)F%L-USF	B65	Insert (Turning)
DPET ○○○○○(○)MF%L-USF	B65	Insert (Turning)
DPET ○○○○(○)(○)M%L-FSF	B65	Insert (Turning)
DPET ○○○○%L-FSF	B65	Insert (Turning)
DS-42	P8	Spare Parts (Shim)
DS-44	D12, P8	Spare Parts (Shim)
DSBN%L ○○○○□-○○	D12	Toolholder (Turning)
DT-7	G55-G56, P17	Spare Parts (Torx Wrench / Screwdriver Type)
DT-8	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DT-10	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DT-15	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DT-20	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DT-25	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DT-32	D14, F84, P8	Spare Parts (Shim)
DT-42	F84, P8	Spare Parts (Shim)
DTGN%L ○○○○□-○○	D14	Toolholder (Turning)
DTM-6	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DTM-7	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DTM-8	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DTM-10	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DTM-15	P17	Spare Parts (Torx Wrench / Screwdriver Type)
DTP-9	P17	Spare Parts (Torx Plus Wrench / Screwdriver Type)
DTP-15	P17	Spare Parts (Torx Plus Wrench / Screwdriver Type)
DTP-20	P17	Spare Parts (Torx Plus Wrench / Screwdriver Type)
DTPM-8	P17	Spare Parts (Torx Plus Wrench / Screwdriver Type)
DTPM-10	P17	Spare Parts (Torx Plus Wrench / Screwdriver Type)
DTPM-15	P17	Spare Parts (Torx Plus Wrench / Screwdriver Type)
DV-33	D18, P8	Spare Parts (Shim)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru