для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
DVJN%L	○○-○□	D18	Toolholder (Turning)
DVLN%L	○○○○□-○○	D18	Toolholder (Turning)
DVPN%L	○○-○□	D18	Toolholder (Turning)
DVPN%L	○○○○□-○○	D18	Toolholder (Turning)
DW-32		D22	Spare Parts (Shim)
DW-42		F87, P8	Spare Parts (Shim)
DW-44		D22, P8	Spare Parts (Shim)
DWLN%L	○○-○□	D22	Toolholder (Turning)
DWLN%L	○○○○□-○○	D22	Toolholder (Turning)
DVVNN	○○-○□	D18	Toolholder (Turning)
DVVNN	○○○○□-○○	D18	Toolholder (Turning)
E			
E○○□-	SCLC%L○○-○○	F100	Boring Bars (Discontinued Description)
E○○□-	SCLC%L○A	F39	Boring Bars (Dynamic Bar)
E○○□-	SCLC%L○A-○/○	F39	Boring Bars (Dynamic Bar)
E○○□-	SCLC%L○○-○○A	F39	Boring Bars (Dynamic Bar)
E○○□-	SCLC%L○○-○○A-○/○	F39	Boring Bars (Dynamic Bar)
E○○□-	SCLP%L○○-○○	F100	Boring Bars (Discontinued Description)
E○○□-	SCLP%L○○-○○A	F41	Boring Bars (Dynamic Bar)
E○○□-	SCLP%L○○-○○A-○/○	F41	Boring Bars (Dynamic Bar)
E○○□-	SDQC%L○A	F46	Boring Bars (Dynamic Bar)
E○○□-	SDQC%L○A-○/○	F46	Boring Bars (Dynamic Bar)
E○○□-	SDQC%L○○-○○A	F46	Boring Bars (Dynamic Bar)
E○○□-	SDQC%L○○-○○A-○/○	F46	Boring Bars (Dynamic Bar)
E○○□-	SDUC%L○A	F45	Boring Bars (Dynamic Bar)
E○○□-	SDUC%L○A-○/○	F45	Boring Bars (Dynamic Bar)
E○○□-	SDUC%L○○-○○A	F45	Boring Bars (Dynamic Bar)
E○○□-	SDUC%L○○-○○A-○/○	F45	Boring Bars (Dynamic Bar)
E○○□-	SDZC%L○○-○○A	F47	Boring Bars (Dynamic Bar)
E○○□-	STLP%L○○-○○A	F53	Boring Bars (Dynamic Bar)
E○○□-	STLP%L○○-○○A-○/○	F53	Boring Bars (Dynamic Bar)
E○○□-	STUP%L○○-○○	F101	Boring Bars (Discontinued Description)
E○○□-	SVPB%L○○-○○A	F60	Boring Bars (Dynamic Bar)
E○○□-	SVPC%L○○-○○A	F60	Boring Bars (Dynamic Bar)
E○○□-	SVUB%L○○-○○A	F63	Boring Bars (Dynamic Bar)
E○○□-	SVUC%L○○-○○A	F63	Boring Bars (Dynamic Bar)
E○○□-	SWUB%L○○-○○A	F67	Boring Bars (Dynamic Bar)
E○○□-	SWUB%L○○-○○A-○/○	F67	Boring Bars (Dynamic Bar)
E○○□-	SWUP%L○○-○○A	F67	Boring Bars (Dynamic Bar)
E○○□-	SWUP%L○○-○○A-○/○	F67	Boring Bars (Dynamic Bar)
EGT	16-1	G42	Toolholder (External Grooving)
ENG	○○○S○○○○○	B91	Insert (Turning)
ENG	○○○(○)T○○○○○	B91	Insert (Turning)
ENG	○○○T○○○○○AA	B91	Insert (Turning)
EZBR	○○○○○○-○○○NB	C21, C33, F18	EZ Bars (Boring)
EZBR	○○○○○○HP-○○○F	F16	EZ Bars (Boring)
EZBR	○○○○○○HP-○○○H	F16	EZ Bars (Boring)
EZBR	○○○○○○ST-○○○F	F17	EZ Bars (Boring)
EZBR	○○○○○○ST-○○○H	F17	EZ Bars (Boring)
EZFGR	○○○○○○-○○○	G76	EZ Bars (Internal Face Grooving)
EZGR	○○○○○○-○○○	G48	EZ Bars (Internal Grooving)
EZGR	○○○○○○-○○○S	G48	EZ Bars (Internal Grooving)
EZTR	○○○○○○-○○-○○○	J28	EZ Bars (Internal Threading)
EZH	○○○○○(.○)CT-○○○	F22, F23, F92, J29	Sleeve
EZH	○○○○○(.○)HP-○○○	F24, F25, F92, J29	Sleeve
EZH	○○○○○(.○)ST-○○○	F26, F27, F92, J29	Sleeve
EZVBR	○○○○○○-○○○	F21	EZ Bars (Boring / Internal Facing / Copying)
F			
FGG%L	○○○○-○○	G33	Insert (Grooving)
FH-2		P17	Spare Parts (Hexagon Wrench / Flag Type)
FH-2.5		P17	Spare Parts (Hexagon Wrench / Flag Type)
FMM	○○-○○	G119	Insert (Grooving)
FMN	○	G119	Insert (Grooving)
FT-5		E34	Spare Parts (Torx Wrench / Flag Type)
FT-6		P17	Spare Parts (Torx Wrench / Flag Type)
FT-7		P17	Spare Parts (Torx Wrench / Flag Type)
FT-8		P17	Spare Parts (Torx Wrench / Flag Type)
FT-10		P17	Spare Parts (Torx Wrench / Flag Type)
FT-15		P17	Spare Parts (Torx Wrench / Flag Type)
FTK	○	G121	Insert (Face Grooving)
FTS-15		F75	Spare Parts (Torx Wrench / Flag Type)
G			
GA	○○	G41	Insert (Grooving)
GB	○○%L○○○	C30	Insert (Grooving)
GB	○○%L○○○R	G7	Insert (Grooving)
GBA	○○%L○○○	C20, C30, G8	Insert (Grooving / Previous Description)
GBA	○○%L○○○MY(N)	G7, G9	Insert (Grooving / Previous Description)
GBA	○○%L○○○N	G6	Insert (Grooving / Previous Description)
GBA	○○%L○○○R	G7, G10	Insert (Grooving / Previous Description)
GBA	○○%L○○○-(○○○)	C20, C30, G8, G10	Insert (Grooving)
GBA	○○%L○○○-○○○GM	G9	Insert (Grooving)
GBA	○○%L○○○-○○○MY	G9	Insert (Grooving)
GBA	○○%L○○○-○○○R	G10	Insert (Grooving)
GDFM	○○○○N-○○○DM	G83	Insert (Face)
GDFM	○○○○N-○○○GH	G83	Insert (Face Grooving)
GDFM	○○○○N-○○○GM	G83	Insert (Face Grooving)
GDFM	○○○○N-○○○R-CM	G83	Insert (Face Grooving)
GDFMS	○○○○N-○○○DM	G83	Insert (Face Grooving)
GDG	○○○○N-○○○GS	G17	Insert (Grooving)
GDG	○○○○N-○○○PG	H12	Insert (Cut-Off)
GDG	○○○○%L-○○○PG-○○D	H12	Insert (Cut-Off)
GDGS	○○○○N-○○○NB	C20, C31, G17	Insert (Grooving)
GDM	○○○○N-○○○GM	G17	Insert (Grooving)
GDM	○○○○N-○○○GMI	G65	Insert (Grooving)
GDM	○○○○N-○○○GL	G17	Insert (Grooving)
GDM	○○○○N-○○○PF	H12	Insert (Cut-Off)
GDM	○○○○N-○○○PH	G17, H13	Insert (Grooving / Cut-Off)
GDM	○○○○N-○○○PM	H13	Insert (Cut-Off)
GDM	○○○○N-○○○PQ	H12	Insert (Cut-Off)
GDM	○○○○N-○○○R-CM	G17, G65	Insert (Grooving)
GDM	○○○○%L-○○○PF-○○D	H13	Insert (Cut-Off)
GDM	○○○○%L-○○○PM-○D	H13	Insert (Cut-Off)
GDM	○○○○%L-○○○PQ-○○D	H13	Insert (Cut-Off)
GDMS	○○○○N-○○○GM	G17	Insert (Grooving)
GDMS	○○○○N-○○○PH	G17, H13	Insert (Grooving / Cut-Off)
GDMS	○○○○N-○○○PM	H13	Insert (Cut-Off)
GDMS	○○○○%L-○○○PM-○D	H13	Insert (Cut-Off)
GE%L	○○○-○○○□	G52, G54	Insert (Grooving)
GER	○○○-○○○□□	G52-G53, G54	Insert (Grooving)
GFV%L	○○○○□-○○○(○)□	G110	Toolholder (Face Grooving)
GFVS%L	○○-H□	G112	Toolholder (Face Grooving)
GFVS%L	○○○○□-H□	G114	Toolholder (Face Grooving)
GFVS%L	○○○○□-○○AA	G108	Toolholder (Face Grooving)
GFVS%L	○○-○○○(○)□	G112-G113	Toolholder (Face Grooving)
GFVS%L	○○○○□-○○○(○)□	G114	Toolholder (Face Grooving)
GFVT%L	○○-H□	G112	Toolholder (Face Grooving)
GFVT%L	○○○○□-H□	G114	Toolholder (Face Grooving)
GFVT%L	○○○○□-○○AA	G108	Toolholder (Face Grooving)
GFVT%L	○○-○○○(○)□	G112-G113	Toolholder (Face Grooving)
GFVT%L	○○○○□-○○○(○)□	G114	Toolholder (Face Grooving)
GG	○○○-○○T00320	G42	Insert (Grooving)
GH	○○○○(○)-○○	B99, G41, G67	Insert (Grooving)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru