для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
GHU ○○-○○	G41, G67	Insert (Grooving)
GIA ○○	G69	Insert (Grooving)
GIFV®L ○○○○B-○○○□	G122	Toolholder (Face Grooving)
GIV®L ○○○○-○□	G61	Toolholder (Grooving)
GIV®L ○○○○-○□(□)	G61	Toolholder (Grooving)
GIV®L ○○○○-○E	G61	Toolholder (Grooving)
GIV®L ○○○○-○W	G61	Toolholder (Grooving)
GMG ○○○○-○○	G32	Insert (Grooving / Previous Description)
GMG ○○○○-○○MG	G32, G68, G120	Insert (Grooving / Previous Description)
GMG ○○○○-○○R	G32	Insert (Grooving / Previous Description)
GMG ○○○○-○○RU	G32	Insert (Grooving / Previous Description)
GMG ○○○○-○○○MG	G32, G68, G120	Insert (Grooving)
GMG ○○○○-○○○MS	G32	Insert (Grooving)
GMG ○○○○-○○○R	G32	Insert (Grooving)
GMG ○○○○-○○○RU	G32	Insert (Grooving)
GMGA ○○○○-○○R	G33, G68, G120	Insert (Grooving / Previous Description)
GMGA ○○○○-○○○R	G33, G68, G120	Insert (Grooving)
GMM 3014-04	G33	Insert (Grooving)
GMM 3014-15R	G33	Insert (Grooving)
GMM 3014-15RU	G33	Insert (Grooving)
GMM ○○○○-MT	G34, H22	Insert (Grooving)
GMM ○○○○-NB	G34, H22	Insert (Grooving)
GMM ○○○○®L-MT-15D	G34, H22	Insert (Grooving)
GMM ○○○○®L-TK-8D	G34, H22	Insert (Grooving)
GMM ○○○○®L-TMR-6D	H22	Insert (Grooving)
GMM ○○○○-TK	G34, H22	Insert (Grooving)
GMM ○○○○-TMR	H22	Insert (Grooving)
GMM ○○○○-○○	G32, G68, G120	Insert (Grooving / Previous Description)
GMM ○○○○-○○MS	G32	Insert (Grooving / Previous Description)
GMM ○○○○-○○R	G32	Insert (Grooving / Previous Description)
GMM ○○○○-○○(○)V	G66	Insert (Grooving / Previous Description)
GMM ○○○○-○○(○)VR	G66	Insert (Grooving / Previous Description)
GMM ○○○○-○○○MS	G32	Insert (Grooving)
GMM ○○○○-○○○MW	G32, G68, G120	Insert (Grooving)
GMM ○○○○-○○○R	G32	Insert (Grooving)
GMM ○○○○-○○○V	G66	Insert (Grooving)
GMM ○○○○-○○○VR	G66	Insert (Grooving)
GMN ○(.○)	C20, C30, G34, G35, H22	Insert (Grooving)
GMN ○-TK	G34, H22	Insert (Grooving)
GM®L ○-TK-8D	G34, H22	Insert (Grooving)
GM®L ○(.○)-○(○)D	G34, H22	Insert (Grooving)
GMGW ○○○○-○○R	C31, G44	Insert (Grooving)
GMGW ○○○○-○○R-HR	C31, G44	Insert (Grooving)
GP-1	P19	Spare Parts (Plug)
GP-2	P19	Spare Parts (Plug)
GS-50	G14, G38, G63, G65-G66, P2	Spare Parts (Screw)
GS-50S	J18, J26, J27.P2	Spare Parts (Screw)
GS-4090T®L W	P2	Spare Parts (Screw)
GV®L ○○○□R	G59	Insert (Grooving / Previous Description)
GV®L ○○○□(□)	C30, G59	Insert (Grooving / Previous Description)
GV®L ○○○-○○○□(□)	G59	Insert (Grooving)
GV®L ○○○-○○○A/B/C	C30	Insert (Grooving)
GVF®L ○○○□	C30, G116	Insert (Grooving / Previous Description)
GVF®L ○○○AA	G109	Insert (Grooving / Previous Description)
GVF®L ○○○□R	G116	Insert (Grooving / Previous Description)
GVF®L ○○○-○○○AA	G109, G116	Insert (Grooving)
GVF®L ○○○-○○○□	C30, G116	Insert (Grooving)
GVF®L ○○○-○○○□R	G116	Insert (Grooving)

H

Part Number	Page	Description
HA○○ PCLN®L 12-○○	F73	Boring Bar (AD Bar Interchangeable Head)
HA○○ PDUN®L 15-○○	F74	Boring Bar (AD Bar Interchangeable Head)
HA○○ PTFN®L 16-○○	F74	Boring Bar (AD Bar Interchangeable Head)
HA○○ SCLC®L 09-○○	F75	Boring Bar (AD Bar Interchangeable Head)
HA○○ SDUC®L 11-○○	F75	Boring Bar (AD Bar Interchangeable Head)
HCB300	D27	Spare Parts (Chipbreaker)
HCB314	D25	Spare Parts (Chipbreaker)
HCB315	D25	Spare Parts (Chipbreaker)
HCB318	D24	Spare Parts (Chipbreaker)
HCL-000	D27	Spare Parts (Clamp Set)
HCL-001	D27, D29	Spare Parts (Clamp Set)
HCL-002	D27	Spare Parts (Clamp Set)
HCL-007	D29	Spare Parts (Clamp Set)
HCL-008	D24, D25	Spare Parts (Clamp Set)
HCL-009	G42-G43	Spare Parts (Clamp Set)
HCL-011	G42-G43	Spare Parts (Clamp Set)
HCL-013	D29	Spare Parts (Clamp Set)
HCL-016	D29	Spare Parts (Clamp Set)
HCL-017C	D29	Spare Parts (Clamp Set)
HCLN®L ○○-○□	D24	Toolholder (Turning)
HF20X53H	P2	Spare Parts (Screw)
HF24X60H	P2	Spare Parts (Screw)
HH3X6	F95, P2	Spare Parts (Screw)
HH3X12	D34-D38, F95, P2	Spare Parts (Screw)
HH4X12	G113-G114, P3	Spare Parts (Screw)
HH4X16	P2	Spare Parts (Screw)
HH5X15	D25, G69, P2	Spare Parts (Screw)
HH5X16	G20-G21, G36-G39, G94, H16, H17, H24, H25, P2	Spare Parts (Screw)
HH5X20	F76, G118-G119, P2	Spare Parts (Screw)
HH5X25	G20-G21, G36-G39, G118-G119, H16, H17, H24, H25, H27, H29, P2	Spare Parts (Screw)
HH5X30	F76.P2	Spare Parts (Screw)
HH6X12	P2	Spare Parts (Screw)
HH6X16	N14-N16, P2	Spare Parts (Screw)
HH6X16AA	P2	Spare Parts (Screw)
HH6X18XX	P2	Spare Parts (Screw)
HH6X20	F76, G41, G68, N15-N16, P2	Spare Parts (Screw)
HH6X25	G20-G21, G36, G40, G44, G67, G120, H16, H24, P2	Spare Parts (Screw)
HH6X30	F76, H29, P2	Spare Parts (Screw)
HH8X25	N14, P3	Spare Parts (Screw)
HH8X25H	P3	Spare Parts (Screw)
HH8X30	N14	Spare Parts (Screw)
HH8X35	P3	Spare Parts (Screw)
HH8X40	P3	Spare Parts (Screw)
HH8X50	P3	Spare Parts (Screw)
HH8X55	P3	Spare Parts (Screw)
HH8X65	P3	Spare Parts (Screw)
HH8X70	P3	Spare Parts (Screw)
HH8X80	P3	Spare Parts (Screw)
HH8X85	P3	Spare Parts (Screw)
HH8X100	P3	Spare Parts (Screw)
HH8X110	P3	Spare Parts (Screw)
HH10X25	P3	Spare Parts (Screw)
HH10X30	P3	Spare Parts (Screw)
HH10X30H	P3	Spare Parts (Screw)
HH10X30M	P3	Spare Parts (Screw)
HH10X30S	P3	Spare Parts (Screw)
HH10X35	P3	Spare Parts (Screw)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru