для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
LL-03	P7	Spare Parts (Lock Pin)
LL-03N	D15, F85, N14, P7	Spare Parts (Lock Pin)
LL-03S	P7	Spare Parts (Lock Pin)
LL-03SN	F78, F85, F86, P7	Spare Parts (Lock Pin)
LL-03T	P7	Spare Parts (Lock Pin)
LL-03TN	D15, F85, P7	Spare Parts (Lock Pin)
LL-05C	D21, P7	Spare Parts (Lock Pin)
LL-1	P7	Spare Parts (Lock Pin)
LL-1C	P7	Spare Parts (Lock Pin)
LL-1CN	D21, D39, P7	Spare Parts (Lock Pin)
LL-1D	F79.P7	Spare Parts (Lock Pin)
LL-1DN	D11, F79, P7	Spare Parts (Lock Pin)
LL-1K	F74, P7	Spare Parts (Lock Pin)
LL-1N	D9, D11, D13, D15, D21, D23, E41, F78, F85, F86, N6, N14, P7	Spare Parts (Lock Pin)
LL-2	P7	Spare Parts (Lock Pin)
LL-2C	D39, P7	Spare Parts (Lock Pin)
LL-2K	F73, P7	Spare Parts (Lock Pin)
LL-2N	D9, D13, D15, D21, D23, E40, F78, F88, N5, N7, N14, P7	Spare Parts (Lock Pin)
LL-3	P7	Spare Parts (Lock Pin)
LL-3K	F74, P7	Spare Parts (Lock Pin)
LL-3N	D11, F82, N5-N6, P7	Spare Parts (Lock Pin)
LL-4	D11, P7	Spare Parts (Lock Pin)
LL-5	P7	Spare Parts (Lock Pin)
LL-5N	D9, P7	Spare Parts (Lock Pin)
LNU ○○○○T○○○○○/○○○A(A)	B98	Insert (Turning)
LP-2S	D20, P7	Spare Parts (Lock Pin)
LP-6S	D20, P7	Spare Parts (Lock Pin)
LPA-11	E17-E19, P7	Spare Parts (Anchor Pin)
LPA-13	E17-E19, P7	Spare Parts (Anchor Pin)
LPA-17	E17-E19, P7	Spare Parts (Anchor Pin)
LPF-11	E22, E24, E30, P7	Spare Parts (Anchor Pin)
LPF-13	E22, E24, P7	Spare Parts (Anchor Pin)
LPF-17	E22, E24, P7	Spare Parts (Anchor Pin)
LPF-1113	E30, P7	Spare Parts (Anchor Pin)
LPF-1117	E30, P7	Spare Parts (Anchor Pin)
LR-10C	D21, P9	Spare Parts (Shim)
LR-12C	D21, D39, P9	Spare Parts (Shim)
LR-16C	D39, P9	Spare Parts (Shim)
LR-80	D21, P9	Spare Parts (Shim)
LR-81	D21, P9	Spare Parts (Shim)
LS-03	P4	Spare Parts (Lock Screw)
LS-03S	P4	Spare Parts (Lock Screw)
LS-03N	D15, N14, P4	Spare Parts (Lock Screw)
LS-03SN	D15, F78, F85, F86, P4	Spare Parts (Lock Screw)
LS-05	D21, P4	Spare Parts (Lock Screw)
LS-1	P4	Spare Parts (Lock Screw)
LS-1N	D9, D11, D13, D15, D21, D23, D39, E41, F85, N6, N14, P4	Spare Parts (Lock Screw)
LS-1P	F74, P4	Spare Parts (Lock Screw)
LS-1S	F79, P4	Spare Parts (Lock Screw)
LS-1SN	F78, F79, F86, P4	Spare Parts (Lock Screw)
LS-1T	D39, P4	Spare Parts (Lock Screw)
LS-2	P4	Spare Parts (Lock Screw)
LS-2N	D9, D11, D13, D15, D21, D23, E40, F78, F82, F88, N5-N7, N14, P4	Spare Parts (Lock Screw)
LS-2P	F73, P4	Spare Parts (Lock Screw)
LS-3	D11, P4	Spare Parts (Lock Screw)
LS-3P	F74, P4	Spare Parts (Lock Screw)
LS-4	P4	Spare Parts (Lock Screw)
LS-4N	D9, P4	Spare Parts (Lock Screw)
LS-11	D20, P4	Spare Parts (Lock Screw)
LS-15	D20, P4	Spare Parts (Lock Screw)

Part Number	Page	Description
LS-32	D13, P9	Spare Parts (Shim)
LS-42	D13, N14, P9	Spare Parts (Shim)
LSD-445R	P12	Spare Parts (Cartridge)
LSE-445R	P12	Spare Parts (Cartridge)
LSO-445R	P12	Spare Parts (Cartridge)
LSP-1	D9, D11, D13, D15, D21, D23, D39, E41, F78, F79, F85, F86, P7	Spare Parts (Shim Pin)
LSP-2	D9, D11, D13, D15, D21, D23, D39, E40, F78, F82, F88, N5-N7, N14, P7	Spare Parts (Shim Pin)
LSP-2K	F74, P7	Spare Parts (Shim Pin)
LSP-3	D9, P7	Spare Parts (Shim Pin)
LSP-3K	F73, F74, P7	Spare Parts (Shim Pin)
LSP-415R	P12	Spare Parts (Cartridge)
LT-3K	F74, P9	Spare Parts (Shim)
LT-32	P9	Spare Parts (Shim)
LT-32N	D15, E41, F85, N14, P9	Spare Parts (Shim)
LT-32N-20	D15, E41, F85, P9	Spare Parts (Shim)
LT-42	P9	Spare Parts (Shim)
LT-42N	D15, N14, P9	Spare Parts (Shim)
LT-42N-20	D15, P9	Spare Parts (Shim)
-490R	P12	Spare Parts (Cartridge)
LTK-5	G121, H30, H31, H33, P18	Spare Parts (Wrench)
LTP-10	F74, P17	Spare Parts (Torx Plus Wrench / L-shaped Type)
LTP-15	F73, F74, P17	Spare Parts (Torx Plus Wrench / L-shaped Type)
LTW-8SS	E39, P17	Spare Parts (Torx Wrench / L-shaped Type)
LTW-10S	E12, E51, F30, F33-F35, G80-G81, H8, H10, H33, J22, P17	Spare Parts (Torx Wrench / L-shaped Type)
LTW-10SS	E38, P17	Spare Parts (Torx Wrench / L-shaped Type)
LTW-15S	G19, G36, G132, H14, H15, H24, H33, J20, P17	Spare Parts (Torx Wrench / L-shaped Type)
LTW-20	E23, F72, G19, G36-G38, G63, G66, G132, H14, H24, H25, H33, P17	Spare Parts (Torx Wrench / L-shaped Type)
LTW-25	G23-G25, G84, G92-G93, H18, H19, P17	Spare Parts (Torx Wrench / L-shaped Type)
LW0	D14	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-094	D8, D10, D12, D14, D22, D24, D25, D27, D29	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-1.5	F22, F24, F27, F30-F32, F94, P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-2	D29, F22, F24, F27, F88, F94, F95, N14-N16, P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-2.5	D14, D15, D22, E42, E43, F71, F84, F95, N14-N16, P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-3	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-4	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-4.5	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-5	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-6	N3-N4, N10, N14, P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-8	N10, P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-10	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-14	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-17	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-19	P17	Spare Parts (Hexagon Wrench / L-shaped Type)
LW-32	P9	Spare Parts (Shim)
LW-32N	F86, P9	Spare Parts (Shim)
LW-42	P9	Spare Parts (Shim)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru