для заказа - kyocera@kyocera-tools.ru





## Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

| Part Number | Page | Description |
|---|---|---|
| LW-42N | **N7, P9** | Spare Parts (Shim) |
| LW-42N℠ | **P9** | Spare Parts (Shim) |
| LW-42N℠ | **F88, P9** | Spare Parts (Shim) |
| LW-125 | **D8, D10** | Spare Parts (Hexagon Wrench / L-shaped Type) |
| LW-156 | **D8, D12, D14, D19, D22, G31, G42-G43, G71, G117, J16, J17** | Spare Parts (Hexagon Wrench / L-shaped Type) |
| LX-156 | **D19** | Spare Parts (Hexagon Wrench / L-shaped Type) |
| **M** | | |
| M3X8 | **D24, D25, D27-D33, D35-D37, F89, F90, P4** | Spare Parts (Screw) |
| M3X12 | **D24, D27-D29, D35-D37, F89, P4** | Spare Parts (Screw) |
| M4X10 | **D24, D27, D29, D32, D33, P4** | Spare Parts (Screw) |
| MAP-2506 | **P12** | Spare Parts (Cartridge) |
| MCLN℠ ○○-○□ | **D8** | Toolholder (Turning) |
| MDJN℠ ○○-○□ | **D10** | Toolholder (Turning) |
| MSD-42 | **P9** | Spare Parts (Shim) |
| MSE-4245S | **P9** | Spare Parts (Shim) |
| MSE-4215 | **P9** | Spare Parts (Shim) |
| MSE-4245 | **P9** | Spare Parts (Shim) |
| MSO-4T245 | **P10** | Spare Parts (Shim) |
| MSO-5200 | **P10** | Spare Parts (Shim) |
| MSP-42 | **P10** | Spare Parts (Shim) |
| MSSN℠ ○○-○□ | **D12** | Toolholder (Turning) |
| MTE-42 | **P10** | Spare Parts (Shim) |
| MTGN℠ ○○-○□ | **D14** | Toolholder (Turning) |
| MVJN℠ ○○-○□ | **D19** | Toolholder (Turning) |
| MVLN℠ ○○○○□-○○ | **D19** | Toolholder (Turning) |
| MVN-32 | **D19, P10** | Spare Parts (Shim) |
| MVVNN ○○-○□ | **D19** | Toolholder (Turning) |
| MVVNN ○○○○□-○○ | **D19** | Toolholder (Turning) |
| MWLN℠ ○○-○□ | **D22** | Toolholder (Turning) |
| **N** | | |
| NL34L | **D14, D19** | Spare Parts (Lock Pin) |
| NL46 | **D8, D10, D12, D14, D22** | Spare Parts (Lock Pin) |
| NL46L | **D24, D25, D27, D29** | Spare Parts (Lock Pin) |
| NL58 | **D8** | Spare Parts (Lock Pin) |
| NL68 | **D8** | Spare Parts (Lock Pin) |
| **P** | | |
| P-03 | **D15, N14, P7** | Spare Parts (Shim Pin) |
| P-03S | **D15, F78, F85, F86, P7** | Spare Parts (Shim Pin) |
| PC-1 | **D9, D11, D13, D15, D21, D23, D39, E41, F78, F79, F85, F86, N6, N14, P19** | Spare Parts (Punch) |
| PC-2 | **D9, D11, D13, D15, D21, D23, D39, E40, F78, F82, F88, N5-N7, N14, P19** | Spare Parts (Punch) |
| PC-2K | **F73, F74** | Spare Parts (Punch) |
| PCLN℠ ○○○○B-○○ | **F78** | Boring Bar (Previous Description) |
| PCLN℠ ○○○○B-○○H | **F78** | Boring Bar (Previous Description) |
| PCLN℠ ○○-○□ | **D9** | Toolholder (Turning) |
| PCLN℠ ○○○○□-○○ | **D9** | Toolholder (Turning) |
| PCLNR ○○○○□□-○○FF | **E40** | Toolholder (Double Sided Tooling) |
| PD-42 | **F82, P10** | Spare Parts (Shim) |
| PDHN℠ ○○○○□-○○ | **D11** | Toolholder (Turning) |
| PDJN℠ ○○-○□ | **D11** | Toolholder (Turning) |
| PDJN℠ ○○○○□-○○ | **D11** | Toolholder (Turning) |
| PDJN℠ ○○○○-○○U | **D11** | Toolholder (Turning) |
| PDUN℠ ○○○○B-○○ | **F79** | Boring Bar (Previous Description) |
| PDUN℠ ○○○○B-○○H | **F79** | Boring Bar (Previous Description) |
| PH- ○○○○ | **F94** | Sleeve (for Micro-Bars / Previous Description) |
| PH ○○-○□□ | **F94** | Sleeve (for Micro-Bars) |
| PH ○○○○-○○ | **F94** | Sleeve (for Micro-Bars) |
| PP-4 | **F82, P7** | Spare Parts (Lock Pin) |
| PRGC℠ ○○-○○□□ | **D21** | Toolholder (Turning) |
| PRGC℠ ○○○○□-○○ | **D21** | Toolholder (Turning) |
| PRGC℠ ○○○○□-○○BE | **D39** | Toolholder (Turning) |
| PRGC℠ ○○○○□-○○BF | **D39** | Toolholder (Turning) |
| PRGN℠ ○○○○□-○○ | **D21** | Toolholder (Turning) |
| PRXC℠ ○○-○○□□ | **D21** | Toolholder (Turning) |
| PRXC℠ ○○○○□-○○ | **D21** | Toolholder (Turning) |
| PSB℠ ○○○○-○○NBS | **C21, C34, F37** | Tip-Bars (Boring) |
| PSB℠ ○○○○-○○S | **F37** | Tip-Bars (Boring) |
| PSBN℠ ○○○○□-○○ | **D13** | Toolholder (Turning) |
| PSBT℠ ○○○○-○○S | **F37** | Tip-Bars (Boring) |
| PSDNN ○○○○□-○○ | **D13** | Toolholder (Turning) |
| PSFG℠ ○○○○-○○S | **G79** | Tip-Bars (Face Grooving) |
| PSG℠ ○○○○-○○S | **G51** | Tip-Bars (Grooving) |
| PSKNR ○○CA○○ | **N14** | Toolholder (Cartridge) |
| PSKN℠ ○○○○□-○○ | **D13** | Toolholder (Turning) |
| PSSNR ○○CA○○ | **N14** | Toolholder (Cartridge) |
| PSSN℠ ○○○○□-○○ | **D13** | Toolholder (Turning) |
| PSTR ○○○○-○○S | **J34** | Tip-Bars (Threading) |
| PSYNR ○○CA○○ | **N14** | Toolholder (Cartridge) |
| PTFNR ○○CA○○ | **N14** | Toolholder (Cartridge) |
| PTFN℠ ○○-○□ | **D15** | Toolholder (Turning) |
| PTFN℠ ○○○○□-○○ | **D15** | Toolholder (Turning) |
| PTGNR ○○CA○○ | **N14** | Toolholder (Cartridge) |
| PTGN℠ ○○-○□ | **D15** | Toolholder (Turning) |
| PTGN℠ ○○○○□-○○ | **D15** | Toolholder (Turning) |
| PTLNR ○○○○□□-○○FF | **E41** | Toolholder (Double ded Tooling) |
| PTTNR ○○CA○○ | **N14** | Toolholder (Cartridge) |
| PTUN℠ ○○○○B-○○ | **F85** | Boring Bar (Previous Description) |
| PTUN℠ ○○○○B-○○H | **F85** | Boring Bar (Previous Description) |
| PVLN℠ ○○○○□-○○Q | **D20** | Toolholder (Turning) |
| PVPN℠ ○○○○□-○○Q | **D20** | Toolholder (Turning) |
| PVVNN ○○○○□-○○Q | **D20** | Toolholder (Turning) |
| PWLN℠ ○○○○B-○○ | **F86** | Boring Bar (Previous Description) |
| PWLN℠ ○○○○B-○○H | **F86** | Boring Bar (Previous Description) |
| PWLN℠ ○○-○□ | **D23** | Toolholder (Turning) |
| PWLN℠ ○○○○□-○○ | **D23** | Toolholder (Turning) |
| **R** | | |
| RBG ○○K○○○○ | **B98** | Insert (Turning) |
| RBG ○○W | **B98** | Insert (Turning / Previous Description) |
| RCGX ○○○○M0-AQ | **B66** | Insert (Turning) |
| RCGX ○○E○○○ | **B98** | Insert (Turning) |
| RCGX ○○○H○○○T○○○○○ | **B98** | Insert (Turning) |
| RCGX ○○(○)S○○○○○ | **B98** | Insert (Turning) |
| RCGX ○○(○)T○○○○○ | **B98** | Insert (Turning) |
| RCGX ○○○T○○○○○/ ○○○AA | **B98** | Insert (Turning) |
| RCMA ○○(○)T○○○○○/ ○○○AA | **B98** | Insert (Turning) |
| RCMT ○○○○M0-BB | **B87** | Insert (Turning) |
| RCMX ○○○○M0 | **B66** | Insert (Turning) |
| RNG ○○E○○○ | **B92** | Insert (Turning) |
| RNG ○○K○○○○○ | **B92** | Insert (Turning) |
| RNG ○○S○○○○○ | **B92** | Insert (Turning) |
| RNG ○○T○○○○○ | **B92** | Insert (Turning) |
| RNG ○○T○○○○○AA | **B92** | Insert (Turning) |
| RNMG ○○ | **B28** | Insert (Turning) |
| RNM ○○S○○○○ | **C19** | Insert (Turning) |
| RPG ○○E○○○ | **B97** | Insert (Turning) |
| RPG ○○T○○○○○ | **B97** | Insert (Turning) |
| RPGX ○○E○○○ | **B98** | Insert (Turning) |
| RPGX ○○T○○○○○ | **B98** | Insert (Turning) |
| RPMT ○○○○M0-BB | **B87** | Insert (Turning) |

kyocera@kyocera-tools.ru
www.kyocera-tools.ru