для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
S			
S○○□-	CCLN%○	F91	Boring Bars
S○○□-	CCLN%○○-○○A	F91	Boring Bars
S○○□-	CCLN%○○-○○GX	F90	Boring Bars
S○○□-	CDUN%○○-○○GX	F90	Boring Bars
S○○□-	CELNR○○-○○	F89	Boring Bars
S○○□-	CSKN%○	F89	Boring Bars
S○○□-	CSKN%○○-○○	F89	Boring Bars
S○○□-	CSKN%○○-○○A	P24	Boring Bars (Discontinued Description)
S○○□-	CSKN%○○-○○GX	F90	Boring Bars
S○○□-	CSKPR○○-○○	F70	Boring Bars
S○○□-	CTUC%○○-○○	P24	Boring Bars (Discontinued Description)
S○○□-	CTUN%○	F91	Boring Bars
S○○□-	CTUN%○○-○○A	F91	Boring Bars
S○○□-	CTUP%○	F71	Boring Bars
S○○□-	CTUP%○○-○○	F71	Boring Bars
S○○(.○)□-	KTGFL16	G13	Sleeve Holder (Grooving)
S○○(.○)□-	KTTXL16	J24	Sleeve Holder (Threading)
S○○□-	PCLN%○	F78	Boring Bars
S○○□-	PCLN%○○-○○	F78	Boring Bars
S○○□-	PDQN%○○-○○	F81	Boring Bars
S○○□-	PDUN%○○-○○	F79, F81	Boring Bars
S○○□-	PDZN%○○-○○	F81	Boring Bars
S○○□-	PTUN%○○-○○	F85	Boring Bars
S○○□-	PWLN%○○-○○	F86, F88	Boring Bars
S○○(.○)□-	SCLCL○○	E34	Sleeve Holder (Turning)
S○○□-	SCLC%○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	SCLC%○○-○○A	F39	Boring Bars (Dynamic Bar)
S○○□-	SCLC%○	F43	Boring Bars (General Purpose)
S○○□-	SCLC%○(.○)E	F43	Boring Bars (General Purpose)
S○○□-	SCLC%○○-○○E	F98	Boring Bars (Discontinued Description)
S○○□-	SCLC%○○-○○AE	F39	Boring Bars (Dynamic Bar)
S○○○□-	SCLCR○○-○○○EZ	F20	Boring Bars (EZ Bar PLUS)
S○○□-	SCLP%○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	SCLP%○(.○)	F39	Boring Bars (General Purpose)
S○○□-	SCLP%○○-○○A	F41	Boring Bars (Dynamic Bar)
S○○□-	SCLP%○○-○○E	F98	Boring Bars (Discontinued Description)
S○○(.○)□-	SDLCL○○	E35	Sleeve Holder (Turning)
S○○□-	SDQC%○○-○○A	F46	Boring Bars (Dynamic Bar)
S○○(.○)□-	SDUCL○○	E35	Sleeve Holder (Turning)
S○○□-	SDUC%○	F48	Boring Bars (General Purpose)
S○○□-	SDUC%○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	SDUC%○○-○○A	F45	Boring Bars (Dynamic Bar)
S○○□-	SDUC%○○-○○E	F98	Boring Bars (Discontinued Description)
S○○□-	SDZC%○	F49	Boring Bars (General Purpose)
S○○□-	SDZC%○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	SDZC%○○-○○A	F47	Boring Bars (Dynamic Bar)
S○○□-	SDZC%○○-○○E	F98	Boring Bars (Discontinued Description)
S○○□-	SINR-○	J21	Toolholder (Threading)
S○○□-	SSKPR○○-○○	F70	Boring Bars
S○○□-	STLB%○.○AE	F53	Boring Bars (Dynamic Bar)
S○○□-	STLB%○○-○○A	F53	Boring Bars (Dynamic Bar)
S○○□-	STLB%○○-○○AE	F53	Boring Bars (Dynamic Bar)
S○○□-	STLC%○○-○○A	F51	Boring Bars (Dynamic Bar)
S○○□-	STLP%○○-○○A	F53	Boring Bars (Dynamic Bar)
S○○□-	STUB%○.○	F55	Boring Bars (General Purpose)
S○○□-	STUB%○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	STUB%○○-○○E	F98	Boring Bars (Discontinued Description)
S○○□-	STUP%○.(○)	F55	Boring Bars (General Purpose)
S○○□-	STUP%○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	STUP%○○-○○E	F98	Boring Bars (Discontinued Description)
S○○(.○)□-	STWL15	G80	Toolholder (for Twin Bars)
S○○□-	STWP%○	F56, J35	Toolholder (Boring / Threading)
S○○□-	STWP%○○-○○	F56, J35	Toolholder (Boring / Threading)
S○○□-	STWP%○○-○○E	F56, J35	Toolholder (Boring / Threading)
S○○(.○)□-	STWR15	F34	Toolholder (for Twin Bars)
S○○□-	SVJB%○	F64	Boring Bars (General Purpose)
S○○□-	SVJB%○E	F64	Boring Bars (General Purpose)
S○○□-	SVJB%○○-○○A	F58	Boring Bars (Dynamic Bar)
S○○□-	SVJB%○○-○○E	F97, F98	Boring Bars (Discontinued Description)
S○○□-	SVJB%○○-○○EN	F98	Boring Bars (Discontinued Description)
S○○□-	SVJC%○○-○○A	F58	Boring Bars (Dynamic Bar)
S○○□-	SVJC%○○-○○E	F99	Boring Bars (Discontinued Description)
S○○□-	SVJP%○○-○○A	F58	Boring Bars (Dynamic Bar)
S○○□-	SVJP%○○-○○E	F99	Boring Bars (Discontinued Description)
S○○□-	SVNR12	F31	Toolholder (for System Tip-Bars / Discontinued Description)
S○○□-	SVNR12N	F31	Toolholder (for System Tip-Bars)
S○○(.○)□-	SVNR12S	P22	Toolholder (for System Tip-Bars / Discontinued Description)
S○○(.○)□-	SVNR12SN	F31	Toolholder (for System Tip-Bars)
S○○(.○)□-	SVNR12SXN	F33	Toolholder (for System Tip-Bars)
S○○□-	SVNR12XN	F33	Toolholder (for System Tip-Bars)
S○○□-	SVPB%○○-○○A	F60	Boring Bars (Dynamic Bar)
S○○□-	SVPB%○E	F64	Boring Bars (General Purpose)
S○○□-	SVPB%○○-○○E	F97, F99	Boring Bars (Discontinued Description)
S○○□-	SVPB%○○-○○EN	F99	Boring Bars (Discontinued Description)
S○○□-	SVPC%○.○E	F64	Boring Bars (General Purpose)
S○○□-	SVPC%○○-○○A	F60	Boring Bars (Dynamic Bar)
S○○□-	SVPC%○○-○○E	F99	Boring Bars (Discontinued Description)
S○○(.○)□-	SVUBL○○	E36	Sleeve Holder (Turning)
S○○□-	SVUCL○○	E36	Sleeve Holder (Turning)
S○○□-	SVUB%○○-○○A	F63	Boring Bars (Dynamic Bar)
S○○□-	SVUB%○E	F65	Boring Bars (General Purpose)
S○○□-	SVUB%○○-○○E	F97, F99	Boring Bars (Discontinued Description)
S○○□-	SVUB%○○-○○EN	F99	Boring Bars (Discontinued Description)
S○○□-	SVUC%○.○E	F65	Boring Bars (General Purpose)
S○○□-	SVUC%○○-○○A	F63	Boring Bars (Dynamic Bar)
S○○□-	SVUC%○○-○○E	F99	Boring Bars (Discontinued Description)
S○○□-	SVZB%○E	F65	Boring Bars (General Purpose)
S○○□-	SVZB%○○-○○A	F63	Boring Bars (Dynamic Bar)
S○○□-	SVZB%○○-○○E	F97, F99	Boring Bars (Discontinued Description)
S○○□-	SVZB%○○-○○EN	F99	Boring Bars (Discontinued Description)
S○○□-	SVZC%○.○E	F65	Boring Bars (General Purpose)
S○○□-	SVZC%○○-○○A	F63	Boring Bars (Dynamic Bar)
S○○□-	SVZC%○○-○○E	F99	Boring Bars (Discontinued Description)
S○○□-	SWUB%○.○	F68	Boring Bars (General Purpose)
S○○□-	SWUB%○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	SWUB%○.○AE	F67	Boring Bars (Dynamic Bar)
S○○□-	SWUB%○○-○○A	F67	Boring Bars (Dynamic Bar)
S○○□-	SWUB%○○-○○AE	F67	Boring Bars (Dynamic Bar)
S○○□-	SWUB%○○-○○E	F99	Boring Bars (Discontinued Description)
S○○□-	SWUB%○○-○○-○○	F99	Boring Bars (Discontinued Description)
S○○□-	SWUP%○○-○○A	F67	Boring Bars (Dynamic Bar)
S○○□-	SWUP%○○-○○E	F99	Boring Bars (Discontinued Description)
S○○□-	SYXP%○○-○○E	P24	Boring Bars (Discontinued Description)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru