для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
S○○□- WWLN※○○-○○	F88	Boring Bars
S○○□- WWLN※○○-○○E	F88	Boring Bars
S-34	D14, D19	Spare Parts (Shim Screw)
S-46	D8, D10, D12, D14, D22, D24, D25, D27, D29	Spare Parts (Shim Screw)
S-58	D8	Spare Parts (Shim Screw)
S-68	D8	Spare Parts (Shim Screw)
SABSR ○(○)-○○□□F	E17, E49	Toolholder (Turning)
SABSR ○○○○□(□)-○○F	E17, E49	Toolholder (Turning)
SABWR ○○○○□(□)-○○F	E18, E19, E49	Toolholder (Turning)
SB-1STR	F55, F57, P5	Spare Parts (Screw)
SB-1TR	F53, F55, F57, P5	Spare Parts (Screw)
SB-2TR	F55, F57, J21, P5	Spare Parts (Screw)
SB-3STR	F43, F56, P5	Spare Parts (Screw)
SB-3TR	F46, F55, F56, N16, P5	Spare Parts (Screw)
SB-3.5TR	J20, J21, P5	Spare Parts (Screw)
SB-4TR	F43, F56, F70, F72, G14, G63, J18, J26, J27, N16, P5	Spare Parts (Screw)
SB-5TR	G36-G38, G65-G66, H24, H25, P5	Spare Parts (Screw)
SB-1635TR	F20, F39, F43, F50, P5	Spare Parts (Screw)
SB-2035TR	F20, F39, F53, F67, P5	Spare Parts (Screw)
SB-2035TRG	P5	Spare Parts (Screw)
SB-2040TR	F68, F69, J21, P5	Spare Parts (Screw)
SB-2040TRG	P5	Spare Parts (Screw)
SB-2042TRG	P5	Spare Parts (Screw)
SB-2045TR	P5	Spare Parts (Screw)
SB-2045TRN	G55-G56, P5	Spare Parts (Screw)
SB-2050TR	E29, E32, E33, E36, E51, F58, F60, F63-F65, F67-F69, F82, F97, J21, P5	Spare Parts (Screw)
SB-2060TR	P5	Spare Parts (Screw)
SB-2080TR	P5	Spare Parts (Screw)
SB-2250TR	F51, P5	Spare Parts (Screw)
SB-2255TR	G55-G57, P5	Spare Parts (Screw)
SB-2260TR	P5	Spare Parts (Screw)
SB-2290TR	P5	Spare Parts (Screw)
SB-2545TR	F39, F41, F43, F47, F53, F67, P5	Spare Parts (Screw)
SB-2550TR	E32, E51	Spare Parts (Screw)
SB-2555TRG	P5	Spare Parts (Screw)
SB-2555TRP	P5	Spare Parts (Screw)
SB-2560TR	E34, E35, E44, F45-F49, F51, P5	Spare Parts (Screw)
SB-2570TR	E21, E23, E25-E34, E36, E39, E44, E51, F58, F60, F63-F65, G55-G57, P5	Spare Parts (Screw)
SB-25100TR	P5	Spare Parts (Screw)
SB-3060TR	F41, F53, P5	Spare Parts (Screw)
SB-3060TRG	P5	Spare Parts (Screw)
SB-3065TRP	P5	Spare Parts (Screw)
SB-3070TRG	P5	Spare Parts (Screw)
SB-3070TRP	P5	Spare Parts (Screw)
SB-3080TR	D14, D22, E17-E19, E29, E38, F30, F31, F33-F35, F84, G55, G80-G81, N16, P5	Spare Parts (Screw)
SB-3580TR	F75, P5	Spare Parts (Screw)
SB-3590TRP	P5	Spare Parts (Screw)
SB-3592TR	P5	Spare Parts (Screw)
SB-4050TRN	H10, P5	Spare Parts (Screw)
SB-4060TR	P5	Spare Parts (Screw)
SB-4065TR	E34, E35, E44, F39, F41, F45-F47, F53, F67, P5	Spare Parts (Screw)
SB-4070TRG	P5	Spare Parts (Screw)
SB-4070TRN	P5	Spare Parts (Screw)
SB-4070TRS	E45, G12, G13, J26, P5	Spare Parts (Screw)
SB-4070TRW	G12, G132, J24, P6	Spare Parts (Screw)
SB-4075TRP	P5	Spare Parts (Screw)
SB-4082TPR	P5	Spare Parts (Screw)
SB-4085TR	D8, D10, D12, D18, D22, E20, E23, E25-E28, E35, E44, F48, F49, F64, F77, F80, F83, F84, F87, G55, J21, P5	Spare Parts (Screw)
SB-4085TRP	P5	Spare Parts (Screw)
SB-4090TRP	P5	Spare Parts (Screw)
SB-4090TRPN	P5	Spare Parts (Screw)
SB-40115TR	F64, F65, F97, P5	Spare Parts (Screw)
SB-40120TR	G19, H14, H15, P5	Spare Parts (Screw)
SB-40125TRN	E30, E31, F58, F60, F63, N8, P5	Spare Parts (Screw)
SB-40140TR	P5	Spare Parts (Screw)
SB-40140TRN	P5	Spare Parts (Screw)
SB-45130TR	P5	Spare Parts (Screw)
SB-4590TRWN	E12, E51, H8, H33, J22, P5	Spare Parts (Screw)
SB-5070TR	P5	Spare Parts (Screw)
SB-5085TR	P5	Spare Parts (Screw)
SB-5090TR	E23, F72, P5	Spare Parts (Screw)
SB-50120TR	P5	Spare Parts (Screw)
SB-50120TRP	P5	Spare Parts (Screw)
SB-50120TRS	P5	Spare Parts (Screw)
SB-50140TR	P5	Spare Parts (Screw)
SB-50140TRP	P5	Spare Parts (Screw)
SB-60120TR	G23-G25, G84, G92-G93, H18, H19, P5	Spare Parts (Screw)
SC-30067	P6	Spare Parts (Screw)
SC-35085	P6	Spare Parts (Screw)
SC-40100	P6	Spare Parts (Screw)
SC-50130	P6	Spare Parts (Screw)
SC-60160	P6	Spare Parts (Screw)
SC-60210	P6	Spare Parts (Screw)
SCAC※ ○○○○-○○	E49, P21	Toolholder (Turning / Discontinued Description)
SCACR ○○○○-○○FF	E49, P21	Toolholder (Turning / Discontinued Description)
SCLC※ ○○○○□-○○	E23, E49	Toolholder (Turning)
SCLC※ ○○-○□□FF	E23, E49	Toolholder (Turning)
SCLC※ ○○○○□(□)-○○FF	E23, E49	Toolholder (Turning)
SCLNR ○(○)-○.○□F	E38	Toolholder (for Small Double-Sided Tools)
SCLNR ○○○○□-○○FF	E38	Toolholder (for Small Double-Sided Tools)
SCMT ○○○○HQ	B67	Insert (Turning)
SDJC※ ○○○○□-○○	E25, E48	Toolholder (Turning)
SDJC※ ○○○○□-○○F	E48, P21	Toolholder (Turning / Discontinued Description)
SDJCR ○○(.○)-○□□-FO	E20, E49	Toolholder (Goose-neck Holder)
SDJCR ○○○○□□-○○-F○○	E20, E49	Toolholder (Goose-neck Holder)
SDJC※ ○(○)-○□□FF	E25, E49	Toolholder (Turning)
SDJC※ ○○○○□(□)-○○FF	E25, E49	Toolholder (Turning)
SDLC※ ○(○)-○□□FF	E26, E49	Toolholder (Turning / Discontinued Description)
SDLC※ ○○○○□(□)-○○FF	E26, E50	Toolholder (Turning / Discontinued Description)
SDLNR ○(○)-○.○□F	E38	Toolholder (for Small Double-Sided Tools)
SDLNR ○○○○□-○○FF	E38	Toolholder (for Small Double-Sided Tools)
SDLP※ ○(○)-○□□FF	E28, E50	Toolholder (Turning)
SDLP※ ○○○○-○○F	E50, P21	Toolholder (Turning / Discontinued Description)
SDLP※ ○○○○□(□)-○○FF	E28, E50	Toolholder (Turning)
SDNCN ○(○)-○□□	E27, E50	Toolholder (Turning)
SDNCN ○○○○□(□)-○○	E27, E48	Toolholder (Turning)
SDNC※ ○-○□□F	E27, E50	Toolholder (Turning)
SDNC※ ○○○○□□-○○F	E27, E50	Toolholder (Turning)
SDXC※ ○○○○□□-○○	E26, E50	Toolholder (Turning)
SE-3070TRP	P6	Spare Parts (Screw)
SE-40050TRN	P6	Spare Parts (Screw)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru