для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
SE-40055TR	P6	Spare Parts (Screw)
SE-40068TR	P6	Spare Parts (Screw)
SE-40080TR	P6	Spare Parts (Screw)
SE-40090TR	P6	Spare Parts (Screw)
SE-40100TR	P6	Spare Parts (Screw)
SE-40120TR	G36, G132, H24, H33, P6	Spare Parts (Screw)
SE-50125TR	G19, G36, G132, H14, H24, H33, P6	Spare Parts (Screw)
SEG○○○NE	C29	Insert (Turning)
SF%-○○○(○)□	G112, G114, G115	Blade (Face Grooving)
SH-50150TR	P6	Spare Parts (Screw)
SH-○○○○	F95	Sleeve (for Boring Bar / Previous Description)
SH○○○○-○○○	F95	Sleeve (for Boring Bar)
SHA○○○○(.○)-○○○	F94, G57	Sleeve (for Small Tools SIGE)
SHC○○○○-○○	F95	Coolant Sleeve (for Boring Bar)
SHC-○○○○○○	F95	Coolant Sleeve (for Boring Bar / Previous Description)
SHL-○	F95	Spare Parts (Back Cover)
SI-GIV%○○-○○	G61	Insert (Grooving)
SIGE%○○EH	G55	Toolholder (Grooving)
SIGE%○○○○□-EH	G55	Toolholder (Grooving)
SIGE%○○○○-WH	G56	Toolholder (Grooving)
SIGER○○○○-WH-90	G57	Toolholder (Grooving / for Small Tools)
SIN%○○○○S-○○	J21	Toolholder (Threading)
SIN%○○○○S-○○E	J21	Toolholder (Threading)
SIT%○○○○-○○	F56, J35	Toolholder (Boring / Threading)
SJLC%○○○○○B-○○W	F50	Boring Bar (Previous Description)
SJS-○	F96	Coolant Joint
SJZC%○○○○○B-○○W	F50	Boring Bar (Previous Description)
SKC-2	G31, G71, J16, J17	Spare Part (Clamp Screw)
SKC-3	G31, G71, G117, J16, J17	Spare Part (Clamp Screw)
SL-○(.○-○○)	F95	Sleeve (for Boring Bar)
SLS-1	F94, F95	Sleeve (for Boring Bar)
SLS-2	F95	Sleeve (for Boring Bar)
SMOOOOA	N14-N16	Spare Parts (Plate)
SMOOOOB	N14-N16	Spare Parts (Plate)
SNGA○○○	B32	Insert (Turning)
SNGA○○○MEF	C10	Insert (Turning)
SNGA○○○S○○○○○	B93	Insert (Turning)
SNGA○○○S○○○○○ME	C10	Insert (Turning)
SNGA○○○S○○○○○MEH	C10	Insert (Turning)
SNGA○○○S○○○○○MEP	C10	Insert (Turning)
SNGA○○○S○○○○○MET	C10	Insert (Turning)
SNGA○○○T○○○○○	B93	Insert (Turning)
SNGA○○○T○○○○○AA	B93	Insert (Turning)
SNGA○○○T○○○○○ME	C10	Insert (Turning)
SNGG○○○%-25R	B32	Insert (Turning)
SNGG○○○%-B/C	B32	Insert (Turning)
SNG○○○S○○○○○	B93	Insert (Turning)
SNG○○○T○○○○○	B93, B94	Insert (Turning / Milling)
SNG○○○T○○○○○AA	B93	Insert (Turning)
SNGX○○○T○○○○○	B94	Insert (Turning)
SNM○○○	B32	Insert (Turning / Milling)
SNMA○○○	B32	Insert (Turning)
SNMA○○○T○○○○○AA	B93	Insert (Turning)
SNMF○○○○○○-21	B87	Insert (Turning)
SNMG○○○	B29	Insert (Turning)
SNMG○○○C	B31	Insert (Turning)
SNMG○○○(○)GC	B31	Insert (Turning)
SNMG○○○HQ	B29	Insert (Turning)
SNMG○○○HS	B29	Insert (Turning)
SNMG○○○MQ	B31	Insert (Turning)
SNMG○○○MS	B31	Insert (Turning)
SNMG○○○MU	B31	Insert (Turning)
SNMG○○○PG	B29	Insert (Turning)

Part Number	Page	Description
SNMG○○○PH	B30	Insert (Turning)
SNMG○○○PQ	B29	Insert (Turning)
SNMG○○○PS	B29	Insert (Turning)
SNMG○○○PT	B29	Insert (Turning)
SNMG○○○%-C	B32	Insert (Turning)
SNMG○○○XP	B30	Insert (Turning)
SNMG○○○XQ	B30	Insert (Turning)
SNMG○○○XS	B30	Insert (Turning)
SNMG○○○ZS	B31	Insert (Turning)
SNMM○○○PX	B30	Insert (Turning)
SNM○○○S○○○○○	C19	Insert (Turning)
SNM○○○T○○○○○	B94	Insert (Turning)
SP-2D	D14, D22, P18	Spare Parts (Spring)
SP-3D	D8, D10, D12, D22, F77, F80, F83, F84, F87, P18	Spare Parts (Spring)
SP-5	G69, P18	Spare Parts (Spring)
SP-5D	D18, P18	Spare Parts (Spring)
SP-6	G40-G41, G67, P18	Spare Parts (Spring)
SP-8	P18	Spare Parts (Spring)
SP3X4	F30, F31, F33.P6	Spare Parts (Screw)
SP3X6	P6	Spare Parts (Screw)
SP3X8	D40, E42, E43, J20, J21, N9, P6	Spare Parts (Screw)
SP3X10	F70, F71, P6	Spare Parts (Screw)
SP4X9	P6	Spare Parts (Screw)
SP8X35	P6	Spare Parts (Screw)
SP-129	D36, D37, P10	Spare Parts (Shim)
SP-130A	F89, P11	Spare Parts (Shim)
SP-141	D27, D32, D33, D36, D37, P10	Spare Parts (Shim)
SP-141P	F89, F90, P11	Spare Parts (Shim)
SP-143	D27, D36, D37, P10	Spare Parts (Shim)
SP-143P	F89, P11	Spare Parts (Shim)
SP-148	D36, D37, P10	Spare Parts (Shim)
SP-162	D27, D32, D33, P10	Spare Parts (Shim)
SP-210A	F91, P11	Spare Parts (Shim)
SP-219	D38, P10	Spare Parts (Shim)
SP-221	D28, P10	Spare Parts (Shim)
SP-223	D28, P10	Spare Parts (Shim)
SP-230P	P11	Spare Parts (Shim)
SP-341P	F89, P11	Spare Parts (Shim)
SP-342	D25, P10	Spare Parts (Shim)
SP-420A	F91, P11	Spare Parts (Shim)
SP-429	D34, P11	Spare Parts (Shim)
SP-441	D24, D30, P10	Spare Parts (Shim)
SP-441P	F90, P11	Spare Parts (Shim)
SP-443	D24, P10	Spare Parts (Shim)
SP-443P	P11	Spare Parts (Shim)
SP-454	D24, P10	Spare Parts (Shim)
SP-521	D31, P11	Spare Parts (Shim)
SP-521P	F90, P11	Spare Parts (Shim)
SP-523	P11	Spare Parts (Shim)
SP-523P	P11	Spare Parts (Shim)
SP-541	D31, P11	Spare Parts (Shim)
SP-543	P11	Spare Parts (Shim)
SP-826	D35, P11	Spare Parts (Shim)
SP-829	D35, P11	Spare Parts (Shim)
SP-841	D29, D35, P11	Spare Parts (Shim)
SP-843	D29, D35, P11	Spare Parts (Shim)
SP-849	D35, P11	Spare Parts (Shim)
SP-861	D29, P11	Spare Parts (Shim)
SPGH○○○%	B67	Insert (Turning)
SPG○○○	B67, C29	Insert (Turning / Milling)
SPG○○○NE	C29	Insert (Turning / Milling)
SPG○○○T○○○○○AA	B97	Insert (Turning)
SPG○○○T○○○○○	B97	Insert (Turning)
SPGR○○○%	B67	Insert (Turning)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru