для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
SPM	○○○	B67	Insert (Turning / Milling)
SPMR	○○○	B67	Insert (Turning / Milling)
SPMR	○○○G	B67	Insert (Turning / Milling)
SP-RC		D40, P12	Spare Parts (Shim)
SPW-6045		P6	Spare Parts (Screw)
SPW-7050		P6	Spare Parts (Screw)
SRCP℅	○○○○B-○○-A○○	F72	Boring Bar (for Bearing Machining)
SS-4N		E30, E31, F58, F61, F63, N8, P6	Spare Parts (Shim Screw)
SSKPR	○○○○B-○○	F70	Boring Bar (Previous Description)
STDER	○○CA○○	N16	Toolholder (Cartridge)
STDPR	○○CA○○	N16	Toolholder (Cartridge)
STEER	○○CA○○	N16	Toolholder (Cartridge)
STEPR	○○CA○○	N16	Toolholder (Cartridge)
STFER	○○CA○○	N16	Toolholder (Cartridge)
STFPR	○○CA○○	N16	Toolholder (Cartridge)
STGC℅	○○○○□-○○	E29	Toolholder (Turning)
STGP℅	○○○○□-○○	E29	Toolholder (Turning)
STLNR	○(○)-○.○□F	E39	Toolholder (for Small Double-Sided Tools)
STLNR	○○○○□-○○FF	E39	Toolholder (for Small Double-Sided Tools)
STVP℅	○○-○	J18	Toolholder (Threading)
STWL	○○○○□-15	G80	Toolholder (for Twin Bars)
STWR	○○○○□-15	F34	Toolholder (for Twin Bars)
STWSR	○○○○□(□)-15T	F35, G80	Toolholder (for Twin Bars)
STXB℅	○○○○○B-○○W	F57	Boring Bar (Previous Description)
STXP℅	○○○○○B-○○W	F57	Boring Bar (Previous Description)
STZB℅	○○○○○B-○○W	F57	Boring Bar (Previous Description)
SV-60136R		P6	Spare Parts (Screw)
SV-60136TR		P6	Spare Parts (Screw)
SVJB℅	○○○○□-○○	E30	Toolholder (Turning)
SVJB℅	○○○○-○○F	E50, P21	Toolholder (Turning / Discontinued Description)
SVJB℅	○○○○□-○○(N)	E30	Toolholder (Turning)
SVJB℅	○-○□□FF	E30, E50	Toolholder (Turning)
SVJB℅	○○○○□□-○○FF	E30, E50	Toolholder (Turning)
SVJP℅	○(○)-○□□FF	E32, E51	Toolholder (Turning)
SVJP℅	○○○○□(□)-○○FF	E32, E51	Toolholder (Turning)
SVLP℅	○○○○-○○F	E50, P21	Toolholder (Turning / Discontinued Description)
SVLP℅	○(○)-○(○)□□FF	E32, E51	Toolholder (Turning)
SVLP℅	○○○○□(□)-○○FF	E32, E51	Toolholder (Turning)
SVLPR	○○(.○)-○□□-F○	E21	Toolholder (Goose-neck Holder)
SVLPR	○○○○□□-○○-F○○	E21	Toolholder (Goose-neck Holder)
SVNR	○○○○□-12	P22	Toolholder (for System Tip-Bars / Discontinued Description)
SVNR	○○○○□-12N	F30	Toolholder (for System Tip-Bars)
SVN-32		F58, F61, F63-F65, F97, P12	Spare Parts (Shim)
SVN-32N		E30, E31, N8, P12	Spare Parts (Shim)
SVNSR	○(○)-12-○○	F30	Toolholder (for System Tip-Bars)
SVNSR	○○○○□-12-○○	P22	Toolholder (for System Tip-Bars / Discontinued Description)
SVNSR	○○○○□-12-○○N	F30	Toolholder (for System Tip-Bars)
SVNSR	○○○○□-12-○○XN	F33	Toolholder (for System Tip-Bars)
SVPB℅	○○○○□(□)-○○	E31, E50	Toolholder (Turning)
SVPB℅	○○○○□-○○N	E31	Toolholder (Turning)
SVPP℅	○○○○□-○○	E50, P21	Toolholder (Turning / Discontinued Description)
SVPPR	○(○)-○(○)□□FF	E33, E51	Toolholder (Turning)
SVPPR	○○○○□(□)-○○FF	E33, E51	Toolholder (Turning)
SVVBN	○(○)-○□□	E31, E51	Toolholder (Turning)
SVVBN	○○○○□(□)-○○	E31, E48	Toolholder (Turning)
SVVBN	○○○○□-○○N	E31	Toolholder (Turning)
SW-1.8		N14-N16	Spare Parts (Axial Screw driver)
SYXP℅	○○○○□-○○F	P21	Toolholder (Turning / Discontinued Description)

Part Number		Page	Description
T			
T63H-	BL○○○-○○○	P28	Toolholder (HSK Tooling / Discontinued Description)
T63H-	C○○-○○(○)	N10	Toolholder (HSK Tooling)
T63H-	KGBA℅-16	N9	Grooving (HSK Tooling)
T63H-	KGBA℅-22-○○	N9	Grooving (HSK Tooling)
T63H-	KTNR-○○	N9	Threading (HSK Tooling)
T63H-	N○○-○○(○)	N10	Toolholder (HSK Tooling)
T63H-	PCLN℅-DX12	N5	Toolholder (HSK Tooling)
T63H-	PCMNN-□12	N5	Toolholder (HSK Tooling)
T63H-	PDJN℅-DX15	N5	Toolholder (HSK Tooling)
T63H-	PDNNN-□15	N6	Toolholder (HSK Tooling)
T63H-	PTGN℅-DX16	N6	Toolholder (HSK Tooling)
T63H-	PWLN℅-DX08	N7	Toolholder (HSK Tooling)
T63H-	S2020R-105T	N4	Toolholder (HSK Tooling)
T63H-	S2525-○○(○)F	N4	Toolholder (HSK Tooling)
T63H-	S2525℅-○○○	N3	Toolholder (HSK Tooling)
T63H-	SVLB℅-DX16N	N8	Toolholder (HSK Tooling)
T63H-	SVVBN-□16N	N8	Toolholder (HSK Tooling)
T63H-	WTENN-□16	N6	Toolholder (HSK Tooling)
T63H-	WWMNN-□08	N7	Toolholder (HSK Tooling)
T100H-	C○○-○○(○)	N10	Toolholder (HSK Tooling)
T100H-	N○○-○○(○)	N10	Toolholder (HSK Tooling)
T100H-	S2525-○○○F	N4	Toolholder (HSK Tooling)
T100H-	S2525R-○○○T	N4	Toolholder (HSK Tooling)
T100H-	S2525℅-○○○	N3	Toolholder (HSK Tooling)
TBET	○○○○(○)(○)M℅	B68	Insert (Turning)
TBG	○○○○F	C18	Insert (Turning)
TBG	○○○○(○)T○○○○○AA	B97	Insert (Turning)
TBG	○○○○(○)T○○○○○	C18	Insert (Turning)
TBGT	○○○○○CF	B68	Insert (Turning)
TBGT	○○○○(○)(○)M℅	B68	Insert (Turning)
TBGT	○○○○○M-CF	B68	Insert (Turning)
TBGT	○○○○○MP-CF	B68	Insert (Turning)
TBGT	○○○○(○)℅	B68	Insert (Turning)
TBGW	○○○○(○)	B68, C26	Insert (Turning)
TBGW	○○○○(○)NE	C26	Insert (Turning)
TBMT	○○○○(○)	C26	Insert (Turning)
TBMT	○○○○(○)DP	B68	Insert (Turning)
TBMT	○○○○(○)NE	C26	Insert (Turning)
TCET	○○○○(○)(○)F℅-USF	B69	Insert (Turning)
TCET	○○○○(○)MF℅-USF	B69	Insert (Turning)
TCG	○○○○(○)	B70	Insert (Turning)
TCG	○○○(○)(○)T○○○○○	B97	Insert (Turning)
TCGR	○○○○(○)℅-F	B70	Insert (Turning)
TCGT	○○○○(○)	B68	Insert (Turning)
TCGT	○○○(○)(○)(○)E℅-U	B69	Insert (Turning)
TCGT	○○○○(○)(○)F℅-U	B69	Insert (Turning)
TCGT	○○○(○)(○)(○)ME℅-U	B69	Insert (Turning)
TCGT	○○○(○)(○)(○)(○)MF℅-U	B69	Insert (Turning)
TCGT	○○○○(○)℅	B69	Insert (Turning)
TCGT	○○○(○)℅-A3	B69	Insert (Turning)
TCGW	○○○(○)(○)(○)	B70, C26	Insert (Turning)
TCGW	○○○(○)NE	C26	Insert (Turning)
TCGW	○○○(○)SE	C26	Insert (Turning)
TCMT	○○○(○)(○)(○)	C26	Insert (Turning)
TCMT	○○○○(○)(○)HQ	B68	Insert (Turning)
TCMT	○○○(○)(○)(○)NE	C26	Insert (Turning)
TCMT	○○○(○)SE	C26	Insert (Turning)
TCMX	○○○○(○)WP	B68	Insert (Turning)
TG	○○℅○○○	G14, G63	Insert (Grooving)
TGF	○○℅○○○-○○○	C30, G13	Insert (Grooving)
TGF	○○℅○○○N	G13	Insert (Grooving)
TH-4		P18	Spare Parts (Hexagon Wrench / T-shaped Type)
TH8X15		P6	Spare Parts (Screw)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru