для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
TKN ○(.○)	H27	Insert (Cut-Off)
TKN ○(.○)-P	H27	Insert (Cut-Off)
TK□□ ○(.○)	H7	Insert (Cut-Off)
TK□□ ○(.○)-P	H7	Insert (Cut-Off)
TKF ○○□□○○○-AS	C32	Insert (Grooving / Turning)
TKF ○○□□○○○-ASR	C32	Insert (Grooving / Turning)
TKF ○○□□○○○-NB(○.○)	C32, H6, H7	Insert (Grooving / Turning)
TKF ○○□□○○○-NB-○○DR	H6, H7	Insert (Cut-Off)
TKF ○○□□○○○-S	H6, H7	Insert (Cut-Off)
TKF ○○□□○○○-S-○○DR	H6, H7	Insert (Cut-Off)
TKF ○○□□○○○-T	H6, H7	Insert (Cut-Off)
TKF ○○□□○○○-T-○○DR	H6, H7	Insert (Cut-Off)
TKFB ○○L○○○○○MR	B84	Insert (Back Turning)
TKFB ○○R○○○○○-GQ	B85	Insert (Back Turning)
TKFB ○○R○○○○○M	B84	Insert (Back Turning)
TKFS ○○□□○○○-S	H11	Insert (Cut-Off)
TKFT 12□□○○○○(○)	J22	Insert (Threading)
TN-32	J20, J21, N9, P12	Spare Parts (Shim)
TN-43	J20, J21, N9, P12	Spare Parts (Shim)
TNEG ○○○(○)□□-SSF	B40	Insert (Turning)
TNGA ○○○	B38	Insert (Turning)
TNGA ○○○MEF	C11	Insert (Turning)
TNGA ○○○S○○○○○	B95	Insert (Turning)
TNGA ○○○(○)S○○○○○ME	C11	Insert (Turning)
TNGA ○○○S○○○○○MEH	C11	Insert (Turning)
TNGA ○○○S○○○○○MEP	C11	Insert (Turning)
TNGA ○○○S○○○○○MET	C11	Insert (Turning)
TNGA ○○○(○)S○○○○○SE	C11	Insert (Turning)
TNGA ○○○S○○○○○SET	C11	Insert (Turning)
TNGA ○○○T○○○○○	B95	Insert (Turning)
TNGA ○○○T○○○○○AA	B95	Insert (Turning)
TNGA ○○○T○○○○○ME	C11	Insert (Turning)
TNGA ○○○T○○○○○SE	C11	Insert (Turning)
TNGG ○○○AH	B39	Insert (Turning)
TNGG ○○○FP-TK	B36	Insert (Turning)
TNGG ○○○(○)MFP-SK	B36	Insert (Turning)
TNGG ○○○TK	B37	Insert (Turning)
TNGG ○○○(○)□□	B40	Insert (Turning)
TNGG ○○○□□-25R	B40	Insert (Turning)
TNGG ○○○□□-A3	B39	Insert (Turning)
TNGG ○○○(○)□□-B/C	B40	Insert (Turning)
TNGG ○○○(○)□□-S	B40	Insert (Turning)
TNGM ○○○S○○○○○BB○	C11	Insert (Turning)
TNG ○○○S○○○○○	B95	Insert (Turning)
TNG ○○○T○○○○○	B95	Insert (Turning)
TNG ○○○T○○○○○AA	B95	Insert (Turning)
TNGU ○○○○(○)ME□□-U	B51	Insert (Turning)
TNGU ○○○○(○)(○)MF□□-F	B51	Insert (Turning)
TNGU ○○○○(○)(○)MF□□-U	B51	Insert (Turning)
TNMA ○○○	B38	Insert (Turning)
TNMC ○○NV○○○○○	J19	Insert (Threading)
TNMG ○○○	B35	Insert (Turning)
TNMG ○○○AH	B39	Insert (Turning)
TNMG ○○○C	B38	Insert (Turning)
TNMG ○○○CQ	B33	Insert (Turning)
TNMG ○○○GC	B38	Insert (Turning)
TNMG ○○○(○)GP	B33	Insert (Turning)
TNMG ○○○GS	B34	Insert (Turning)
TNMG ○○○GT	B35	Insert (Turning)
TNMG ○○○GU	B37	Insert (Turning)
TNMG ○○○HK	B34	Insert (Turning)
TNMG ○○○HQ	B33	Insert (Turning)
TNMG ○○○HS	B34	Insert (Turning)
TNMG ○○○MQ	B37	Insert (Turning)
TNMG ○○○MS	B37	Insert (Turning)
TNMG ○○○MU	B37	Insert (Turning)
TNMG ○○○PG	B34	Insert (Turning)
TNMG ○○○PH	B35	Insert (Turning)
TNMG ○○(○)(○)PP	B33	Insert (Turning)
TNMG ○○○PQ	B33	Insert (Turning)
TNMG ○○○PS	B34	Insert (Turning)
TNMG ○○○PT	B35	Insert (Turning)
TNMG ○○○□□-C	B40	Insert (Turning)
TNMG ○○○□□-ST	B37	Insert (Turning)
TNMG ○○○TK	B37	Insert (Turning)
TNMG ○○○XF	B36	Insert (Turning)
TNMG ○○○XP	B36	Insert (Turning)
TNMG ○○○XQ	B36	Insert (Turning)
TNMG ○○○XS	B36	Insert (Turning)
TNMG ○○○ZS	B38	Insert (Turning)
TNMM ○○○(○)M	C23	Insert (Turning)
TNMM ○○○(○)MNE	C23	Insert (Turning)
TNMM ○○○(○)MSE	C23	Insert (Turning)
TNMM ○○○PX	B35	Insert (Turning)
TNM ○○○S○○○○○	C19	Insert (Turning)
TNN ○○E□□○○(.○)NPT	J10	Insert (Threading / Previous description)
TNN ○○ER○○PT	J10	Insert (Threading / Previous description)
TNN ○○ER○○UN	J8	Insert (Threading / Previous description)
TNN ○○ER○○W	J8	Insert (Threading / Previous description)
TNN ○○E□□○○○M	J6	Insert (Threading / Previous description)
TNN ○○ER○○○TR	J14	Insert (Threading / Previous description)
TNN ○○ER○○○○	J12	Insert (Threading / Previous description)
TNN ○○I□□○○(.○)NPT	J11	Insert (Threading / Previous description)
TNN ○○I□□○○PT	J11	Insert (Threading / Previous description)
TNN ○○IR○○UN	J9	Insert (Threading / Previous description)
TNN ○○IR○○W	J9	Insert (Threading / Previous description)
TNN ○○I□□○○○M	J7	Insert (Threading / Previous description)
TNN ○○IR○○○TR	J15	Insert (Threading / Previous description)
TNN ○○IR○○○○(○)	J15	Insert (Threading / Previous description)
TNW-32	P12	Spare Parts (Shim)
TPET ○○○○(○)(○)F□□-USF	B73	Insert (Turning)
TPET ○○○○(○)(○)(○)MF□□-USF	B73	Insert (Turning)
TPET ○○○○(○)(○)(○)M□□-FSF	B73	Insert (Turning)
TPET ○○○○(○)(○)□□-FSF	B73	Insert (Turning)
TPGB ○○○(○)(○)(○)	B74, C27, J35	Insert (Turning / Threading)
TPGB ○○○MEF	B16	Insert (Turning)
TPGB ○○○(○)(○)(○)NE	C27	Insert (Turning)
TPGB ○○○(○)(○)(○)SE	C26	Insert (Turning)
TPGB ○○○S○○○○○MES	B16	Insert (Turning)
TPGB ○○○(○)S○○○○○MET	B16	Insert (Turning)
TPGB ○○○(○)(○)(○) S○○○○○SET	B16	Insert (Turning)
TPGB ○○○(○)T○○○○○ME	B16	Insert (Turning)
TPGB ○○○(○)(○)(○) T○○○○○SE	B16	Insert (Turning)
TPGH ○○○(○)(○)(○)M□□	B72	Insert (Turning)
TPGH ○○○(○)M□□-H	B73	Insert (Turning)
TPGH ○○○(○)(○)(○)□□	B72	Insert (Turning)
TPGH ○○○(○)(○)(○)□□-H	B73	Insert (Turning)
TPG ○○○(○)(○)(○)	B76, C29	Insert (Turning / Milling)
TPG ○○○NE	C29	Insert (Turning / Milling)
TPG ○○○(○)SE	C29	Insert (Turning / Milling)
TPG ○○○(○)(○)T○○○○○AA	B97	Insert (Turning)
TPG ○○○S○○○○○SET	C18	Insert (Turning)
TPG ○○○(○)(○)T○○○○○	B97	Insert (Turning / Milling)
TPG ○○○(○)T○○○○○ME	C18	Insert (Turning)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru