для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
VPET ○○○○(○)(○)MF□-U	B81	Insert (Turning)
VPET ○○○○(○)(○)MF□-USF	B81	Insert (Turning)
VPET ○○○○(○)(○)□-FSF	B81	Insert (Turning)
VPGT ○○○○CF	B80	Insert (Turning)
VPGT ○○○○(○)(○)CK	B80	Insert (Turning)
VPGT ○○○○M-CF	B80	Insert (Turning)
VPGT ○○○○(○)(○)M-CK	B80	Insert (Turning)
VPGT ○○○○MF-GF	B80	Insert (Turning)
VPGT ○○○○MFP-GF	B80	Insert (Turning)
VPGT ○○○○MP-CF	B80	Insert (Turning)
VPGT ○○○○(○)(○)MP-CK	B80	Insert (Turning)
W		
W-6	G40, G67, P18	Spare Parts (Washer)
W6-14	P18	Spare Parts (Washer)
W-8	P18	Spare Parts (Washer)
W6X17	P6	Spare Parts (Screw)
W6X18	P6	Spare Parts (Screw)
W6X18N	P6	Spare Parts (Screw)
W6X20	P6	Spare Parts (Screw)
W8X16	P6	Spare Parts (Screw)
W8X18	P6	Spare Parts (Screw)
W8X21	P6	Spare Parts (Screw)
WB-5	F96, P18	Spare Parts (Washer)
WB-6	F96, P18	Spare Parts (Washer)
WB-8	F96, P18	Spare Parts (Washer)
WBET ○○○○(○)(○)M□-F	B82	Insert (Turning)
WBGT ○○○○○M□-CF	B82	Insert (Turning)
WBGT ○○○○○MP□-CF	B82	Insert (Turning)
WBGT ○○○○(○)(○)(○)M□-F	B82	Insert (Turning)
WBGT ○○○○(○)(○)□-F	B82	Insert (Turning)
WBGW ○○○○(○)(○)□	B83	Insert (Turning)
WBGW ○○○○(○)(○) S○○○○○□-SET	C18	Insert (Turning)
WBGW ○○○○(○)T○○○○○□-SE	C18	Insert (Turning)
WBMT ○○○○(○)(○)L	C28, C29	Insert (Turning)
WBMT ○○○○(○)(○)L-NE	C28, C29	Insert (Turning)
WBMT ○○○○○(○)L-SE	C28, C29	Insert (Turning)
WBMT ○○○○(○)(○)□-DP	B82	Insert (Turning)
WCGT ○○○○○□-F	B82	Insert (Turning)
WCS-1N	D16, N6, P14	Spare Parts (Clamp Set)
WCS-8	D23, F88, N7.P14	Spare Parts (Clamp Set)
WN-1	D16, D23, N6-N7, P19	Spare Parts (Shim Nut)
WNGA ○○○MEF	C13	Insert (Turning)
WNGA ○○○S○○○○○ME	C13	Insert (Turning)
WNGA ○○○S○○○○○MET	C13	Insert (Turning)
WNGA ○○○S○○○○○SE	C13	Insert (Turning)
WNGA ○○○S○○○○○SET	C13	Insert (Turning)
WNGA ○○○T○○○○○ME	C13	Insert (Turning)
WNGA ○○○T○○○○○AA	B96	Insert (Turning)
WNGA ○○○T○○○○○	B96	Insert (Turning)
WNGG ○○○AH	B48	Insert (Turning)
WNGG ○○○TK	B47	Insert (Turning)
WNGG ○○○□	B48	Insert (Turning)
WNGG ○○○(○)□-S	B48	Insert (Turning)
WNMA ○○○	B48	Insert (Turning)
WNMG ○○○	B45	Insert (Turning)
WNMG ○○○C	B48	Insert (Turning)
WNMG ○○○CJ	B44	Insert (Turning)
WNMG ○○○CQ	B44	Insert (Turning)
WNMG ○○○GC	B48	Insert (Turning)
WNMG ○○○GP	B43	Insert (Turning)
WNMG ○○○GS	B44	Insert (Turning)
WNMG ○○○GT	B45	Insert (Turning)
WNMG ○○○GU	B46	Insert (Turning)
WNMG ○○○(○)HQ	B44	Insert (Turning)
WNMG ○○○HS	B45	Insert (Turning)
WNMG ○○○HT	B45	Insert (Turning)
WNMG ○○○MQ	B47	Insert (Turning)
WNMG ○○○MS	B47	Insert (Turning)
WNMG ○○○MU	B47	Insert (Turning)
WNMG ○○○PG	B44	Insert (Turning)
WNMG ○○○PH	B45	Insert (Turning)
WNMG ○○○(○)PP	B43	Insert (Turning)
WNMG ○○○PQ	B43	Insert (Turning)
WNMG ○○○PS	B45	Insert (Turning)
WNMG ○○○PT	B45	Insert (Turning)
WNMG ○○○TK	B47	Insert (Turning)
WNMG ○○○WP	B43	Insert (Turning)
WNMG ○○○WQ	B43	Insert (Turning)
WNMG ○○○XP	B46	Insert (Turning)
WNMG ○○○XQ	B46	Insert (Turning)
WNMG ○○○XS	B46	Insert (Turning)
WNMG ○○○ZS	B48	Insert (Turning)
WNMM ○○○(○)M	C23	Insert (Turning)
WNMM ○○○(○)MNE	C23	Insert (Turning)
WNMM ○○○(○)MSE	C23	Insert (Turning)
WP-1S	P7	Spare Parts (Shim Pin)
WP5X11	F88, P7	Spare Parts (Shim Pin)
WP5X15	D23, N7, P7	Spare Parts (Shim Pin)
WPGT ○○○(○)(○)M□-Y	B83	Insert (Turning)
WPGT ○○○(○)(○)□-Y	B83	Insert (Turning)
WPGW ○○○(○)(○)	B83	Insert (Turning)
WPMT ○○○○(○)	C29	Insert (Turning)
WPMT ○○○(○)GP	B83	Insert (Turning)
WPMT ○○○(○)(○)HQ	B83	Insert (Turning)
WPMT ○○○○(○)NE	C29	Insert (Turning)
WPMT ○○○○○SE	C29	Insert (Turning)
WSP-1	D16, N6, P18	Spare Parts (Spacer)
WTENN ○○-○□	D16	Toolholder (Turning)
WTENN ○○○○□-○○N	D16	Toolholder (Turning)
WTJN□ ○○-○□	D16	Toolholder (Turning)
WTJN□ ○○○○□-○○N	D16	Toolholder (Turning)
WTKN□ ○○-○□	D16	Toolholder (Turning)
WTKN□ ○○○○□-○○N	D16	Toolholder (Turning)
WTN-33	D16, N6, P12	Spare Parts (Shim)
WTN-33-20	D16, P12	Spare Parts (Shim)
WWLN□ ○○○○□-○○	D23	Toolholder (Turning)
WWLN□ ○○○○B-○○E	F88	Boring Bar (Previous Description)
WWN-42	D23, N7, P12	Spare Parts (Shim)
WWP-42	F88, P12	Spare Parts (Shim)
WWP-42-16	F88, P12	Spare Parts (Shim)
X		
XNS-48	D8, D10, D22	Spare Parts (Clamp Screw)
XNS-510	D8	Spare Parts (Clamp Screw)
XNS36	D14	Spare Parts (Clamp Screw)
XNS59	D12	Spare Parts (Clamp Screw)
XNS510	D14, D19	Spare Parts (Clamp Screw)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru