

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
E○○□- SVUC%○○-○○A	F63	Boring Bars (Dynamic Bar)
E○○□- SWUB%○○-○○A	F65	Boring Bars (Dynamic Bar)
E○○□- SWUB%○○-○○A-○/○	F65	Boring Bars (Dynamic Bar)
E○○□- SWUP%○○-○○A	F65	Boring Bars (Dynamic Bar)
E○○□- SWUP%○○-○○A-○/○	F65	Boring Bars (Dynamic Bar)
EZBR ○○○○○○-○○○NB	C10,C21,F16	EZ Bars (Boring)
EZBR ○○○○○○□□-○○OF	F14,F15	EZ Bars (Boring)
EZBR ○○○○○○□□-○○OH	F14,F15	EZ Bars (Boring)
EZFGR ○○○○○○-○○○	G45	EZ Bars (Face Grooving)
EZGR ○○○○○○-○○○	G34	EZ Bars (Internal Grooving)
EZGR ○○○○○○-○○○S	G34	EZ Bars (Internal Grooving)
EZH ○○○○○(○)□□-○○(○)	F20-F25	Sleeve (for EZ Bars)
EZTR ○○○○○○-○○-○○○	J10	EZ Bars (Internal Threading)
EZVBR ○○○○○○-○○○	F19	EZ Bars (Copying / Profiling)
F		
FH-2	E17-E19,E22,E24,E30,P5	Spare Parts (Hexagon Wrench / Flag type)
FH-2.5	E41,P5	Spare Parts (Hexagon Wrench / Flag type)
FT-5	E34,P5	Spare Parts (Torx Wrench / Flag type)
FT-6	E29,E32,E33,E36,F18,F39,F43,F50,F53,F56,F58,F61,F63,F65,F59,G40,G41,J29,P5	Spare Parts (Torx Wrench / Flag type)
FT-7	F47,G42,P5	Spare Parts (Torx Wrench / Flag type)
FT-8	E21,E23,E25-E35,E42,F39,F41,F43-F45,F47,F49,F50,F55,F57,F59,G4,G40-G42,J6,J29,P5	Spare Parts (Torx Wrench / Flag type)
FT-10	E17-E19,E29,E43,F32,F33,F35,F41,F49,G4,G5,P5	Spare Parts (Torx Wrench / Flag type)
FT-15	E20,E21,E23,E25-E28,E30,E31,E35,E42,F39,F43,F45,F59,G12,G13,J28,J29,P5	Spare Parts (Torx Wrench / Flag type)
G		
GBA ○○%○○○	G8-G10	Insert (Grooving / Previous Part Number)
GBA ○○%○○○MY	G9	Insert (Grooving / Previous Part Number)
GBA ○○%○○○MYN	G7	Insert (Grooving)
GBA ○○%○○○ON	G6	Insert (Grooving)
GBA ○○%○○○OR	G10	Insert (Grooving / Previous Part Number)
GBA ○○%○○○-○○○	C9,C20,G8-G10	Insert (Grooving / Previous Part Number)
GBA ○○%○○○-○○○GM	G9	Insert (Grooving)
GBA ○○%○○○-○○○MY	G9	Insert (Grooving / Previous Part Number)
GBA ○○%○○○-○○○OR	G10	Insert (Grooving / Previous Part Number)
GDG ○○○○ON-○○○GS	G17	Insert (Grooving)
GDG ○○○○ON-○○○PG	H12	Insert (Cut-Off)
GDG ○○○○%○-○○○PG-15D	H12	Insert (Cut-Off)
GDGS ○○○○ON-○○○NB	C9,C20,G17	Insert (Grooving)

Part Number	Page	Description
GDM ○○○○ON-○○○GL	G16	Insert (Grooving)
GDM ○○○○ON-○○○GM	G16	Insert (Grooving)
GDM ○○○○ON-○○○PF	H12	Insert (Cut-Off)
GDM ○○○○ON-○○○PH	G17,H13	Insert (Grooving / Cut-Off)
GDM ○○○○ON-○○○PM	H13	Insert (Cut-Off)
GDM ○○○○ON-○○○PQ	H12	Insert (Cut-Off)
GDM ○○○○ON-○○○R-CM	G17	Insert (Grooving)
GDM ○○○○%○-○○○PF-15D	H12	Insert (Cut-Off)
GDM ○○○○%○-○○○PM-6D	H13	Insert (Cut-Off)
GDM ○○○○%○-○○○PQ-15D	H12	Insert (Cut-Off)
GDMS ○○○○ON-○○○GM	G16	Insert (Grooving)
GDMS ○○○○ON-○○○PH	G17,H13	Insert (Grooving / Cut-Off)
GDMS ○○○○ON-○○○PM	H13	Insert (Cut-Off)
GDMS ○○○○%○-○○○PM-6D	H13	Insert (Cut-Off)
GE%○ ○○○-○○○A	G38	Insert (Grooving)
GE%○ ○○○-○○○B	G38	Insert (Grooving)
GE%○ ○○○-○○○C	G39	Insert (Grooving)
GER ○○○-○○○AR	G38	Insert (Grooving)
GER ○○○-○○○BR	G38	Insert (Grooving)
GER ○○○-○○○CM	G39	Insert (Grooving)
GER ○○○-○○○CR	G39	Insert (Grooving)
GM%○ ○-TK-8D	G27,H18	Insert (Grooving / Plunge & Turn)
GM%○ ○(○)○(○)D	G27,H18	Insert (Grooving / Plunge & Turn)
GMG ○○○○-○○	G26	Insert (Grooving / Plunge & Turn) / Previous Part Number
GMG ○○○○-○○(○)MG	G26	Insert (Grooving / Plunge & Turn) / Previous Part Number
GMG ○○○○-○○(○)R	G26	Insert (Grooving / Plunge & Turn) / Previous Part Number
GMG ○○○○-○○○MS	G26	Insert (Grooving / Plunge & Turn) / Previous Part Number
GMM ○○○○-MT	G27,H18	Insert (Grooving / Plunge & Turn)
GMM ○○○○-NB	G27,H18	Insert (Grooving / Plunge & Turn)
GMM ○○○○%○-MT-15D	G27,H18	Insert (Grooving / Plunge & Turn)
GMM ○○○○%○-TK-8D	G27,H18	Insert (Grooving / Plunge & Turn)
GMM ○○○○%○-TMR-6D	H18	Insert (Grooving / Plunge & Turn)
GMM ○(○)(○)(○)-TK	G27,H18	Insert (Grooving / Plunge & Turn)
GMM ○○○○-TMR	H18	Insert (Grooving / Plunge & Turn)
GMM ○○○○-○○	G26	Insert (Grooving / Plunge & Turn) / Previous Part Number
GMM ○○○○-○○(○)MS	G26	Insert (Grooving / Plunge & Turn) / Previous Part Number
GMM ○○○○-○○(○)R	G26	Insert (Grooving / Plunge & Turn) / Previous Part Number
GMM ○○○○-○○○MW	G26	Insert (Grooving / Plunge & Turn)
GMN ○(○)	C9,C20,G27,G28,H18	Insert (Grooving / Plunge & Turn)
GMN ○-TK	G27,H18	Insert (Grooving / Plunge & Turn)
H		
HH5X16	G20,G21,G30,G31,H17,H20,H21,P2	Spare Parts (Screw)
HH5X25	G20,G21,G30,G31,H17,P2	Spare Parts (Screw)
HPB%○ ○○○○-○○○	F28	2-Edge Tip-Bars (Boring)
HPB%○ ○○○○-○○○NB	F28	2-Edge Tip-Bars (Boring)

GRADES	A
INSERTS	B
CBN & POD	C
TURNING	E
BORING	F
GROOVING	G
CUT-OFF	H
THREADING	J
SOLID END MILLS	L
MILLING	M
SPARE PARTS	P
TECHNICAL	R
INDEX	T