

PREVIOUS SPARE PART LIST

MHD (Face Mills and Integral Arbor Type)

Part Number	Spare Parts			
	Clamp Screw	Wrench	Arbor Bolt	Wrench
MHD 63-FMA -SA	SB-3080TR	DT-10	HH16X90	LW-14
80-FMA -SA			HH20X110	LW-17
100-FMA -SA			HH24X110	LW-19
MHD 63-FMA -A			HH16X90	LW-14
80-FMA -A			HH20X110	LW-17
100-FMA -A			HH24X110	LW-19
MHD 63-BT50 -SA			HH16X65	LW-14
80-BT50 -SA			HH20X90	LW-17
100-BT50 -SA			HH24X90	LW-19
MHD 63-BT50 -A			HH16X65	LW-14
80-BT50 -A			HH20X90	LW-17
100-BT50 -A			HH24X90	LW-19
MHD 63 -F			-	-
80 -F			-	-
100 -F			-	-

MHD (Radius)

Part Number	Spare Parts						
	Clamp Screw		Wrench		Arbor Bolt		Wrench
	for Bottom Insert	for Middle Insert	for Bottom Insert	for Middle Insert	1 Front Piece	2 Front Piece	
MHD 32-S32 -4RSA	SB-2560TR	SB-2560TR	DT-8	DT-8	-	HH8X50	LW-6
40-S32 -5RSA	SB-3080TR	SB-3080TR	DT-10	DT-10		HH8X55	
40-S42 -5RSA			DT-15			HH12X55	
50-S42 -6RSA	SB-4085TR						
MHD 32-S32 -A	SB-2560TR		DT-8		-	HH8X50	LW-6
40-S32 -A	SB-3080TR		DT-10			HH8X65	
40-S42 -A						HH12X65	
50-S42 -A							
MHD 32 -F	SB-2560TR		DT-8		-	-	-
40 -F	SB-3080TR		DT-10				
50 -F							
MHD 32 -4RF	SB-2560TR	SB-2560TR	DT-8	DT-8	-	-	-
40 -5RF	SB-3080TR	SB-3080TR	DT-10	DT-10			
50 -6RF	SB-4085TR		DT-15				

MVG

Part Number	Spare Parts	
	Clamp Set	Wrench
MVG ...	CPS-6V	LW-3

Blank Tool

Part Number	Spare Parts
	Coolant Pipe
T63H- BL...-...	CL63-1

GRADES	A
LINEUP / INSERTS	B
45° / 70° LEAD	C
75° LEAD	D
90° LEAD	E
HIGH FEED	F
MULTI-FUNCTION	G
SLOT MILLS	H
RADIUS / BALL-NOSE	J
OTHER APPLICATIONS	K
TOOL HOLDING	O
SPARE PARTS	P
TECHNICAL	R
INDEX	T