

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
Numeric		
556C%	P8	Spare Parts (Shim)
○-○○/○○- (○○K)-SET	K3	Toolholder (API Ring Groover)
A		
AJ- ○×○○(-○.○)	P2	Spare Parts (Adjustment Screw / Chamfering Attachment)
AJ-412	C16	Spare Parts (Adjustment Screw)
AP-1416	H20-H21	Spare Parts (Cam Pin)
AP-1820	H20-H21	Spare Parts (Cam Pin)
APET ○○○○PDR	B25	Insert (Milling)
APET ○○○○○○	B25	Insert (Milling)
API-RG-○ BT○○	K3	Body Part (API Ring Groovers)
API-RG-○ CV○○	K3	Body Part (API Ring Groovers)
API-RG-○ DIN-○○○○○	K3	Body Part (API Ring Groovers)
API-RG-○ NMTB○○	K3	Body Part (API Ring Groovers)
APKT ○○○○(○○)PDR-V	B18	Insert (Milling)
APMT ○○○○○○E%-NB○	B18	Insert (Milling)
APMT ○○○○○○ER-NBOP	B18	Insert (Milling)
B		
BCS- ○	P13	Spare Parts (Clamp Set)
BDGT ○○(□)○○○(○)FR-JA	B18	Insert (Milling)
BDMT ○○(□)○○○(○)ER-JS	B18	Insert (Milling)
BDMT ○○(□)○○○(○)ER-JT	B18-B19	Insert (Milling)
BDMT ○○(□)○○○(○)ER-NO	B19	Insert (Milling)
BDMT ○○(□)○○○(○)FR	B26	Insert (Milling)
BH3X6	P2	Spare Parts (Screw)
BH3X12	P2	Spare Parts (Screw)
BH6X25	P2	Spare Parts (Screw)
BH8X30	P2	Spare Parts (Screw)
BH6X10TR	P2	Spare Parts (Screw)
BX ○○○-SET	K3	Cartridge Set (API Ring Groover)
BX ○○○-R-SET	K3	Cartridge Set (API Ring Groover)
C		
C09N	C10, C12, P15	Spare Parts (Clamp)
C17R	P15	Spare Parts (Clamp)
C20R	P15	Spare Parts (Clamp)
C25R	P15	Spare Parts (Clamp)
C43R	C19	Spare Parts (Clamp)
C44R	C19	Spare Parts (Clamp)
C90SD ○○○○-12%	H20-H21	Spare Parts (Cartridge)
C90SP ○○○○-10%	H20-H21	Spare Parts (Cartridge)
C91R	E48	Spare Parts (Clamp)
C92R	E48	Spare Parts (Clamp)
CB-11	P16	Spare Parts (Chipbreaker)
CB-12	P16	Spare Parts (Chipbreaker)
CB-13	P16	Spare Parts (Chipbreaker)
CB-14	P16	Spare Parts (Chipbreaker)
CB-15	P16	Spare Parts (Chipbreaker)
CB-16	P16	Spare Parts (Chipbreaker)
CB-17	P16	Spare Parts (Chipbreaker)
CB-51	P16	Spare Parts (Chipbreaker)
CB-S3220	P16	Spare Parts (Chipbreaker)
CB-S4220	P16	Spare Parts (Chipbreaker)
CB-T2212	P16	Spare Parts (Chipbreaker)
CB-T3220	P16	Spare Parts (Chipbreaker)
CE-010	P13	Spare Parts (Clamp Set)
CE-020	P13	Spare Parts (Clamp Set)
CE-030	P13	Spare Parts (Clamp Set)
CE-030A	P13	Spare Parts (Clamp Set)
CE-040	P13	Spare Parts (Clamp Set)

Part Number	Page	Description
CE-111	P15	Spare Parts (Clamp)
CE-121	P15	Spare Parts (Clamp)
CE-131	P15	Spare Parts (Clamp)
CE-141	P15	Spare Parts (Clamp)
CE-220	P13	Spare Parts (Clamp Set)
CE-320	P13	Spare Parts (Clamp Set)
CE-360S	P13	Spare Parts (Clamp Set)
CE-410	P13	Spare Parts (Clamp Set)
CE-430	P13	Spare Parts (Clamp Set)
CEM ○○○○-OW(-7.5)	E75	End Mill
CGA-3%	P15	Spare Parts (Clamp)
CGA-4%	P15	Spare Parts (Clamp)
CGA-5%	P15	Spare Parts (Clamp)
CGB%	P15	Spare Parts (Clamp)
CGH-1%	P15	Spare Parts (Clamp)
CGH-2%	P15	Spare Parts (Clamp)
CGH-3%	P15	Spare Parts (Clamp)
CGIA-3R	P15	Spare Parts (Clamp)
CGIA-4R	P15	Spare Parts (Clamp)
CGIA-5R	P15	Spare Parts (Clamp)
CH-20R	C22, P15	Spare Parts (Clamp)
CL63-1	P19	Spare Parts (Coolant Pipe)
CL100-1	P19	Spare Parts (Coolant Pipe)
CM ○○○○-○○(○)	K5	End Mill (Chamfering)
CM ○○○○-○○-○○	K5	End Mill (Chamfering)
CM ○○○○-○○-AL	K5	End Mill (Chamfering)
CP-2D	P16	Spare Parts (Clamp)
CP-3D	P16	Spare Parts (Clamp)
CP-5D	P16	Spare Parts (Clamp)
CP-8TE	E49, P16	Spare Parts (Clamp)
CP-8W	E49, P16	Spare Parts (Clamp)
CP-RC%	P13	Spare Parts (Clamp Set)
CP8X15TL	C18, P2	Spare Parts (Screw)
CP8X23TL	C18, P2	Spare Parts (Screw)
CPS-1	P14	Spare Parts (Clamp Set)
CPS-2	P14	Spare Parts (Clamp Set)
CPS-2P	P14	Spare Parts (Clamp Set)
CPS-2S	E49, E69, P14	Spare Parts (Clamp Set)
CPS-2TR	E66, P14	Spare Parts (Clamp Set)
CPS-3	E49, P14	Spare Parts (Clamp Set)
CPS-4V	P14	Spare Parts (Clamp Set)
CPS-5E	E69, P14	Spare Parts (Clamp Set)
CPS-5F	K12, P14	Spare Parts (Clamp Set)
CPS-5%	P14	Spare Parts (Clamp Set)
CPS-5S	P14	Spare Parts (Clamp Set)
CPS-5V	P14	Spare Parts (Clamp Set)
CPS-6F	K12, P14	Spare Parts (Clamp Set)
CPS-6M	D8, P14	Spare Parts (Clamp Set)
CPS-6S	P14	Spare Parts (Clamp Set)
CPS-6V	K14, P14	Spare Parts (Clamp Set)
CPS-8V	P14	Spare Parts (Clamp Set)
CS-2D	P2	Spare Parts (Screw)
CS-3D	P2	Spare Parts (Screw)
CS-5D	P2	Spare Parts (Screw)
D		
DCMT ○○○○HQ	B25, K4	API Insert (Ring Grooving)
DCMT ○○○○CQ	B25, K4	API Insert (Ring Grooving)
DC-42	P8	Spare Parts (Shim)
DC-44	P8	Spare Parts (Shim)
DD-42	P8	Spare Parts (Shim)
DD-42-16	P8	Spare Parts (Shim)
DD-43	P8	Spare Parts (Shim)

T INDEX