

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
LC-42N	P9	Spare Parts (Shim)
LC-42N-20	P9	Spare Parts (Shim)
LC-42N%	P9	Spare Parts (Shim)
LC-42N%-20	P9	Spare Parts (Shim)
LC-42%	P9	Spare Parts (Shim)
LC-53	P9	Spare Parts (Shim)
LC-53N	P9	Spare Parts (Shim)
LD-4K	P9	Spare Parts (Shim)
LD-4K43	P9	Spare Parts (Shim)
LD-32	P9	Spare Parts (Shim)
LD-32N	P9	Spare Parts (Shim)
LD-42	P9	Spare Parts (Shim)
LD-42-20	P9	Spare Parts (Shim)
LD-43	P9	Spare Parts (Shim)
LD-43-20	P9	Spare Parts (Shim)
LGBA-16% S	P14	Spare Parts (Clamp Set)
LGBA-22% S	P14	Spare Parts (Clamp Set)
LL-03	P7	Spare Parts (Lock Pin)
LL-03N	P7	Spare Parts (Lock Pin)
LL-03S	P7	Spare Parts (Lock Pin)
LL-03SN	P7	Spare Parts (Lock Pin)
LL-03T	P7	Spare Parts (Lock Pin)
LL-03TN	P7	Spare Parts (Lock Pin)
LL-05C	P7	Spare Parts (Lock Pin)
LL-1	P7	Spare Parts (Lock Pin)
LL-1C	P7	Spare Parts (Lock Pin)
LL-1CN	P7	Spare Parts (Lock Pin)
LL-1D	P7	Spare Parts (Lock Pin)
LL-1DN	P7	Spare Parts (Lock Pin)
LL-1K	P7	Spare Parts (Lock Pin)
LL-1N	P7	Spare Parts (Lock Pin)
LL-2	P7	Spare Parts (Lock Pin)
LL-2C	P7	Spare Parts (Lock Pin)
LL-2K	P7	Spare Parts (Lock Pin)
LL-2N	P7	Spare Parts (Lock Pin)
LL-3	P7	Spare Parts (Lock Pin)
LL-3K	P7	Spare Parts (Lock Pin)
LL-3N	P7	Spare Parts (Lock Pin)
LL-4	P7	Spare Parts (Lock Pin)
LL-5	P7	Spare Parts (Lock Pin)
LL-5N	P7	Spare Parts (Lock Pin)
LNEU ○○○○-○○(-○)	H10	Insert (Milling)
LNEU ○○○○-○○S(-○)	H10	Insert (Milling)
LOF07R	C16	Spare Parts (Cartridge)
LOGU ○○○○○ER-GM	B13	Insert (Milling)
LOGT ○○○○○FR-AM	B13	Insert (Milling)
LOMU ○○○○○ER-GH	B13	Insert (Milling)
LOMU ○○○○○ER-GM	B13	Insert (Milling)
LOMU ○○○○○ER-SM	B13	Insert (Milling)
LP-2S	P7	Spare Parts (Lock Pin)
LP-6S	P7	Spare Parts (Lock Pin)
LPA-11	P7	Spare Parts (Anchor Pin)
LPA-13	P7	Spare Parts (Anchor Pin)
LPA-17	P7	Spare Parts (Anchor Pin)
LPF-11	P7	Spare Parts (Anchor Pin)
LPF-13	P7	Spare Parts (Anchor Pin)
LPF-17	P7	Spare Parts (Anchor Pin)
LPF-1113	P7	Spare Parts (Anchor Pin)
LPF-1117	P7	Spare Parts (Anchor Pin)
LPGT ○○○○○ER-GM	B13, F23	Insert (Milling)
LR-10C	P9	Spare Parts (Shim)
LR-12C	P9	Spare Parts (Shim)

Part Number	Page	Description
LR-16C	P9	Spare Parts (Shim)
LR-80	P9	Spare Parts (Shim)
LR-81	P9	Spare Parts (Shim)
LS-03	P4	Spare Parts (Lock Screw)
LS-03N	P4	Spare Parts (Lock Screw)
LS-03S	P4	Spare Parts (Lock Screw)
LS-03SN	P4	Spare Parts (Lock Screw)
LS-05	P4	Spare Parts (Lock Screw)
LS-1	P4	Spare Parts (Lock Screw)
LS-1N	P4	Spare Parts (Lock Screw)
LS-1P	P4	Spare Parts (Lock Screw)
LS-1S	P4	Spare Parts (Lock Screw)
LS-1SN	P4	Spare Parts (Lock Screw)
LS-1T	P4	Spare Parts (Lock Screw)
LS-2	P4	Spare Parts (Lock Screw)
LS-2N	P4	Spare Parts (Lock Screw)
LS-2P	P4	Spare Parts (Lock Screw)
LS-3	P4	Spare Parts (Lock Screw)
LS-3P	P4	Spare Parts (Lock Screw)
LS-4	P4	Spare Parts (Lock Screw)
LS-4N	P4	Spare Parts (Lock Screw)
LS-11	P4	Spare Parts (Lock Screw)
LS-15	P4	Spare Parts (Lock Screw)
LS-32	P9	Spare Parts (Shim)
LS-42	P9	Spare Parts (Shim)
LSD-445R	P12	Spare Parts (Cartridge)
LSE-445R	P12	Spare Parts (Cartridge)
LSE-445SR	C19	Spare Parts (Cartridge)
LSO-445R	C22, P12	Spare Parts (Cartridge)
LSP-1	P7	Spare Parts (Shim Pin)
LSP-2	P7	Spare Parts (Shim Pin)
LSP-2K	P7	Spare Parts (Shim Pin)
LSP-3	P7	Spare Parts (Shim Pin)
LSP-3K	P7	Spare Parts (Shim Pin)
LSP-415R	P12	Spare Parts (Cartridge)
LT-3K	P9	Spare Parts (Shim)
LT-32	P9	Spare Parts (Shim)
LT-32N	P9	Spare Parts (Shim)
LT-32N-20	P9	Spare Parts (Shim)
LT-42	P9	Spare Parts (Shim)
LT-42N	P9	Spare Parts (Shim)
LT-42N-20	P9	Spare Parts (Shim)
LTE-490R	P12	Spare Parts (Cartridge)
LTE-490SR	E48	Spare Parts (Cartridge)
LTK-5	P18	Spare Parts (Wrench)
LTP-10	P17	Spare Parts (Torx Plus Wrench / L-Shape Type)
LTP-15	P17	Spare Parts (Torx Plus Wrench / L-Shape Type)
LTW-8SS	P17	Spare Parts (Torx Wrench / L-Shape Type)
LTW-10S	P17	Spare Parts (Torx Wrench / L-Shape Type)
LTW-10SS	P17	Spare Parts (Torx Wrench / L-Shape Type)
LTW-15S	P17	Spare Parts (Torx Wrench / L-Shape Type)
LTW-20	K6, P17	Spare Parts (Torx Wrench / L-Shape Type)
LTW-25	P17	Spare Parts (Torx Wrench / L-Shape Type)
LW-1.5	P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-2	C18, E49, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-2.5	H20-H21, P18	Spare Parts (Hexagon Wrench / L-Shape Type)

GRADES	A
LINEUP / INSERTS	B
45° / 60° LEAD	C
75° LEAD	D
90° LEAD	E
HIGH FEED	F
MULTI-FUNCTION	G
SLOT MILLS	H
RADIUS / BALL-NOSE	J
OTHER APPLICATIONS	K
TOOL HOLDING	O
SPARE PARTS	P
TECHNICAL	R
INDEX	T