

A			
A63-WH-	BL○○○-○○(○)	N12	Blank Tool (HSK Tooling) / Previous Description
A63-WH-	C○○-○○(○)	N11	Toolholder (HSK Tooling) / Previous Description
A63-WH-	KGBA%-16	N10	Grooving (HSK Tooling) / Previous Description
A63-WH-	KGBA%-22-○○	N10	Grooving (HSK Tooling) / Previous Description
A63-WH-	KTNR-○○	N10	Threading (HSK Tooling) / Previous Description
A63-WH-	N○○-○○(○)	N11	Toolholder (HSK Tooling) / Previous Description
A63-WH-	PCLN%-DX12	N6	Toolholder (HSK Tooling) / Previous Description
A63-WH-	PCMNN-□12	N6	Toolholder (HSK Tooling) / Previous Description
A63-WH-	PDJN%-DX15	N6	Toolholder (HSK Tooling) / Previous Description
A63-WH-	PDNNN-□15	N7	Toolholder (HSK Tooling) / Previous Description
A63-WH-	PTGN%-DX16	N7	Toolholder (HSK Tooling) / Previous Description
A63-WH-	PWLN%-DX08	N8	Toolholder (HSK Tooling) / Previous Description
A63-WH-	S2525%-105	N4	Toolholder (HSK Tooling) / Previous Description
A63-WH-	SVLB%-DX16	N9	Toolholder (HSK Tooling) / Previous Description
A63-WH-	SVVBN-□16	N9	Toolholder (HSK Tooling) / Previous Description
A63-WH-	WTENN-□16	N7	Toolholder (HSK Tooling) / Previous Description
A63-WH-	WWMNN-□08	N8	Toolholder (HSK Tooling) / Previous Description
A○○□-	PCLN%-○○-○○	F66	Boring Bar
A○○□-	PDUN%-○○-○○	F67	Boring Bar
A○○□-	PTUN%-○○-○○	F68	Boring Bar
A○○□-	PWLN%-○○-○○	F69	Boring Bar
A○○□-	SCLC%-○○-○○E	F50	Boring Bar
A○○□-	SCLC%-○○-○○AE	F25	Boring Bar (Dynamic Bar)
A○○□-	SCLP%-○○-○○AE	F27	Boring Bar (Dynamic Bar)
A○○□-	SCLP%-○○-○○E	F50	Boring Bar
A○○□-	SDQC%-○○-○○AE	F30	Boring Bar (Dynamic Bar)
A○○□-	SDUC%-○○-○○AE	F29	Boring Bar (Dynamic Bar)
A○○□-	SDZC%-○○-○○AE	F31	Boring Bar (Dynamic Bar)
A○○□-	STLC%-○○-○○AE	F34	Boring Bar (Dynamic Bar)
A○○□-	STLP%-○○-○○AE	F33	Boring Bar (Dynamic Bar)
A○○□-	STUP%-○○-○○E	F56	Boring Bar
A○○□-	SVJB%-○○-○○AE	F37	Boring Bar (Dynamic Bar)
A○○□-	SVJC%-○○-○○AE	F37	Boring Bar (Dynamic Bar)
A○○□-	SVJP%-○○-○○AE	F37	Boring Bar (Dynamic Bar)
A○○□-	SVPB%-○○-○○AE	F37	Boring Bar (Dynamic Bar)
A○○□-	SVPC%-○○-○○AE	F37	Boring Bar (Dynamic Bar)
A○○□-	SVUB%-○○-○○AE	F39	Boring Bar (Dynamic Bar)
A○○□-	SVUC%-○○-○○AE	F39	Boring Bar (Dynamic Bar)
A○○□-	SVZB%-○○-○○AE	F39	Boring Bar (Dynamic Bar)
A○○□-	SVZC%-○○-○○AE	F39	Boring Bar (Dynamic Bar)
A○○□-	SWUB%-○○-○○AE	F41	Boring Bar (Dynamic Bar)
A○○□-	SWUP%-○○-○○AE	F41	Boring Bar (Dynamic Bar)
AABSR	○○○○□-○○F	E8	Toolholder (Turning)
AABWR	○○○○□-○○F	E9, E10	Toolholder (Turning)
ABS	○○R○○○○	B72	Insert (Turning)
ABS	○○R○○○○M	B72	Insert (Turning)
ABW	○○%-○○○○	B72	Insert (Turning)
ABW	○○R○○○○M	B72	Insert (Turning)
ACLC%-	○○○○□-○○F	E11	Toolholder (Turning)
AD○○□		F45	Boring Bar (AD Bar Adapter)
ADJC%-	○○○○□-○○F	E14	Toolholder (Turning)
ADNC%-	○○○○□-○○F	E20	Toolholder (Turning)
AJ-	○×○○(-○○○)	K11	Spare Parts (Adjusting Screw / Chamfering Attachment)
AJ-412		M25	Spare Parts (Adjusting screw)
AP-1416		M112, M113	Spare Parts (Cam Pin)
AP-1820		M112, M113	Spare Parts (Cam Pin)
APKT	○○○○(○○)PDER-V	M17	Insert (Milling)
APMT	○○○○○○E%-NB○	M17	Insert (Milling)
APMT	○○○○○○ER-NB○P	M17	Insert (Milling)
AVJB%-	○○○○□-○○F	E24	Toolholder (Turning)
AVVB%-	○○○○□-○○F	E23	Toolholder (Turning)
B			
BCS	-○	H19, P14	Spare Parts (Clamp Set)
BDGT	○○○○○○FR-JA	M16	Insert (Milling)
BDMT	○○○○○○ER-JS	M16	Insert (Milling)
BDMT	○○○○○○ER-JT	M16	Insert (Milling)
BDMT	○○○○○○ER-NO	M17	Insert (Milling)
BDMT	○○○○○○FR	C27, M21	Insert (Milling)
BGIAR	○○-○	G48	Blade (Grooving)

Description	Page	Category
BH3X6	F74, P2	Spare Parts (Bolt)
BH3X12	D33, D34, D35, F74, P2	Spare Parts (Bolt)
BH6X25	G11, P2	Spare Parts (Bolt)
BH8X30	G26, P2	Spare Parts (Bolt)
C		
C○○□- SCLC%○○-○○	F49	Boring Bar
C○○□- SCLC%○○-○○A	F25	Boring Bar (Dynamic Bar)
C○○□- SCLP%○○○○	F49	Boring Bar
C○○□- SCLP%○○-○○-○/○	F49	Boring Bar
C○○□- SDUC%○○-○○	F51	Boring Bar
C○○□- SJLC%○○-○○○	F53	Boring Bar
C○○□- SJZC%○○-○○○	F53	Boring Bar
C○○□- STLB%○○-○○A	F33	Boring Bar (Dynamic Bar)
C○○□- STUB%○○-○○	F55	Boring Bar
C○○□- STUP%○○-○○	F55	Boring Bar
C○○□- STUP%○○-○○-○/○	F55	Boring Bar
C○○□- STXB%○○-○○○	F58	Boring Bar
C○○□- STXP%○○-○○	F58	Boring Bar
C○○□- STZB%○○-○○○	F58	Boring Bar
C○○□- SWUB%○○-○○	F65	Boring Bar
C○○□- SWUB%○○-○○A	F41	Boring Bar (Dynamic Bar)
C○○□- SWUB%○○-○○-○/○	F65	Boring Bar
C○○□- SWUP%○○-○○	F65	Boring Bar
C○○□- SWUP%○○-○○-○/○	F65	Boring Bar
C17R	M41, P13	Spare Parts (Clamp)
C20R	M31, P13	Spare Parts (Clamp)
C25R	M39, P13	Spare Parts (Clamp)
C43R	M28	Spare Parts (Clamp)
C44R	M28	Spare Parts (Clamp)
C90SD ○○○○-12%	M112, M113	Spare Parts (Cartridge)
C90SP ○○○○-10%	M112, M113	Spare Parts (Cartridge)
C91R	M40	Spare Parts (Clamp)
C92R	M40	Spare Parts (Clamp)
CB-11	D25, D34, D35, P16	Spare Parts (Chipbreaker)
CB-12	D26, F72, P16	Spare Parts (Chipbreaker)
CB-13	D26, F72, P16	Spare Parts (Chipbreaker)
CB-14	D23, P16	Spare Parts (Chipbreaker)
CB-15	D23, P16	Spare Parts (Chipbreaker)
CB-16	D22, D23, F72 P16	Spare Parts (Chipbreaker)
CB-17	D22, P16	Spare Parts (Chipbreaker)
CB-51	D25, P16	Spare Parts (Chipbreaker)
CB-S3220	E28, P16	Spare Parts (Chipbreaker)
CB-S4220	E28, P16	Spare Parts (Chipbreaker)
CBSN% ○○○○□-○○	D38	Toolholder (Turning)
CBSN% ○○○○B-12-A20	F71	Boring Bar (for Bearing Machining)
CB-T2212	E29, P16	Spare Parts (Chipbreaker)
CB-T3220	E29, P16	Spare Parts (Chipbreaker)
CCET ○○○○○○(○)F%-USF	B48	Insert (Turning)
CCET ○○○○○○(○)MF%-USF	B48	Insert (Turning)
CCET ○○○○○○(○)M%-FSF	B47	Insert (Turning)
CCET ○○○○○○(○)%-FSF	B47	Insert (Turning)
CCGT ○○○○○○	B46, B74	Insert (Turning)
CCGT ○○○○○○AH	B46	Insert (Turning)
CCGT ○○○○○○E%-U	B48, B74	Insert (Turning)
CCGT ○○○○○○FN-Z	B46	Insert (Turning)
CCGT ○○○○○○(○)F%-U	B48, B74	Insert (Turning)
CCGT ○○○○○○(○)M	B46	Insert (Turning)
CCGT ○○○○○○M-CF	B45	Insert (Turning)
CCGT ○○○○○○ME%-U	B48	Insert (Turning)
CCGT ○○○○○○(○)MF	B46	Insert (Turning)
CCGT ○○○○○○MF-GF	B45	Insert (Turning)
CCGT ○○○○○○MFP-GF	B45	Insert (Turning)
CCGT ○○○○○○MF-GQ	B45	Insert (Turning)
CCGT ○○○○○○MFP-GQ	B45	Insert (Turning)
CCGT ○○○○○○(○)MF%-U	B48	Insert (Turning)
CCGT ○○○○○○(○)M%-F	B47	Insert (Turning)