

Description	Page	Category
CNMN ○○○○○○T○○○○○	B81	Insert (Turning)
CNMP ○○○○○○TK	B14, B40	Insert (Turning)
CNMU ○○○○○○E-GK	B38	Insert (Turning)
CP-2D	D14	Spare Parts (Clamp)
CP-3D	D8, D10, D12, D20	Spare Parts (Clamp)
CP-5D	D16	Spare Parts (Clamp)
CP-8TE	M41, P13	Spare Parts (Clamp)
CP-8W	M41, P13	Spare Parts (Clamp)
CPGB ○○○○○○	C10	Insert (Turning) / Previous Description
CPGB ○○○○○○ME	C10	Insert (Turning) / Previous Description
CPGB ○○○○○○ME-T	C10	Insert (Turning) / Previous Description
CPGB ○○○○○○SE	C10	Insert (Turning) / Previous Description
CPGB ○○○○○○SE-T	C10	Insert (Turning) / Previous Description
CPGB ○○○○○○S○○○○○MET	C10	Insert (Turning)
CPGB ○○○○○○S○○○○○SET	C10	Insert (Turning)
CPGB ○○○○○○T○○○○○	C10	Insert (Turning)
CPGB ○○○○○○T○○○○○ME	C10	Insert (Turning)
CPGB ○○○○○○T○○○○○SE	C10	Insert (Turning)
CPMB ○○○○○○	B49	Insert (Turning)
CPMH ○○○○○○	B49, B74, C18	Insert (Turning)
CPMH ○○○○○○HQ	B49, B74	Insert (Turning)
CPMH ○○○○○○NE	C18	Insert (Turning)
CPMH ○○○○○○%L-Y	B49, B74	Insert (Turning)
CPMT ○○○○○○GP	B49, B74	Insert (Turning)
CPMT ○○○○○○XP	B49, B74	Insert (Turning)
CPMT ○○○○○○XQ	B49, B74	Insert (Turning)
CP-RC%L	D38, F71, P14	Spare Parts (Clamp Set)
CP8X○○TL	M26, P2	Spare Parts (Screw)
CPS-1	F61, P15	Spare Parts (Clamp Set)
CPS-2	F60, F61, P15	Spare Parts (Clamp Set)
CPS-2P	E28, E29, P15	Spare Parts (Clamp Set)
CPS-2S	M85, P15	Spare Parts (Clamp Set)
CPS-2TR	M82, P15	Spare Parts (Clamp Set)
CPS-3	E28, E29, F60, F61, P15	Spare Parts (Clamp Set)
CPS-4V	G41, P15	Spare Parts (Clamp Set)
CPS-5E	M85, P15	Spare Parts (Clamp Set)
CPS-5F	G41, M132, P15	Spare Parts (Clamp Set)
CPS-5%L	D17, P15	Spare Parts (Clamp Set)
CPS-5S	J16, J17, N10, P15	Spare Parts (Clamp Set)
CPS-5V	G41, G58, G60, G70, P15	Spare Parts (Clamp Set)
CPS-6F	M132, P15	Spare Parts (Clamp Set)
CPS-6M	M27, M31, M39, P15	Spare Parts (Clamp Set)
CPS-6S	J16, J17, N10, P15	Spare Parts (Clamp Set)
CPS-6V	G41, G60, G63, G70, M144, P15	Spare Parts (Clamp Set)
CPS-8V	G60, G63, G70, P15	Spare Parts (Clamp Set)
CRDNN ○○○○□-○○	D27	Toolholder (Turning)
CRDNN ○○○○□-○○A	D33	Toolholder (Turning)
CRSN%L ○○○○□-○○	D27	Toolholder (Turning)
CRSN%L ○○○○□-○○A	D33	Toolholder (Turning)
CS-2D	D14	Spare Parts (Screw)
CS-3D	D8, D10, D12, D20	Spare Parts (Screw)
CS-5D	D16	Spare Parts (Screw)
CSBP%L ○○○○□-○○N	E28	Toolholder (Turning)
CSDNN ○○○○□-○○	D25	Toolholder (Turning)
CSDNN ○○○○□-○○A	D35	Toolholder (Turning)
CSDNN ○○○○□-○○GX	D30	Toolholder (Turning)
CSDPN ○○○○□-○○N	E28	Toolholder (Turning)
CSKN%L ○○○○□-○○	D25	Toolholder (Turning)
CSKN%L ○○○○□-○○A	D34	Toolholder (Turning)
CSKN%L ○○○○B-○○	F72	Boring Bar / Previous Description
CSKN%L ○○○○B-○○A	F74	Boring Bar / Previous Description
CSKN%L ○○○○□-○○GX	D31	Toolholder (Turning)
CSKP%L ○○○○B-○○	F60	Boring Bar / Previous Description
CSKP%L ○○○○□-○○N	E28	Toolholder (Turning)
CS-N%L ○○○○□-○○	D25	Toolholder (Turning)
CS-N%L ○○○○□-○○GX	D31	Toolholder (Turning)

Description	Page	Category
CSRN%L ○○○○□-○○	D25	Toolholder (Turning)
CSRN%L ○○○○□-○○A	D34	Toolholder (Turning)
CSRN%L ○○○○□-○○GX	D30	Toolholder (Turning)
CSSN%L ○○○○□-○○	D25	Toolholder (Turning)
CSSN%L ○○○○□-○○A	D35	Toolholder (Turning)
CSSN%L ○○○○□-○○GX	D30	Toolholder (Turning)
CSSP%L ○○○○□-○○N	E28	Toolholder (Turning)
CSYN%L ○○○○□-○○	D25	Toolholder (Turning)
CSYN%L ○○○○□-○○A	D34	Toolholder (Turning)
CSYN%L ○○○○□-○○GX	D31	Toolholder (Turning)
CT○○○ -45A	K11	Insert (Drilling) / Chamfering
CTFP%L ○○○○□-○○N	E29	Toolholder (Turning)
CTGP%L ○○○○□-○○N	E29	Toolholder (Turning)
CTJN%L ○○○○□-○○	D26	Toolholder (Turning)
CTJN%L ○○○○□-○○A	D36	Toolholder (Turning)
CTTP%L ○○○○□-○○N	E29	Toolholder (Turning)
CTUC%L ○○○○B-○○	F72	Boring Bar / Previous Description
CTUN%L ○○○○B-○○A	F74	Boring Bar / Previous Description
CTUN%L ○○○○□-○○	D26	Toolholder (Turning)
CTUN%L ○○○○□-○○A	D36	Toolholder (Turning)
CTUP%L ○○○○B-○○	F61	Boring Bar / Previous Description

D

DC ○○○○M-SC	K4, K5, K6	Insert (Drilling)
DC-44	D8	Spare Parts (Shim)
DCET ○○○○○○(○)F%L-JSF	B55	Insert (Turning)
DCET ○○○○○○(○)F%L-USF	B54	Insert (Turning)
DCET ○○○○○○(○)M%L-FSF	B53	Insert (Turning)
DCET ○○○○○○(○)MF%L-JSF	B55	Insert (Turning)
DCET ○○○○○○(○)MF%L-USF	B54	Insert (Turning)
DCET ○○○○○○(○)%L-FSF	B53	Insert (Turning)
DCGT ○○○○○○	B51, B75	Insert (Turning)
DCGT ○○○○○○AH	B55	Insert (Turning)
DCGT ○○○○○○CF	B50, B75	Insert (Turning)
DCGT ○○○○○○CK	B50	Insert (Turning)
DCGT ○○○○○○EN-Z	B75	Insert (Turning)
DCGT ○○○○○○(○)E%L-J	B55	Insert (Turning)
DCGT ○○○○○○E%L-U	B54, B75	Insert (Turning)
DCGT ○○○○○○FN-Z	B52	Insert (Turning)
DCGT ○○○○○○(○)F%L-J	B55	Insert (Turning)
DCGT ○○○○○○(○)F%L-U	B54, B75	Insert (Turning)
DCGT ○○○○○○(○)M	B51	Insert (Turning)
DCGT ○○○○○○○○ME%L-J	B55	Insert (Turning)
DCGT ○○○○○○ME%L-U	B54	Insert (Turning)
DCGT ○○○○○○(○)MF	B51	Insert (Turning)
DCGT ○○○○○○○○MF%L-U	B54	Insert (Turning)
DCGT ○○○○○○MF-GF	B50	Insert (Turning)
DCGT ○○○○○○MF-GQ	B51	Insert (Turning)
DCGT ○○○○○○MFP-GF	B50	Insert (Turning)
DCGT ○○○○○○MFP-GQ	B51	Insert (Turning)
DCGT ○○○○○○(○)MF%L-J	B55	Insert (Turning)
DCGT ○○○○○○(○)MF%L-U	B54	Insert (Turning)
DCGT ○○○○○○(○)M%L-F	B53	Insert (Turning)
DCGT ○○○○○○M-CF	B50	Insert (Turning)
DCGT ○○○○○○MP-CF	B50	Insert (Turning)
DCGT ○○○○○○M-CK	B50	Insert (Turning)
DCGT ○○○○○○MP-CK	B50	Insert (Turning)
DCGT ○○○○○○%L-A3	B55	Insert (Turning)
DCGT ○○○○○○(○)%L-F	B53	Insert (Turning)
DCGT ○○○○○○%L-FS	B53	Insert (Turning)
DCGW ○○○○○○	B55	Insert (Turning)
DCLN%L ○○○○□-○○	D8	Toolholder (Turning)
DCMT ○○○○○○	B51, B75, C19	Insert (Turning)
DCMT ○○○○○○GK	B51	Insert (Turning)
DCMT ○○○○○○GP	B50, B75	Insert (Turning)
DCMT ○○○○○○HQ	B51, B75	Insert (Turning)
DCMT ○○○○○○MQ	B52	Insert (Turning)
DCMT ○○○○○○NE	C19	Insert (Turning)
DCMT ○○○○○○SE	C19	Insert (Turning)
DCMT ○○○○○○XP	B52, B75	Insert (Turning)
DCMT ○○○○○○XQ	B52, B75	Insert (Turning)
DCMT ○○○○○○%L-NE	C19	Insert (Turning)
DCMW ○○○○○○	C11	Insert (Turning) / Previous Description
DCMW ○○○○○○ME	C11	Insert (Turning) / Previous Description