

Description	Page	Category
E		
ENGN ○○○○○○	B83	Insert (Turning)
ENGN ○○○○○○S○○○○○	B83	Insert (Turning)
ENGN ○○○○○○T○○○○○	B83	Insert (Turning)
EO□□- SCLC%○○-○○	F50	Boring Bar
EO□□- SCLC%○○-○○A	F25	Boring Bar (Dynamic Bar)
EO□□- SCLC%○○-○○A-○/○	F25	Boring Bar
EO□□- SCLP%○○-○○	F50	Boring Bar
EO□□- SCLP%○○-○○A	F27	Boring Bar (Dynamic Bar)
EO□□- SCLP%○○-○○A-○/○	F27	Boring Bar (Dynamic Bar)
EO□□- SDQC%○○-○○A	F30	Boring Bar (Dynamic Bar)
EO□□- SDQC%○○-○○A-○/○	F30	Boring Bar (Dynamic Bar)
EO□□- SDUC%○○-○○A	F29	Boring Bar (Dynamic Bar)
EO□□- SDUC%○○-○○A-○/○	F29	Boring Bar (Dynamic Bar)
EO□□- SDZC%○○-○○A	F31	Boring Bar (Dynamic Bar)
EO□□- STLP%○○-○○A	F33	Boring Bar (Dynamic Bar)
EO□□- STLP%○○-○○A-○/○	F33	Boring Bar (Dynamic Bar)
EO□□- STUP%○○-○○	F56	Boring Bar
EO□□- SVPB%○○-○○A	F37	Boring Bar (Dynamic Bar)
EO□□- SVPC%○○-○○A	F37	Boring Bar (Dynamic Bar)
EO□□- SVUB%○○-○○A	F39	Boring Bar (Dynamic Bar)
EO□□- SVUC%○○-○○A	F39	Boring Bar (Dynamic Bar)
EO□□- SWUB%○○-○○A	F41	Boring Bar (Dynamic Bar)
EO□□- SWUB%○○-○○A-○/○	F41	Boring Bar (Dynamic Bar)
EO□□- SWUP%○○-○○A	F41	Boring Bar (Dynamic Bar)
EO□□- SWUP%○○-○○A-○/○	F41	Boring Bar (Dynamic Bar)
F		
FGG%L ○○○○-○○	G19	Insert (Grooving / Plunge&Turn)
FH-2	P17	Spare Parts (Hexagon Wrench / Flag type)
FH-2.5	P17	Spare Parts (Hexagon Wrench / Flag type)
FMM ○○-○○	G67	Insert (Grooving / Plunge&Turn)
FMN ○	G67	Insert (Grooving / Plunge&Turn)
FPMT ○○○○○○ER	M20	Insert (Milling)
FS- ○○	K11	Spare Parts (Drill fitting screw for Chamfering Attachment)
FT-6	P17	Spare Parts (Trox Wrench / Flag type)
FT-7	F34, P17	Spare Parts (Trox Wrench / Flag type)
FT-8	P17	Spare Parts (Trox Wrench / Flag type)
FT-10	P17	Spare Parts (Trox Wrench / Flag type)
FT-15	G15, P17	Spare Parts (Trox Wrench / Flag type)
FTK ○	G69	Insert (Cut-Off)
FTS-15	F44	Spare Parts (Trox Wrench / Flag type)
G		
GA ○○	G17	Insert (Grooving)
GB ○○%○○○	C24, G10	Insert (Grooving)
GB ○○%○○○R	G10	Insert (Grooving)
GBA ○○%○○○	C16, C24, G6, G7, G8	Insert (Grooving)
GBA ○○%○○○MY	G7	Insert (Grooving)
GBA ○○%○○○R	G8	Insert (Grooving)
GBA ○○%○○○-○○○	C16, C24, G6, G7, G8	Insert (Grooving)
GBA ○○%○○○-○○○MY	G7	Insert (Grooving)
GBA ○○%○○○-○○○R	G8	Insert (Grooving)
GE%L ○○○-○○○□	G34, G35	Insert (Grooving)
GER ○○○-○○○□□	G34, G35	Insert (Grooving)
GFV%L ○○○○□-○○○(○)□	G60	Toolholder (Grooving)
GFVS%L ○○○○□-HB	G62	Toolholder (Grooving)
GFVS%L ○○○○□-HC	G62	Toolholder (Grooving)
GFVS%L ○○○○□-○○AA	G58	Toolholder (Grooving)
GFVS%L ○○○○□-○○○(○)□	G62, G63	Toolholder (Grooving)
GFVT%L ○○○○□-HB	G62	Toolholder (Grooving)
GFVT%L ○○○○□-HC	G62	Toolholder (Grooving)
GFVT%L ○○○○□-○○AA	G58	Toolholder (Grooving)
GFVT%L ○○○○□-○○○(○)□	G62, G63	Toolholder (Grooving)
GH ○○○○-○○	B90, G17, G45	Insert (Grooving)
GHU ○○○○	G17, G45	Insert (Grooving)
GIA ○○	G48	Insert (Grooving)
GIFV%L ○○○○B-○○○□	G70	Toolholder (Grooving)
GIV%L ○○○○-○□E	G41	Toolholder (Grooving)
GIV%L ○○○○-○□W	G41	Toolholder (Grooving)
GIV%L ○○○○-○□	G41	Toolholder (Grooving)
GIV%L ○○○○-○□(□)	G41	Toolholder (Grooving)

Description	Page	Category
GMG ○○○○-○○	G18, G47, G68	Insert (Grooving / Plunge&Turn) / Previous Description
GMG ○○○○-○○R	G18, G47, G68	Insert (Grooving / Plunge&Turn) / Previous Description
GMG ○○○○-○○MG	G18, G47, G68	Insert (Grooving / Plunge&Turn) / Previous Description
GMG ○○○○-○○RU	G18	Insert (Grooving / Plunge&Turn) / Previous Description
GMG ○○○○-○○○R	G18, G47, G68	Insert (Grooving / Plunge&Turn)
GMG ○○○○-○○○MG	G18, G47, G68	Insert (Grooving / Plunge&Turn)
GMG ○○○○-○○○MS	G18	Insert (Grooving / Plunge&Turn)
GMG ○○○○-○○○RU	G18	Insert (Grooving / Plunge&Turn)
GMGA ○○○○-○○R	G19, G47, G68	Insert (Grooving / Plunge&Turn) / Previous Description
GMGA ○○○○-○○○R	G19, G47, G68	Insert (Grooving / Plunge&Turn)
GMM 3014-04	G19	Insert (Grooving / Plunge&Turn)
GMM 3014-15R	G19	Insert (Grooving / Plunge&Turn)
GMM 3014-15RU	G19	Insert (Grooving / Plunge&Turn)
GMM ○○○○%L-MT-15D	G20, H10	Insert (Grooving / Plunge&Turn)
GMM ○○○○%L-TK-8D	G20, H10	Insert (Grooving / Plunge&Turn)
GMM ○○○○-MT	G20, H10	Insert (Grooving / Plunge&Turn)
GMM ○○○○-NB	G20, H10	Insert (Grooving / Plunge&Turn)
GMM ○○○○-TK	G20, H10	Insert (Grooving / Plunge&Turn)
GMM ○○○○-○○	G18, G47, G68	Insert (Grooving / Plunge&Turn) / Previous Description
GMM ○○○○-○○R	G18	Insert (Grooving / Plunge&Turn) / Previous Description
GMM ○○○○-TMR	H10	Insert (Grooving / Plunge&Turn)
GMM ○○○○%L-TMR-6D	H10	Insert (Grooving / Plunge&Turn)
GMM ○○○○-○○V	G46	Insert (Grooving / Plunge&Turn) / Previous Description
GMM ○○○○-○○MS	G18	Insert (Grooving / Plunge&Turn) / Previous Description
GMM ○○○○-○○VR	G46	Insert (Grooving / Plunge&Turn) / Previous Description
GMM ○○○○-○○○R	G18	Insert (Grooving / Plunge&Turn)
GMM ○○○○-○○○V	G46	Insert (Grooving / Plunge&Turn)
GMM ○○○○-○○○MS	G18	Insert (Grooving / Plunge&Turn)
GMM ○○○○-○○○MW	G18, G47, G68	Insert (Grooving / Plunge&Turn)
GMM ○○○○-○○○VR	G46	Insert (Grooving / Plunge&Turn)
GMN ○ (.)	C16, C24, G20, G21, H10	Insert (Grooving / Plunge&Turn)
GMN ○-TK	G20, H10	Insert (Grooving / Plunge&Turn)
GM%L ○-TK-8D	G20, H10	Insert (Grooving / Plunge&Turn)
GM%L ○-○(○)D	G20, H10	Insert (Grooving / Plunge&Turn)
GMGW ○○○○-○○R	C25, G26	Insert (Grooving / Plunge&Turn)
GMGW ○○○○-○○R-HR	C25, G26	Insert (Grooving / Plunge&Turn)
GOMT ○○○○○○ER-D	M18	Insert (Milling)
GP-1	K40, K42, K44, P18	Spare Parts (Plug)
GP-2	K40, K41, K42, K43, K44, K45, K46, P18	Spare Parts (Plug)
GS 91-○	B90, G26	Insert (Grooving)
GS-40TR	P2	Spare Parts (Screw)
GS-50	F60, G15, G24, G44, G46, J22, J23, P2	Spare Parts (Screw)
GS-50S	F60, P2	Spare Parts (Screw)
GS-4090T%LW	P2	Spare Parts (Screw)
GV%L ○○○□R	G42	Insert (Grooving)
GV%L ○○○□(□)	C24, G42, M133	Insert (Grooving)
GV%L ○○○-○○○□(□)	C24, G42, M133	Insert (Grooving)
GVF%L ○○○□	C24, G65, G71, M140	Insert (Grooving)
GVF%L ○○○AA	G59	Insert (Grooving)
GVF%L ○○○□R	G65, G71	Insert (Grooving)
GVF%L ○○○-○○○□	C24, G65, G71, M140	Insert (Grooving)
GVF%L ○○○-○○○□R	G65, G71	Insert (Grooving)
GVF%L ○○○-○○○AA	G59	Insert (Grooving)
H		
HA○○ PCLN%L12-○○	F42	Boring Bar (AD Bar Interchangeable Head)
HA○○ PDUN%L15-○○	F43	Boring Bar (AD Bar Interchangeable Head)
HA○○ PTFN%L16-○○	F43	Boring Bar (AD Bar Interchangeable Head)
HA○○ SCLC%L09-○○	F44	Boring Bar (AD Bar Interchangeable Head)
HA○○ SDUC%L11-○○	F44	Boring Bar (AD Bar Interchangeable Head)
HF20x53H	M46, P6	Spare Parts (Bolt with Coolant Hole)
HF24x60H	M46, P6	Spare Parts (Bolt with Coolant Hole)
HH3X6	F76, P2	Spare Parts (Bolt)
HH3X12	D32, D33, D34, D35, D36, F76, P2	Spare Parts (Bolt)