

Description Index

○ : Figure, □ : Alphabet

Description	Page	Category
RDHX ○○○○M0T	M20	Insert (Milling)
RDMT ○○○○M0-H	M20	Insert (Milling)
RNGN ○○○○○○	B83	Insert (Turning)
RNGN ○○○○○○K○○○○○	B83	Insert (Turning)
RNGN ○○○○○○P○○○○○	B83	Insert (Turning)
RNGN ○○○○○○S○○○○○	B83	Insert (Turning)
RNGN ○○○○○○T○○○○○	B83	Insert (Turning)
RNMG ○○○○○○	B24	Insert (Turning)
RNMN ○○○○○○	C9	Insert (Turning) / Previous Description
RNMN ○○○○○○S○○○○○	C9	Insert (Turning)
RPMT ○○○○○○	M20	Insert (Milling)
RPMT ○○○○M0	M20	Insert (Milling)
RPMT ○○○○M0-H	M20	Insert (Milling)
RPMT ○○○○M0-BB	B73	Insert (Turning)

S

SO□□- CCLN%○○-○OA	F74	Boring Bar
SO□□- CCLN%○○-○○GX	F73	Boring Bar
SO□□- CDUN%○○-○○GX	F73	Boring Bar
SO□□- CELN%○○-○○	F72	Boring Bar
SO□□- CSKN%○○-○○	F72	Boring Bar
SO□□- CSKN%○○-○OA	F74	Boring Bar
SO□□- CSKN%○○-○○GX	F73	Boring Bar
SO□□- CSKP%○○-○○	F60	Boring Bar
SO□□- CTUC%○○-○○	F72	Boring Bar
SO□□- CTUN%○○-○OA	F74	Boring Bar
SO□□- CTUP%○○-○○	F61	Boring Bar
SO□□- KTGLF16	G13	Sleeve Holder (Grooving)
SO□□- KTTXL16	J20	Sleeve Holder (Threading)
SO□□- PCLN%○○-○○	F66	Boring Bar
SO□□- PDUN%○○-○○	F67	Boring Bar
SO□□- PTUN%○○-○○	F68	Boring Bar
SO□□- PWLN%○○-○○	F69, F70	Boring Bar
SO□□- SCLCLOO	E13	Sleeve Holder (Turning)
SO□□- SCLC%○○-○○	F49	Boring Bar
SO□□- SCLC%○○-○OA	F25	Boring Bar (Dynamic Bar)
SO□□- SCLC%○○-○○E	F49	Boring Bar
SO□□- SCLC%○○-○OAE	F25	Boring Bar (Dynamic Bar)
SO□□- SCLP%○○-○○	F49	Boring Bar
SO□□- SCLP%○○-○OA	F27	Boring Bar (Dynamic Bar)
SO□□- SCLP%○○-○○E	F49	Boring Bar
SO□□- SDLC%○○	E19	Sleeve Holder (Turning)
SO□□- SDQC%○○-○OA	F30	Boring Bar (Dynamic Bar)
SO□□- SDUC%○○	E19	Sleeve Holder (Turning)
SO□□- SDUC%○○-○○	F51	Boring Bar
SO□□- SDUC%○○-○OA	F29	Boring Bar (Dynamic Bar)
SO□□- SDUC%○○-○○E	F51	Boring Bar
SO□□- SDZC%○○-○○	F52	Boring Bar
SO□□- SDZC%○○-○OA	F31	Boring Bar (Dynamic Bar)
SO□□- SDZC%○○-○○E	F52	Boring Bar
SO□□- SSKP%○○-○○	F60	Boring Bar
SO□□- STLB%○○-○OA	F33	Boring Bar (Dynamic Bar)
SO□□- STLB%○○-○OAE	F33	Boring Bar (Dynamic Bar)
SO□□- STLC%○○-○OA	F34	Boring Bar (Dynamic Bar)
SO□□- STLP%○○-○OA	F33	Boring Bar (Dynamic Bar)
SO□□- STUB%○○-○○	F54	Boring Bar
SO□□- STUB%○○-○○E	F54	Boring Bar
SO□□- STUP%○○-○○	F54	Boring Bar
SO□□- STUP%○○-○○E	F54	Boring Bar
SO□□- STW%15	F9, G55	Toolholder (for Twin Bar)
SO□□- STWP%○○-○○	F57, J28	Toolholder (Boring / Threading)
SO□□- STWP%○○-○○E	F57, J28	Toolholder (Boring / Threading)
SO□□- SVJB%○○-○OA	F37	Boring Bar (Dynamic Bar)
SO□□- SVJB%○○-○○E	F62	Boring Bar
SO□□- SVJB%○○-○○EN	F62	Boring Bar
SO□□- SVJC%○○-○OA	F37	Boring Bar (Dynamic Bar)
SO□□- SVJC%○○-○○E	F62	Boring Bar
SO□□- SVJP%○○-○OA	F37	Boring Bar (Dynamic Bar)
SO□□- SVJP%○○-○○E	F62	Boring Bar
SO□□- SVNR12	F14	Toolholder (for System Tip-Bar)
SO□□- SVNR12N	F14	Toolholder (for System Tip-Bar)
SO□□- SVNR12S	F14	Toolholder (for System Tip-Bar)
SO□□- SVNR12SN	F14	Toolholder (for System Tip-Bar)
SO□□- SVNR12XN	F17	Toolholder (for System Tip-Bar)

Description	Page	Category
SO□□- SVNR12SXN	F17	Toolholder (for System Tip-Bar)
SO□□- SVPB%○○-○OA	F37	Boring Bar (Dynamic Bar)
SO□□- SVPB%○○-○○E	F62	Boring Bar
SO□□- SVPB%○○-○○EN	F62	Boring Bar
SO□□- SVPC%○○-○OA	F37	Boring Bar (Dynamic Bar)
SO□□- SVUB%○○	E27	Sleeve Holder (Turning)
SO□□- SVUC%○○	E27	Sleeve Holder (Turning)
SO□□- SVPC%○○-○○E	F62	Boring Bar
SO□□- SVUB%○○-○OA	F39	Boring Bar (Dynamic Bar)
SO□□- SVUC%○○-○OA	F39	Boring Bar (Dynamic Bar)
SO□□- SVUB%○○-○○E	F63	Boring Bar
SO□□- SVUB%○○-○○EN	F63	Boring Bar
SO□□- SVUC%○○-○○E	F63	Boring Bar
SO□□- SVZB%○○-○OA	F39	Boring Bar (Dynamic Bar)
SO□□- SVZB%○○-○○E	F63	Boring Bar
SO□□- SVZB%○○-○○EN	F63	Boring Bar
SO□□- SVZC%○○-○OA	F39	Boring Bar (Dynamic Bar)
SO□□- SVZC%○○-○○E	F63	Boring Bar
SO□□- SWUB%○○-○○	F65	Boring Bar
SO□□- SWUB%○○-○OA	F41	Boring Bar (Dynamic Bar)
SO□□- SWUB%○○-○OAE	F41	Boring Bar (Dynamic Bar)
SO□□- SWUB%○○-○○E	F65	Boring Bar
SO□□- SWUB%○○-○○-○○	F65	Boring Bar
SO□□- SWUP%○○-○OA	F41	Boring Bar (Dynamic Bar)
SO□□- SWUP%○○-○○E	F65	Boring Bar
SO□□- SYXP%○○-○○E	F59	Boring Bar
SO□□- WWLN%○○-○○E	F70	Boring Bar
SO□- CH○○	K10	Toolholder ("Magic Drill" / Chamfering Attachment)
SFOO- DRC○○○M-○	K12, K13, K14	Toolholder ("Magic Drill")
SSOO- DRC○○○M-○	K7, K8, K9	Toolholder ("Magic Drill")
SOO- DRS○○○○○	K38	Toolholder ("Magic Drill")
SOO- DRX○○○M-○-○○	K24, K25, K26, K27, K28, K29, K30	Toolholder ("Magic Drill")
SOO- DRZ○○○○○-12CR	K47	Toolholder ("Magic Drill")
SOO- DRZ○○○○○-20CR	K47	Toolholder ("Magic Drill")
SOO- DRZ○○○○○(○○)-○○	K40, K41, K42, K43, K44, K45, K46	Toolholder ("Magic Drill")
SABSR ○○○○□-○○F	E8	Toolholder (Turning)
SABWR ○○○○□-○○F	E9, E10	Toolholder (Turning)
SB-1STR	F54, F55, F58, P4	Spare Parts (Screw)
SB-3STR	F49, F50, F57, J28, P4	Spare Parts (Screw)
SB-1TR	F54, F55, F56, F58, P4	Spare Parts (Screw)
SB-2TR	F54, F55, F56, F58, J17, P4	Spare Parts (Screw)
SB-3TR	F54, F55, F56, F57, J28, P4	Spare Parts (Screw)
SB-3.5TR	J16, J17, P4	Spare Parts (Screw)
SB-4TR	F49, F50, F54, F55, F56, F57, F60, F71, G15, G44, J22, J23, P4	Spare Parts (Screw)
SB-5TR	G23, G24, G46, H13, P4	Spare Parts (Screw)
SB-1635TR	F25, F49, F53, P4	Spare Parts (Screw)
SB-2035TR	F25, F33, F41, P4	Spare Parts (Screw)
SB-2040TR	F49, F59, F65, J17, P4	Spare Parts (Screw)
SB-2045TR	F59, K24, K26, K28, K40, K42, K44, P4	Spare Parts (Screw)
SB-2050TR	E22, E25, E26, E27, F37, F39, F41, F63, F65, J17, P4	Spare Parts (Screw)
SB-2060TR	P4	Spare Parts (Screw)
SB-2080TR	K38, P4	Spare Parts (Screw)
SB-2250TR	F34, K24, K26, K28, K30, M136, P4	Spare Parts (Screw)
SB-2255TR	G36, G37, G38, P4	Spare Parts (Screw)
SB-2260TR	K40, K42, K44, M136, P4	Spare Parts (Screw)