для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
LW-3	D8, E49, H20-H21, K12, K14, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-4	E48, E49, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-4.5	E50, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-5	C2, C4, E44, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-6	P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-8	P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-10	E35, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-14	E35, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-17	E16, E35, P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-19	P18	Spare Parts (Hexagon Wrench / L-Shape Type)
LW-32	P9	Spare Parts (Shim)
LW-32N	P9	Spare Parts (Shim)
LW-42	P9	Spare Parts (Shim)
LW-42N	P9	Spare Parts (Shim)
LW-42N℀	P9	Spare Parts (Shim)
LW-42℀	P9	Spare Parts (Shim)
M		
M3X8	P4	Spare Parts (Screw)
M3X12	P4	Spare Parts (Screw)
M4X10	P4	Spare Parts (Screw)
MAP-1806	D5	Spare Parts (Cartridge)
MAP-1806M	E56	Spare Parts (Cartridge)
MAP-1806S	E56	Spare Parts (Cartridge)
MAP-2506	E59, E61, P12	Spare Parts (Shim)
MAP 100R○○-S100	E74	End Mill
MCSE ○○○	K6	End Mill (Chamfering)
MCSE ○○○-○○D	K6	End Mill (Chamfering)
MEAL ○○-S○○	E68	End Mill (for Aluminum Machining)
MEC ○○○○-S○○○-○○	E12	End Mill (MEC)
MEC ○○○○-S○○○-○○T	E12	End Mill (MEC)
MEC ○○○○-S○○○-○.○-○○	E12	End Mill (MEC)
MEC ○○○○-S○○○-○.○-○○T	E12	End Mill (MEC)
MEC ○○-M○○-○○(T)-○T	E17	Modular Type Head (MEC)
MEC ○○-S○○-○○	E13-E14	End Mill (MEC)
MEC ○○-S○○-○○T	E13	End Mill (MEC)
MEC ○○-S○○-○○○-○○	E14	End Mill (MEC)
MEC ○○-S○○-○○○-○○-○	E14	End Mill (MEC)
MEC ○○-S○○-○○○-○○T	E13	End Mill (MEC)
MEC ○○-S○○-○○○-○○T-○	E13	End Mill (MEC)
MEC ○○○○R-○○(T)-○T(N)	E15	Face Mill (MEC)
MEC ○○○R-○○-○(○)T(N)	E16	Face Mill (MEC)
MEC ○○○R-○○-○(○)T-M(N)	E16	Face Mill (MEC)
MEC ○○○R-○○-○(○)(□)□	E16	Face Mill (MEC)
MECH ○○○○-W○○○(○)-○○-○-○T	E32	End Mill (MECH)
MECH ○○○-S○○-○○-○-○T	E32	End Mill (MECH)
MECH ○○○○R-○○-○-○T	E33	End Mill (MECH)
MECH ○○○R-○○-○-○T	E33	End Mill (MECH)
MECH ○○○R-○○-○-○T-M	E33	Shell Mill (MECH)
MECH ○○○R○○-○-○T-BT○○	E33	End Mill (MECH)
MECH ○○○R○○-○T-BT○○-A	E34	End Mill (MECH)
MECH ○○○R○○-○T-BT○○SA	E34	End Mill (MECH)
MECH ○○○R○○-○T-F	E35	End Mill (MECH)
MECX ○○○○-S○○○-○○-○T	E24	End Mill (MECX)
MECX ○○-S○○-○○-○T	E24	End Mill (MECX)
MECX ○○-S○○-○○○-○○-○T	E24	End Mill (MECX)
MECX ○○○○R-○○-○(○)T	E25	Face Mill (MECX)
MECX ○○○R-○○-○(○)T-M	E25	Face Mill (MECX)
MEF ○○-S○○	K8	End Mill (Countersinking)
METS ○○-S○○	K10	End Mill (T-Slotting)
METS ○○-S○○-H	K10	End Mill (T-Slotting)
MEW ○○-M○○-○○-○T	E8	Modular Type Head (MEW)
MEW ○○-S○○-○○-○T	E5	End Mill (MEW)
MEW ○○-S○○-○○-○○○-○T	E5	End Mill (MEW)
MEW ○○-W○○-○○-○T	E5	End Mill (MEW)
MEW ○○○○R-○○-○T	E6	Face Mill (MEW)
MEW ○○○R-○○-○T(-M)	E7	Face Mill (MEW)
MEW ○○○○-S○○○-○-○○-○T	E4	End Mill (MEW)
MEW ○○○○-W○○○-○○-○T	E4	End Mill (MEW)
MEWH ○○○R-○○-○-○T-M	E30	Shell Mill (MEWH)
MEWH ○○○-S○○-○○-○-○T	E29	End Mill (MEWH)
MEWH ○○○○R-○○-○-○T	E30	Shell Mill (MEWH)
MEWH ○○○○-W○○○-○○-○-○T	E29	End Mill (MEWH)
MEY ○○○○-S○○○-HG	G2	End Mill (3-D End Mill)
MEY ○○-S○○	G2	End Mill (3-D End Mill)
MEY ○○-S○○-○○○	G2	End Mill (3-D End Mill)
MEY ○○-S○○-○○○H	G2	End Mill (3-D End Mill)
MEZ ○○-S○○G	G6	End Mill (3-D End Mill)
MEZ ○○-S○○-○○○G	G6	End Mill (3-D End Mill)
MEZ ○○-S○○-○○○HG	G6	End Mill (3-D End Mill)
MFH ○○○○-M○○-○○-○T	F17	Modular Type Head (MFH)
MFH ○○○○-S○○○-○○-○T-○(○)	F7, F14	End Mill (MFH)
MFH ○○○○-W○○-○○-○T	F7	End Mill (MFH)
MFH ○○○○-W○○○-○○-○T-○	F14	End Mill (MFH)
MFH ○○○(○)R-○○-○T	F4-F5, F16	Face Mill (MFH)
MFH ○○○R-○○-○T-M	F5	Face Mill (MFH)
MFH ○○○R-○○-○T-○○M	F5	Face Mill (MFH)
MFH ○○○○-S○○○-○○-○T-○(○)	F22	End Mill (MFH)
MFH ○○-M○○-○○-○T	F10, F17	Modular Type Head (MFH)
MFH ○○-S○○-○○-○T	F8-F9, F15, F22	End Mill (MFH)
MFH ○○-S○○-○○-○T-○○○	F8, F15	End Mill (MFH)
MFH ○○-W○○-○○-○T	F8, F15, F22	End Mill (MFH)
MFK ○○○(○)R-○○-○(○)T	C10-C11	Face Mill (MFK)
MFK ○○○R-○○-○(○)T-M	C11	Face Mill (MFK)
MFPN-45	C2, C4, P9	Spare Parts (Shim)
MFPN 45○○○○(○)R-○(○)T	C2	Face Mill (MFPN)
MFPN 45○○○℀-○(○)T	C3	Face Mill (MFPN)
MFPN 45○○○R-○(○)T-M	C3	Face Mill (MFPN)
MFPN 45○○○R-S32-○T	C4	End Mill (MFPN)
MFPN 45○○○○R-W125-○T	C4	End Mill (MFPN)
MFWN-90	E44, P9	Spare Parts (Shim)
MFWN ○○○○○○(○)R-○(○)T	E42	Face Mill (MFWN)
MFWN ○○○○○R-○(○)T	E43	Face Mill (MFWN)
MFWN ○○○○○R-○(○)T-M	E43	Face Mill (MFWN)
MFWN ○○○○○○R-W125-○T	E45	Face Mill (MFWN)
MFWN ○○○○○R-S○○-○T	E45	Face Mill (MFWN)
MGI ○○○○-1□(□)	K12	End Mill (Grooving for M/C)
MOF 45○○○R-○○-○(○)T	C14	Face Mill
MOF 45○○○R-○○-○(○)T-M	C14	Face Mill
MOFX 45○○○R-○○-○(○)T-SF	C16	Face Mill
MOFX 45○○○R○○-○(○)T-MSF	C16	Face Mill
MP-1	C2, C4, D5, E6-E8, E17, E29-E30, E32-E33, E35, E44-E45, E56, E59, E61, F4, F6-F10, F14-F17, F22, G2, H9, H20-H21, J2, J6-J9, J13-J14, J17	Spare Parts (Anti-seize Compound)
MRF ○○-S○○	J2	End Mill (Ball-Nose)
MRF ○○-S○○-○○○	J2	End Mill (Ball-Nose)
MRFW ○○-S○○	J2	End Mill (Ball-Nose)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru