для заказа - kyocera@kyocera-tools.ru

KTGF-F

Part Number			Spare Parts	
			Clamp Screw	Wrench
KTGF R/L	·····	-16F	SB-4070TRW	FT-8

KN91

Part Number			Spare Parts				
			Clamp	Clamp Bolt	Washer	Spring	Wrench
KN91 R/L	44	-4	*CE-111/121	BH8X30	W-8	SP-8	LW-5
	44	-5					
	44	-7	*CE-131/141				

* KN91R/L44-4 / 5 ... CE-111 for Right-hand Toolholder, and CE-121 for Left-hand Toolholder.
KN91R/L44-7 ... CE-131 for Right-hand Toolholder, and CE-141 for Left-hand Toolholder.

KGHS

Part Number			Spare Parts				
			Clamp	Clamp Bolt	Washer	Spring	Wrench
KGHS R/L	·····	-4	CGH-1	HH6X25	W-6	SP-6	LW-5
	·····	-5					
	·····	-7	CGH-2				

• Clamp: KGHSR/L ... CGH- O L for Right-hand Toolholder, and CGH- O R for Left-hand Toolholder.

KGM (Small Parts Machining)

Part Number			Spare Parts	
			Clamp Screw	Wrench
KGMR/L	0810K	- ···	SE-40120TR	LTW-15S
	1010··	- ···		
	1212··	- 1.5-···		
	1212··	- 2-···		
	1212··	- 2.5-···		
	1616··	- 2-···	SE-50125TR	LTW-20
	1616··	- 2.5-···		
	1616··	- 3-···		

GFVS-AA / GFVT-AA

Part Number			Spare Parts	
			Clamp Set	Wrench
GFVSR/L	·····	-08AA	CPS-5V	FT-15
GFVTR/L	·····	-08AA	CPS-5V	FT-15

KTKH-S

Part Number			Spare Parts
			Releasing Wrench
KTKHR/L	·····	- ···S	LTK-5

KTKH-B

Part Number			Spare Parts	
			Clamp Screw	Wrench
KTKHR/L	0808K	- ···B	SE-40120TR	FT-15
	1010K	- ···B		
	1212M	- ···B		
	1414M	- ···B		
	1616M	- ···B	SE-50125TR	LTW-20

KTTX

Part Number			Spare Parts	
			Clamp Screw	Wrench
KTTXR	·····	-16F	SB-4070TRW	FT-8

kyocera@kyocera-tools.ru
www.kyocera-tools.ru