для заказа - kyocera@kyocera-tools.ru

Parts Compatibility of Lever Lock Toolholders

1) For better usability of lever lock toolholders, some levers, lock screws and shims are modified.

2) It is highly recommended to use only new parts. However, they are compatible with conventional parts and can be used together with them.

3) It is possible to use new parts only with a toolholder which has been in use.

4) When purchasing replacements, order them stating the new numbers.

5) Some of the shims remain unmodified.

Category	Ref. Page	Toolholder Description			Spare Parts					
					Lever		Lock Screw		Shim	
					New No.	Conventional	New No.	Conventional	New No.	Conventional
External Toolholders		PCLNR/L		·····09	LL-1N	LL-1	LS-1N	LS-1	LC-32N	LC-32
				·····12	LL-2N	LL-2	LS-2N	LS-2	LC-42N	LC-42
				·····16	LL-5N	LL-5	LS-4N	LS-4	LC-53N	LC-53
		PDJNR/L		·····11	LL-1DN	LL-1D	LS-1N	LS-1	LD-32N	LD-32
				·····15	LL-3N	LL-3	LS-2N	LS-2	LD-42	
		PSBNR/L		·····09	LL-1N	LL-1	LS-1N	LS-1	LS-32	
				·····12	LL-2N	LL-2	LS-2N	LS-2	LS-42	
		PSKNR/L		·····09	LL-1N	LL-1	LS-1N	LS-1	LS-32	
				·····12	LL-2N	LL-2	LS-2N	LS-2	LS-42	
		PSSNR/L		·····09	LL-1N	LL-1	LS-1N	LS-1	LS-32	
				·····12	LL-2N	LL-2	LS-2N	LS-2	LS-42	
		PSDNN		·····09	LL-1N	LL-1	LS-1N	LS-1	LS-32	
				·····12	LL-2N	LL-2	LS-2N	LS-2	LS-42	
		PTGNR/L		1212F-11	LL-03N	LL-03	LS-03N	LS-03	-	
				·····11	LL-03TN	LL-03T	LS-03SN	LS-03S	-	
				·····16	LL-1N	LL-1	LS-1N	LS-1	LT-32N	LT-32
				·····22	LL-2N	LL-2	LS-2N	LS-2	LT-42N	LT-42
		PTFNR/L		1212F-11	LL-03N	LL-03	LS-03N	LS-03	-	
				·····11	LL-03TN	LL-03T	LS-03SN	LS-03S	-	
				·····16	LL-1N	LL-1	LS-1N	LS-1	LT-32N	LT-32
				·····22	LL-2N	LL-2	LS-2N	LS-2	LT-42N	LT-42
		PRGCR/L		·····12	LL-1CN	LL-1C	LS-1N	LS-1	LR-12C	
		PRXCR/L		·····12						
		PRGNR/L		·····09	LL-1N	LL-1	LS-1N	LS-1	LR-80	
				·····12	LL-2N	LL-2	LS-2N	LS-2	LR-81	
		PWLNR/L		·····06	LL-1N	LL-1	LS-1N	LS-1	LW-32N	LW-32
				·····08	LL-2N	LL-2	LS-2N	LS-2	LW-42N	LW-42
Boring Bars		□16M-	PCLNR/L	09-20	LL-03SN	LL-03S	LS-03SN	LS-03S	-	
		□20Q-		09-27	LL-1N	LL-1	LS-1SN	LS-1S	LC-32N	LC-32
		□25R-		09-32						
		·····	PCLNR/L	12···	LL-2N	LL-2	LS-2N	LS-2	LC-42NR/L	LC-42R/L
		·····	PDUNR/L	11···	LL-1DN	LL-1D	LS-1SN	LS-1S	LD-32N	LD-32
		·····	PTUNR/L	11···	LL-03TN	LL-03T	LS-03SN	LS-03S	-	
		S25R-	PTUNR/L	16-30	LL-03SN	LL-03S	LS-03SN	LS-03S	-	
		S32S-		16-40	LL-1N	LL-1	LS-1N	LS-1	LT-32N	LT-32
		S40T-		16-50						
		□16M-	PWLNR/L	06-20	LL-03SN	LL-03S	LS-03SN	LS-03S	-	
		□20Q-		06-27	LL-1N	LL-1	LS-1SN	LS-1S	LW-32N	LW-32
		□25R-		06-32						
		·····	PWLNR/L	08···	LL-2N	LL-2	LS-2N	LS-2	LW-42NR/L	LW-42R/L
Turning Mill		T63H-	PCLNR/L	-DX12	LL-2N	LL-2	LS-2N	LS-2	LC-42N	LC-42
		T63H-	PCMNN	-□12						
		T63H-	PDJNR/L	-DX15	LL-3N	LL-3	LS-2N	LS-2	LD-42	
		T63H-	PDNNN	-□15						
		T63H-	PTGNR/L	-DX16	LL-1N	LL-1	LS-1N	LS-1	LT-32N	LT-32
		T63H-	PWLNR/L	-DX08	LL-2N	LL-2	LS-2N	LS-2	LW-42N	LW-42

kyocera@kyocera-tools.ru
www.kyocera-tools.ru