для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number	Page	Description
HH10X35HK	P3	Spare Parts (Screw)
HH10X40	P3	Spare Parts (Screw)
HH12X25	P3	Spare Parts (Screw)
HH12X35	P3	Spare Parts (Screw)
HH12X35H	P3	Spare Parts (Screw)
HH12X35HK	P3	Spare Parts (Screw)
HH12X35M	P3	Spare Parts (Screw)
HH12X40	P3	Spare Parts (Screw)
HH12X55	P3	Spare Parts (Screw)
HH12X65	P3	Spare Parts (Screw)
HH12X80	P3	Spare Parts (Screw)
HH12X85	P3	Spare Parts (Screw)
HH12X100	P3	Spare Parts (Screw)
HH12X110	P3	Spare Parts (Screw)
HH12X120	P3	Spare Parts (Screw)
HH12X130	P3	Spare Parts (Screw)
HH12X140	P3	Spare Parts (Screw)
HH12X150	P3	Spare Parts (Screw)
HH16X35	P3	Spare Parts (Screw)
HH16X40	P3	Spare Parts (Screw)
HH16X45	P3	Spare Parts (Screw)
HH16X52H	P3	Spare Parts (Screw)
HH16X65	P3	Spare Parts (Screw)
HH16X90	P3	Spare Parts (Screw)
HH16X110	P3	Spare Parts (Screw)
HH16X130	P3	Spare Parts (Screw)
HH20X40	P3	Spare Parts (Screw)
HH20X55	P3	Spare Parts (Screw)
HH20X75	P3	Spare Parts (Screw)
HH20X90	P3	Spare Parts (Screw)
HH20X110	P3	Spare Parts (Screw)
HH20X120	P3	Spare Parts (Screw)
HH20X140	P3	Spare Parts (Screw)
HH20X150	P3	Spare Parts (Screw)
HH20X170	P3	Spare Parts (Screw)
HH24X40	P3	Spare Parts (Screw)
HH24X60	P3	Spare Parts (Screw)
HH24X75	P3	Spare Parts (Screw)
HH24X90	P3	Spare Parts (Screw)
HH24X110	P3	Spare Parts (Screw)
HH24X120	P3	Spare Parts (Screw)
HH24X140	P3	Spare Parts (Screw)
HH24X150	P3	Spare Parts (Screw)
HH24X170	P3	Spare Parts (Screw)
HPB℅ ○○○○-○○○	F36	2-Edge Tip-Bars (Boring)
HPB℅ ○○○○-○○○NB	F36	2-Edge Tip-Bars (Boring)
HPBT℅ ○○○○-○○○	F36	2-Edge Tip-Bars (Back Boring)
HPFG℅ ○○○○-○○	G79	2-Edge Tip-Bars (Internal Face Grooving)
HPG℅ ○○○○-○○	G51	2-Edge Tip-Bars (Internal Grooving)
HPTR ○○○○○-○○-○○○	J32	2-Edge Tip-Bars (Internal Threading)
HRSN℅ ○○-○□	D29	Toolholder (Turning)
HS3X4	F30, F31, F32, F94, P4	Spare Parts (Screw)
HS3X4P	F22, F24, F27, P4	Spare Parts (Screw)
HS3X8	F31, P4	Spare Parts (Screw)
HS3X12	P4	Spare Parts (Screw)
HS3X16	P4	Spare Parts (Screw)
HS4X4	F94, F95, N14-N16, P4	Spare Parts (Screw)
HS4X4P	F22, F24, F27, P4	Spare Parts (Screw)
HS5X5	F95, N14-N16, P4	Spare Parts (Screw)
HS6X4P	F94, G57, P4	Spare Parts (Screw)
HS6X6	F95, P4	Spare Parts (Screw)
HS6X14	F95, P4	Spare Parts (Screw)
HS6X22	F95, P4	Spare Parts (Screw)
HS8X10	N10, P4	Spare Parts (Screw)
HS8X12	N10, P4	Spare Parts (Screw)
HS10X10	F95, P4	Spare Parts (Screw)
HS10X16	N10, P4	Spare Parts (Screw)
HS12X12	N10, P4	Spare Parts (Screw)
HS12X16	N10, P4	Spare Parts (Screw)
HS12X18	N10, P4	Spare Parts (Screw)
HS12X20	N10, P4	Spare Parts (Screw)
HS12X25	N3, P4	Spare Parts (Screw)
HS12X30	N3-N4, P4	Spare Parts (Screw)
HS12X35	N4, P4	Spare Parts (Screw)
HS16X12	N10, P4	Spare Parts (Screw)
HS16X18	N10, P4	Spare Parts (Screw)
HS16X20	N10, P4	Spare Parts (Screw)
HSB4X8℅	E17-E19, E22, E24, E30, P4	Spare Parts (Screw)
HSDNN ○○-○□	D27	Toolholder (Turning)
HSH655	D29	Spare Parts (Shim)
HSH657	D29	Spare Parts (Shim)
HSH661	D29	Spare Parts (Shim)
HSH665A	D29	Spare Parts (Shim)
HSRN℅ ○○-○□	D27	Toolholder (Turning)
I		
ICSN433	D8, D24	Spare Parts (Shim)
ICSN453	D24	Spare Parts (Shim)
ICSN533	D8	Spare Parts (Shim)
ICSN633	D8	Spare Parts (Shim)
IDSN433	D25	Spare Parts (Shim)
IDSN443	D10	Spare Parts (Shim)
IDSN453	D25	Spare Parts (Shim)
IRSN43	D29	Spare Parts (Shim)
IRSN45	D29	Spare Parts (Shim)
ISSN433	D12, D27	Spare Parts (Shim)
ISSN453	D27	Spare Parts (Shim)
ITSN323	D14	Spare Parts (Shim)
ITSN333	D14	Spare Parts (Shim)
ITSN432	D14	Spare Parts (Shim)
IVSN322	D19	Spare Parts (Shim)
IWSN432	D22	Spare Parts (Shim)
J		
JCET ○○○○○(○)M℅-F	B66	Insert (Turning)
JCET ○○○○○(○)M℅-FSF	B66	Insert (Turning)
JCET ○○○○○(○)℅-FSF	B66	Insert (Turning)
JCGT ○○○○○(○)M℅-F	B66	Insert (Turning)
JCGT ○○○○○(○)℅-F	B66	Insert (Turning)
K		
KDB℅ 16-1	G43	Toolholder (External Grooving)
KCFP ○○○○℅	G117	Insert (Cera-Notch Grooving / Threading)
KCG ○○○○℅	G30, G70	Insert (Cera-Notch Grooving / Threading)
KCGP ○○○○℅	G30, G70	Insert (Cera-Notch Grooving / Threading)
KCGDP ○○○○℅	G30, G70	Insert (Cera-Notch Grooving / Threading)
KCRP	G30, G70	Insert (Cera-Notch Grooving / Threading)
KCT ○℅	J17	Insert (Cera-Notch Grooving / Threading)
KCTP ○℅	J17	Insert (Cera-Notch Grooving / Threading)
KCTK ○℅	J17	Insert (Cera-Notch Grooving / Threading)
KFMS℅ ○○-○-○○○○(○)(○)	G118-G119	Toolholder (Face Grooving)
KFMS℅ ○○○○□○○(○)○○(○)-8	G120	Toolholder (Face Grooving)
KFMS℅ ○○○○□○○(○)○○(○)-○	G118-G119	Toolholder (Face Grooving)
KFTB℅ ○○○○○(○)-○S	G121	Blade (Face Grooving)
KGA℅ ○○○○□-○	G41	Toolholder (Grooving)
KGBA℅ ○○-○	G11	Toolholder (Grooving)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru