для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
KGBA®/℠	○○-○-○○(□)	G11	Toolholder (Grooving)
KGBA®/℠	○○○○□-○○	G11	Toolholder (Grooving)
KGBA®/℠	○○○○22-○○	G11	Toolholder (Grooving)
KGBA®/℠	○○○○22-○○T5	G11	Toolholder (Grooving)
KGBAS®/℠	○○-○	G11	Toolholder (Grooving)
KGBAS®/℠	○○-○-○○	G11	Toolholder (Grooving)
KGBAS®/℠	○○○○□-○○	G11	Toolholder (Grooving)
KGBAS®/℠	○○○○□22-○○	G11	Toolholder (Grooving)
KGBAS®/℠	○○○○□22-○○T5	G11	Toolholder (Grooving)
KGDF®/℠	-○○(○)-○□-C	G86-G93, G95-G105	Blade (Face Grooving)
KGDF®/℠	○○○○X○○(○)-○S	G90-G93	Toolholder (Face Grooving)
KGDF®/℠	○○○○○○(○)-○B-Z	G94	Toolholder (Face Grooving)
KGD®/℠	○○-C	G86-G89	Toolholder Body (Grooving / Cut-Off)
KGD®/℠	○T○○-C	G22-G23, G25	Blade (Grooving / Cut-Off)
KGD®/℠	○○○○-C	G22-G25, G90-G93	Toolholder Body (Grooving / Cut-Off)
KGD®/℠	○○-○T○○	G20, H16	Toolholder (Grooving / Cut-Off)
KGD®/℠	○○○○-○(.○)T○○	G21, H17	Toolholder (Grooving / Cut-Off)
KGD®/℠	○(○)-○(.○)□□	G19, H14	Toolholder (Grooving / Cut-Off)
KGD®/℠	○○-○D○○□□	G19, H14	Toolholder (Grooving / Cut-Off)
KGD®/℠	○○○○□(□)-○(.○)	G19, H14	Toolholder (Grooving / Cut-Off)
KGD®/℠	○○○○-○D○○	G19, H14	Toolholder (Grooving / Cut-Off)
KGD®/℠	○○X-○T○○S	G22, H18	Toolholder (Grooving / Cut-Off)
KGD®/℠	○○○○X-○T○○S	G23, H19	Toolholder (Grooving / Cut-Off)
KGDIR	○○B-○	G65	Toolholder (Internal Grooving)
KGDI®/℠	○○○○B-○	G65	Toolholder (Internal Grooving)
KGDS®/℠	○○-C	G95-G99	Toolholder (Grooving)
KGDS®/℠	○○○○-C	G24-G25, G100-G104	Toolholder (Grooving)
KGDS®/℠	○○○○JX-○(.○)B	H15	Toolholder (Cut-Off)
KGDS®/℠	○○○○X-○T○○S	G24	Toolholder (Grooving)
KGH®/℠	○○○○□-○(○)	G40	Toolholder (Grooving)
KGHS®/℠	○○○○□-○	G40	Toolholder (Grooving)
KGIAR	○○H	G69	Toolholder (Grooving / Toolholder Body)
KGIAR	○○○○B-○	G69	Toolholder (Grooving)
KGM®/℠	○-○-○	G36, H24	Toolholder (Grooving / Cut-Off)
KGM®/℠	○○-○	G36, H24	Toolholder (Grooving / Cut-Off)
KGM®/℠	○○○○□(□)-○(.○)	G36, H24, H33	Toolholder (Grooving / Cut-Off)
KGM®/℠	○○-○T	G37, H24	Toolholder (Grooving / Cut-Off)
KGM®/℠	○○○○-○T○○	G37, H25	Toolholder (Grooving / Cut-Off)
KGMM®/℠	○○○○□-○	G38, H25	Toolholder (Grooving)
KGMS®/℠	○○○○□-○	G38	Toolholder (Grooving)
KGMU®/℠	○○○○□	G39	Toolholder (Grooving)
KGMW®/℠	○○○○□-○	G44	Toolholder (Grooving)
KIGBA®/℠	○○-○	G62	Toolholder (Grooving)
KIGBA®/℠	○○○○-○○	G62	Toolholder (Grooving)
KIGHR	○○○○B-○	G67	Toolholder (Grooving)
KIGM®/℠	○○○○B-○	G68	Toolholder (Grooving)
KIGM®/℠	○○B-○V	G66	Toolholder (Grooving)
KIGM®/℠	○○○○B-○V	G66	Toolholder (Grooving)
KIGMU®/℠	○○○○B-○	G68	Toolholder (Grooving)
KITG®/℠	○○○○T-○○	G63, J26	Toolholder (Grooving / Threading)
KKC®/℠	○-○□(□)	G31, J16	Toolholder (Cera-Notch Grooving / Threading)
KKC®/℠	○○○○□-○-○○○F	G31, J16	Toolholder (Cera-Notch Grooving / Threading)
KKCE®/℠	○○-○□	G117	Toolholder (Cera-Notch Face Grooving)
KN91®/℠	44-○	P25	Toolholder (Grooving / Discontinued Description)
KNMX	○○○○○○®/℠	B28	Insert (Turning)
KPS-42		E42, F70, P8	Spare Parts (Shim)
KPT-32		E43, F71, P8	Spare Parts (Shim)
KPT-42		P8	Spare Parts (Shim)
KSTB	SR○○/○○ CCET○○○	E44	Sub Spindle Tools
KSTB	SR○○□ CCET○○○	E44	Sub Spindle Tools
KSTB	SR○○/○○ DCET○○○	E44	Sub Spindle Tools
KSTB	SR○○□ DCET○○○	E44	Sub Spindle Tools
KSTB	SR○○/○○ VBET○○○	E44	Sub Spindle Tools
KSTB	SR○○□ VBET○○○	E44	Sub Spindle Tools
KSTB	SR○○/○○ TGF○○	E45	Sub Spindle Tools
KSTB	SR○○□ TGF○○	E45	Sub Spindle Tools
KSTB	SR○○/○○ TT○○	E45	Sub Spindle Tools
KSTB	SR○○□ TT○○	E45	Sub Spindle Tools
KTG®/℠	○○○○□-○○	G14	Toolholder (Grooving)
KTG®/℠	○○○○□22-○○	G14	Toolholder (Grooving)
KTGF®/℠	○○○○□-○○	G12	Toolholder (Grooving)
KTGF®/℠	○○○○□(□)-○○F	G12	Toolholder (Grooving)
KTGF®/℠	○(○)-○JXF	G12	Toolholder (Grooving)
KTKB	○○-○S	H28	Blade (Cut-Off)
KTKB	○○-○SS	H28	Blade (Cut-Off)
KTKB®/℠	○○-○S	H28	Blade (Cut-Off)
KTKFL	○○(.○)-○○□□	E12	Toolholder (Back Turning / Cut-Off / Threading)
KTKFL	○○○○□□-○○	E12, E51, J22	Toolholder (Back Turning / Cut-Off / Threading)
KTKF®/℠	○(○)(.○)-○○□□	E12, J22, H8	Toolholder (Back Turning / Cut-Off / Threading)
KTKF®/℠	○○○○□(□)-○○	E12, E51, J22, H8, H33	Toolholder (Back Turning / Cut-Off / Threading)
KTKFS®/℠	○-○○□□	H10	Toolholder (Cut-Off)
KTKFS®/℠	○○○○□-○○A/B	H10	Toolholder (Cut-Off)
KTKH®/℠	○○-○S	H31	Toolholder (Cut-Off)
KTKH®/℠	○-○(.○)-○S	H30	Toolholder (Cut-Off)
KTKH®/℠	○○○○□-○S	H31	Toolholder (Cut-Off)
KTKH®/℠	○○○○□-○T○○S	H31	Toolholder (Cut-Off)
KTKH®/℠	○○○○-○(.○)-○○○B	H33	Toolholder (Cut-Off)
KTKH®/℠	○○○○-○-○○○S	H33	Toolholder (Cut-Off)
KTKTB	○○-○○	H29	Block (Cut-Off)
KTKTBF	○○-○○	H29	Block (Cut-Off)
KTN®/℠	○○-○	J20	Toolholder (Threading)
KTN®/℠	○○○○□-○○	J20	Toolholder (Threading)
KTN®/℠	○○○○□□-○○F	J20	Toolholder (Threading)
KTNSR	○○○○□-○○	J20	Toolholder (Threading)
KTT®/℠	○○○○□-○○	J26	Toolholder (Threading)
KTTXR	○(○)-○□□F	J24	Toolholder (Threading)
KTTXR	○○○○□(□)-○○F	J24	Toolholder (Threading)
KVN-32		D20, P8	Spare Parts (Shim)
L			
LC-32		P9	Spare Parts (Shim)
LC-32N		D9, F78, P9	Spare Parts (Shim)
LC-42		P9	Spare Parts (Shim)
LC-42N		D9, E40, P9	Spare Parts (Shim)
LC-42N-20		D9, P9	Spare Parts (Shim)
LC-42®/℠		P9	Spare Parts (Shim)
LC-42N®/℠		F78, P9	Spare Parts (Shim)
LC-42N®/℠-20		P9	Spare Parts (Shim)
LC-4K		F73, P9	Spare Parts (Shim)
LC-53		P9	Spare Parts (Shim)
LC-53N		D9, P9	Spare Parts (Shim)
LCP025097		F22	Spare Parts (Adjustment Pin)
LCP025140		F24	Spare Parts (Adjustment Pin)
LD-4K		P9	Spare Parts (Shim)
LD-4K43		P9	Spare Parts (Shim)
LD-32		F79, P9	Spare Parts (Shim)
LD-32N		D11, F79, P9	Spare Parts (Shim)
LD-42		D11, F82, N5-N6, P9	Spare Parts (Shim)
LD-42-20		D11, F82, N5-N6, P9	Spare Parts (Shim)
LD-4K		F74, P9	Spare Parts (Shim)
LD-4K43		F74, P9	Spare Parts (Shim)
LD-43		D11, P9	Spare Parts (Shim)
LD-43-20		D11, P9	Spare Parts (Shim)
LGBA-16®/℠S		G11, G62, N9, P14	Spare Parts (Clamp Set)
LGBA-22®/℠S		G11, G62, N9, P14	Spare Parts (Clamp Set)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru