для заказа - kyocera@kyocera-tools.ru

Part Numbers in Alphanumeric Order

○ : NUMBER □ : LETTER

Part Number		Page	Description
TPG	○○○(○)T○○○○○SE	C18	Insert (Turning)
TPGR	○○○(○)□-A/B/C	B76	Insert (Turning)
TPGR	○○○○(○)(○)□-F	B75	Insert (Turning)
TPGT	○○○(○)	B73	Insert (Turning)
TPGT	○○○○○○CF	B71	Insert (Turning)
TPGT	○○○○○○M-CF	B71	Insert (Turning)
TPGT	○○○○○○MP-CF	B71	Insert (Turning)
TPGW	○○○S○○○○○MET	C16	Insert (Turning)
TPGW	○○○S○○○○○SET	C16	Insert (Turning)
TPGW	○○○T○○○○○ME	C16	Insert (Turning)
TPGW	○○○T○○○○○SE	C16	Insert (Turning)
TPMC	○○NV○○○○○	J19	Insert (Threading)
TPMH	○○○(○)(○)(○)	C27	Insert (Turning)
TPMH	○○○(○)(○)(○)NE	C27	Insert (Turning)
TPMH	○○○(○)□-NE	C28	Insert (Turning)
TPMH	○○○(○)(○)(○)SE	C27	Insert (Turning)
TPM	○○○	B76	Insert (Turning / Milling)
TPMR	○○○	B75	Insert (Turning)
TPMR	○○○DP	B75	Insert (Turning)
TPMR	○○○(○)(○)(○)G	B75	Insert (Turning)
TPMR	○○○GP	B75	Insert (Turning)
TPMR	○○○HQ	B75	Insert (Turning)
TPMT	○○○(○)(○)(○)GP	B71	Insert (Turning)
TPMT	○○○(○)(○)(○)HQ	B71	Insert (Turning)
TPMT	○○○(○)(○)(○)PP	B71	Insert (Turning)
TPMT	○○○(○)(○)XP	B71	Insert (Turning)
TPMT	○○○XQ	B72	Insert (Turning)
TPMX	○○○(○)(○)WP	B71	Insert (Turning)
TS-3S		D19, P7	Spare Parts (Lock Pin)
TT-15		P18	Spare Parts (Torx Wrench / T-shaped Type)
TT-25		P18	Spare Parts (Torx Wrench / T-shaped Type)
TT-25L		P18	Spare Parts (Torx Wrench / T-shaped Type)
TT-30		P18	Spare Parts (Torx Wrench / T-shaped Type)
TT	43E□○○○M	J26	Insert (Threading)
TT	○○□○○○○	J26, J27	Insert (Threading)
TTC-20		P18	Spare Parts (Torx Wrench / T-shaped Type)
TTC-25		P18	Spare Parts (Torx Wrench / T-shaped Type)
TTP-20		P18	Spare Parts (Torx Plus Wrench / T-shaped Type)
TTX	32R○○○○(○)	J25	Insert (Threading)
TTX	32R○○○○(○)S	J25	Insert (Threading)
TWBR	○○○○○-○○○	F34	Twin Bars (Turning)
TWBTR	○○○○○-○○○	F35	Twin Bars (Turning)
TWFGL	○○○	G80	Twin Bars (Face Grooving)
TWFGTR	○○○	G80	Twin Bars (Face Grooving)
V			
VBET	○○○○(○)M□-F	B78	Insert (Turning)
VBET	○○○○(○)M□-FSF	B77	Insert (Turning)
VBET	○○○(○)□-FSF	B77	Insert (Turning)
VBET	○○○(○)-FN-Z	B78	Insert (Turning)
VBET	○○○(○)(○)M□-Y	B78	Insert (Turning)
VBGT	○○○(○)(○)M□-F	B78	Insert (Turning)
VBGT	○○○○M□-Y	B78	Insert (Turning)
VBGT	○○○○□-F	B78	Insert (Turning)
VBGT	○○○(○)□-Y	B78	Insert (Turning)
VBGW	○○○MEF	C17	Insert (Turning)
VBGW	○○○S○○○○○MES	C17	Insert (Turning)
VBGW	○○○(○)S○○○○○MET	C17	Insert (Turning)
VBGW	○○○S○○○○○SET	C17	Insert (Turning)
VBGW	○○○(○)T○○○○○ME	C17	Insert (Turning)
VBGW	○○○(○)T○○○○○SE	C17	Insert (Turning)
VBMT	○○○(○)(○)	C28	Insert (Turning)
VBMT	○○○GP	B77	Insert (Turning)
VBMT	○○○HQ	B77	Insert (Turning)
VBMT	○○○(○)NE	C28	Insert (Turning)
VBMT	○○○(○)PP	B77	Insert (Turning)
VBMT	○○○(○)SE	C28	Insert (Turning)
VBMT	○○○(○)VF	B77	Insert (Turning)
VCGT	○○○	B79	Insert (Turning)
VCGT	○○○AH	B79	Insert (Turning)
VCGT	○○○□-A3	B79	Insert (Turning)
VCGT	○○○(○)-FN-Z	B79	Insert (Turning)
VCGW	○○○○○(○)S○○○○○MET	C17	Insert (Turning)
VCGW	○○○○○S○○○○○SET	C17	Insert (Turning)
VCGW	○○○○○(○)T○○○○○ME	C17	Insert (Turning)
VCGW	○○○○○(○)T○○○○○SE	C17	Insert (Turning)
VCMT	○○○○○(○)	C28	Insert (Turning)
VCMT	○○○(○)(○)(○)HQ	B79	Insert (Turning)
VCMT	○○○○○(○)NE	C28	Insert (Turning)
VCMT	○○○(○)(○)(○)PP	B79	Insert (Turning)
VCMT	○○○○○(○)SE	C28	Insert (Turning)
VCMT	○○○○(○)(○)VF	B79	Insert (Turning)
VNBR	○○○○-○○(○)	F29	System Tip-bars (Boring)
VNBR	○○○○-○○(○)NB	C34, F29	System Tip-bars (Boring)
VNBR	○○○○(○○)-○○(○)S	F28	System Tip-bars (Boring)
VNBTR	○○○○-○○(○)	F29	System Tip-bars (Boring)
VNBXR	○○○○(○)-○○(○)S	F32	System Tip-bars (Boring)
VNFGR	○○○○-○○	G78	System Tip-bars (Face Grooving)
VNFGR	○○○○-○○NB	C34, G78	System Tip-bars (Face Grooving)
VNGR	○○○○-○○	G50	System Tip-bars (Grooving)
VNGR	○○○○-○○NB	C34, G50	System Tip-bars (Grooving)
VNGA	○○○	B42	Insert (Turning)
VNGA	○○○MEF	C12	Insert (Turning)
VNGA	○○○S○○○○○	B96, C12	Insert (Turning)
VNGA	○○○(○)S○○○○○ME	C12	Insert (Turning)
VNGA	○○○S○○○○○MEH	C12	Insert (Turning)
VNGA	○○○S○○○○○MEP	C12	Insert (Turning)
VNGA	○○○S○○○○○MET	C12	Insert (Turning)
VNGA	○○○(○)S○○○○○SE	C12	Insert (Turning)
VNGA	○○○S○○○○○SET	C12	Insert (Turning)
VNGA	○○○T○○○○○	B96	Insert (Turning)
VNGA	○○○T○○○○○AA	B96	Insert (Turning)
VNGA	○○○T○○○○○ME	C12	Insert (Turning)
VNGA	○○○T○○○○○SE	C12	Insert (Turning)
VNGG	○○○MFP-SK	B42	Insert (Turning)
VNGG	○○○(○)M-SK	B42	Insert (Turning)
VNGG	○○○(○)□	B42	Insert (Turning)
VNMA	○○○T○○○○○AA	B96	Insert (Turning)
VNMG	○○○	B41	Insert (Turning)
VNMG	○○○GP	B41	Insert (Turning)
VNMG	○○○GU	B42	Insert (Turning)
VNMG	○○○HQ	B41	Insert (Turning)
VNMG	○○○MQ	B42	Insert (Turning)
VNMG	○○○MS	B42	Insert (Turning)
VNMG	○○○MU	B42	Insert (Turning)
VNMG	○○○(○)PP	B41	Insert (Turning)
VNMG	○○○PQ	B41	Insert (Turning)
VNMG	○○○TN-V	B41	Insert (Turning)
VNMG	○○○VF	B41	Insert (Turning)
VNMG	○○○XP	B42	Insert (Turning)
VNMM	○○○(○)M	C23	Insert (Turning)
VNMM	○○○(○)MNE	C23	Insert (Turning)
VNMM	○○○(○)MSE	C23	Insert (Turning)
VNTR	○○○-○○	J34	System Tip-bars (Threading)
VPET	○○○○(○)(○)F□-USF	B81	Insert (Turning)
VPET	○○○○(○)(○)M□-F	B81	Insert (Turning)
VPET	○○○○(○)(○)M□-FSF	B81	Insert (Turning)
VPET	○○○○(○)MF□-J	B81	Insert (Turning)

kyocera@kyocera-tools.ru
www.kyocera-tools.ru