











# TROUBLESHOOTING

## Cutting Edges Figuration and Countermeasures

Typical Cutting Edge Figuration	Observation	Causes	Countermeasures
Nose Wear	 <ul style="list-style-type: none"> <li>• Deterioration of surface roughness and dimensional accuracy</li> </ul>	<ul style="list-style-type: none"> <li>• Too high Vc</li> <li>• End of tool life</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce Vc</li> <li>• Change to higher wear resistant grade</li> </ul>
Notching	 <ul style="list-style-type: none"> <li>• Burr formation</li> <li>• Cutting force increase</li> </ul>	<ul style="list-style-type: none"> <li>• Too high f and Vc</li> </ul>	<ul style="list-style-type: none"> <li>• Sharper cutting performance</li> <li>• Reduce Vc</li> <li>• Change to higher heat resistant grade</li> </ul>
Crater Wear	 <ul style="list-style-type: none"> <li>• Chip control deterioration</li> <li>• Surface finish deterioration (peeled surface)</li> </ul>	<ul style="list-style-type: none"> <li>• Too high Vc</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce Vc</li> <li>• Change to high speed type like Cermet or Al2O3 coated insert</li> </ul>
Plastic Deformation	 <ul style="list-style-type: none"> <li>• Workpiece dimension's change</li> <li>• Crack at nose</li> </ul>	<ul style="list-style-type: none"> <li>• Too high cutting load</li> <li>• Inappropriate tool grade</li> </ul>	<ul style="list-style-type: none"> <li>• Change to harder grade</li> <li>• Reduce f and ap</li> </ul>
Crack from Wear	 <ul style="list-style-type: none"> <li>• Surface finish's sudden deterioration</li> <li>• Workpiece dimension changes</li> </ul>	<ul style="list-style-type: none"> <li>• Too high Vc</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce the pre-set tool life</li> <li>• Change to higher wear resistant grade</li> </ul>
Chipping	 <ul style="list-style-type: none"> <li>• Cutting force increase</li> <li>• Surface roughness deterioration</li> </ul>	<ul style="list-style-type: none"> <li>• Too high f</li> <li>• Chattering</li> <li>• Lack of insert toughness</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce f and ap</li> <li>• Change to more rigid toolholder</li> <li>• Change to tougher grade</li> </ul>
Crack from Welding or Built-up Edge	 <ul style="list-style-type: none"> <li>• Surface finish deterioration</li> <li>• Cutting force increase</li> </ul>	<ul style="list-style-type: none"> <li>• Too low Vc</li> </ul>	<ul style="list-style-type: none"> <li>• Increase Vc</li> <li>• Improve sharp cutting performance (rake angle, chamfer)</li> </ul>
Mechanical Fracture	 <ul style="list-style-type: none"> <li>• Sudden cracking</li> <li>• Unstable tool life</li> </ul>	<ul style="list-style-type: none"> <li>• Too high f and ap</li> <li>• Chattering</li> </ul>	<ul style="list-style-type: none"> <li>• Change to tougher grade</li> <li>• Enlarge chamfer</li> <li>• Enlarge Corner-R(r)</li> <li>• Change to more rigid toolholder</li> </ul>
Fracture from Thermal Crack	 <ul style="list-style-type: none"> <li>• Cracking by heat cycle</li> <li>• Possible in interrupted cutting and milling</li> </ul>	<ul style="list-style-type: none"> <li>• Too high Vc and f</li> </ul>	<ul style="list-style-type: none"> <li>• Reduce f</li> <li>• Reduce Vc</li> <li>• Change to dry cutting</li> </ul>
Flaking	 <ul style="list-style-type: none"> <li>• Possible in high-hardness material cutting</li> <li>• Possible in machining with chattering</li> </ul>	<ul style="list-style-type: none"> <li>• Lack of insert toughness</li> <li>• Lack of toolholder's rigidity</li> </ul>	<ul style="list-style-type: none"> <li>• Change to harder grade (TiC-base ceramic to CBN.)</li> <li>• Change to more rigid toolholder</li> <li>• Change edge preparation</li> </ul>

R  
TECHNICAL